



Incident Detection Camera

User Manual

Legal Information

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

- This product can only enjoy the after-sales service support in the country or region where the purchase is made.
- If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.



Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR

IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.
 Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 Note	Provides additional information to emphasize or supplement important points of the main text.

Contents

Chapter 1 Activation and Login	1
1.1 Activation	1
1.1.1 Default Information	1
1.1.2 Activate via SADP	1
1.1.3 Activate via Web Browser	2
1.2 Login	3
1.3 Download Plug-in	3
Chapter 2 Quick Configuration	5
Chapter 3 Network Configuration	6
3.1 Set IP Address	6
3.2 Set Port	8
3.3 Set IEEE 802.1X	10
3.4 Set DDNS	11
3.5 Set SNMP	11
3.6 Set QoS	13
3.7 Set Multicast	13
3.8 Set RTMP	14
3.9 Connect to Platform	14
3.9.1 Set Arming Host	14
3.9.2 Set SDK Listening	15
3.9.3 Set FTP	17
3.9.4 Set ISAPI Listening	19
3.9.5 Connect to ISUP Platform	21
3.9.6 Connect to OTAP	23
3.9.7 Connect to Hik-Connect	24
3.9.8 Set Integration Protocol	26

3.9.9 Set Cloud Storage	27
Chapter 4 Application Mode Configuration	28
4.1 Set Incident Detection	28
4.1.1 Set Linked Lane Parameters	28
4.1.2 Set Violation Incident	30
4.1.3 Set Linked Area	37
4.1.4 Draw Lane Lines and Incident Areas	38
4.2 Set Data Collection	39
4.2.1 Set Linked Lane Parameters	40
4.2.2 Set Traffic Flow Detection	41
4.2.3 Set Traffic Flow Information Overlay	44
Chapter 5 Capture Parameters Configuration	47
5.1 Set License Plate Recognition Parameters	47
5.2 Set Supplement Light Parameters	47
5.3 Set Feature Recognition	50
5.4 Set Target Picture Matting	50
5.5 Set Information Overlay	51
5.5.1 Set Single Picture Overlay	51
5.5.2 Set Composite Picture Overlay	54
5.6 Set Image Encoding Parameters	56
5.7 Set Picture Composition	58
5.8 Set Capture Schedule	60
5.9 Set Captured Image Parameters	61
5.10 Set ICR	62
5.11 Advanced Configuration	63
5.11.1 System Service	63
5.11.2 Vehicle Capture and Recognition Service	64
5.11.3 Set Image Format	65

Chapter 6 Radar Detection	66
6.1 Set Detection Parameters	66
6.2 Set Lane Parameters	69
6.3 Set Radar Calibration	71
6.3.1 Manual Calibration	72
6.3.2 Auto Calibration	74
6.3.3 Force Auto Calibration	76
6.4 Search Detected Vehicles	79
Chapter 7 View Real-Time Picture	81
Chapter 8 Live View and Local Configuration	85
8.1 Live View	85
8.1.1 Start/Stop Live View	85
8.1.2 Select Image Display Mode	85
8.1.3 Select Window Division Mode	85
8.1.4 Select Stream Type	85
8.1.5 Capture Picture Manually	85
8.1.6 Record Manually	85
8.1.7 Enable Digital Zoom	86
8.1.8 Enable Regional Focus	86
8.1.9 Select Video Mode	86
8.2 Set Snapshot Mode	87
8.3 PTZ Operation	87
8.4 Local Configuration	89
Chapter 9 Record and Capture	94
9.1 Set Storage Card	94
9.2 Set Record Schedule	95
9.3 Set Snapshot Schedule	97
9.4 Search Picture	97

9.5 Playback	98
Chapter 10 Encoding and Display	100
10.1 Set Camera Parameters	100
10.2 Set OSD	102
10.3 Set Video Encoding Parameters	104
10.4 Set ROI	105
10.5 Set Privacy Mask	107
10.6 Enable Regional Exposure	108
Chapter 11 Serial Port Configuration	109
11.1 Set RS-485	109
11.2 Set RS-232	110
Chapter 12 Event and Alarm	111
12.1 Exception Alarm	111
12.2 Set Email	111
12.3 Set Email Event	112
Chapter 13 Safety Management	113
13.1 Manage User	113
13.2 Enable User Lock	114
13.3 Set SSH	114
13.4 Prohibit PING	115
13.5 Set SDK Protocol Authentication Mode	115
13.6 Set RTSP Authentication	115
13.7 Set Timeout Logout	116
13.8 Set Password Validity Period	116
13.9 Set Login Mode	116
13.10 Set IP Address Filtering	117
13.11 Set HTTPS	117
13.11.1 Create and Install Self-signed Certificate	117

13.11.2 Install Authorized Certificate	118
Chapter 14 Maintenance	119
14.1 View Device Information	119
14.2 Synchronize Time	120
14.3 Set DST	121
14.4 Set Positioning	121
14.5 Download Debug Data	122
14.6 Search Log	123
14.7 Enable Maintenance Service	123
14.8 Reboot	125
14.9 Restore Parameters	125
14.10 Export Parameters	125
14.11 Import Configuration File	126
14.12 Upgrade	126

Chapter 1 Activation and Login

1.1 Activation

For the first-time access, you need to activate the device by setting an admin password. No operation is allowed before activation. The device supports multiple activation methods, such as activation via SADP software, web browser, and iVMS-4200 Client.



Note

Refer to the user manual of iVMS-4200 Client for the activation via client software.

1.1.1 Default Information

The device default information is shown as below.

- Default IP address: 192.168.1.64
- Default user name: admin

1.1.2 Activate via SADP

SADP is a tool to detect, activate, and modify the IP address of the device over the LAN.

Before You Start

- Get the SADP software from the supplied disk or the official website (<http://www.hikvision.com/>), and install it according to the prompts.
- The device and the computer that runs the SADP tool should belong to the same network segment.

The following steps show how to activate one device and modify its IP address. For batch activation and IP address modification, refer to *User Manual of SADP* for details.

Steps

1. Run the SADP software and search the online devices.
2. Find and select your device in online device list.
3. Enter a new password (admin password) and confirm the password.



Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

4. Click **Activate** to start activation.




Figure 1-1 Activate via SADP

Status of the device becomes **Active** after successful activation.

5. Modify IP address of the device.

- 1) Select the device.
- 2) Change the device IP address to the same network segment as your computer by either modifying the IP address manually or checking **Enable DHCP** (Dynamic Host Configuration Protocol).
- 3) Enter the admin password and click **Modify** to activate your IP address modification.

1.1.3 Activate via Web Browser

Use web browser to activate the device. For the device with the DHCP enabled by default, use SADP software or client software to activate the device.

Before You Start

Ensure the device and the computer are in the LAN with the same network segment.

Steps

1. Change the IP address of your computer to the same network segment as the device.
2. Open the web browser, and enter the default IP address of the device to enter the activation interface.
3. Create and confirm the admin password.



Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

4. Click **OK** to complete activation.
5. Go to the network settings interface to modify IP address of the device.

1.2 Login

You can log in to the device via web browser for further operations such as live view and local configuration.

Before You Start

Connect the device to the network directly, or via a switch or a router.

Steps

1. Open the web browser, and enter the IP address of the device to enter the login interface.
 2. **Optional:** Select the language.
 3. Enter **User Name** and **Password**.
 4. Click **Login**.
-



Note

- If live view failed, click  on the upper right corner of the interface to download the plug-in and install it.
 - Close the web browser to install the plug-in, or the installation may fail. If you still cannot realize live view after installing the plug-in, try to uninstall the plug-in and reinstall.
-
5. Reopen the web browser after the installation of the plug-in and repeat steps 1 to 4 to login.
 6. **Optional:** Click  on the upper right corner of the interface to log out of the device.

1.3 Download Plug-in

No plug-in mode is enabled by default. In no plug-in mode, the resolution of the live view image will be decreased and the live view may not be smooth. You can download and install plug-in to improve the live view condition.

In no-plug in mode, "No Plug-in Mode" prompt will appear on the upper right corner of the interface. You can click  to download the plug-in. Close the browser to install the plug-in to the computer. Then access to the IP address of the device again, and the "No Plug-in Mode" prompt will disappear from the upper right corner of the interface.




Figure 1-2 Download Plug-in

Chapter 2 Quick Configuration

Click **Quick Configuration** and follow the instructions to complete the basis configuration of the device.

Table 2-1 Quick Configuration

Configuration Sequence	Details
Application Mode	Select Trigger Mode and set the corresponding parameters. Refer to <u>Application Mode Configuration</u> for details.
Basic Parameters	• Device Information: Refer to <u>View Device Information</u> for details. • Time Settings: Refer to <u>Synchronize Time</u> and <u>Set DST</u> for details. • Network Parameters: Refer to <u>Set IP Address</u> for details.
Supplement Light Parameters	Refer to <u>Set Supplement Light Parameters</u> for details.
OSD Configuration	• Text Overlay on Video: Refer to <u>Set OSD</u> for details. • Text Overlay on Picture: Refer to <u>Set Information Overlay</u> for details.
Picture Configuration	Refer to <u>Set Picture Composition</u> for details.
Upload Picture	• Arm Upload: Refer to <u>Set Arming Host</u> for details. • SDK Listening: Refer to <u>Set SDK Listening</u> for details. • FTP: Refer to <u>Set FTP</u> for details. • ISAPI Listening: Refer to <u>Set ISAPI Listening</u> for details. • ISUP: Refer to <u>Connect to ISUP Platform</u> for details. • OTAP: Refer to <u>Connect to OTAP</u> for details. • Integration Protocol: Refer to <u>Set Integration Protocol</u> for details.

Chapter 3 Network Configuration

3.1 Set IP Address

IP address must be properly configured before you operate the device over network. IPv4 and IPv6 are both supported. Both versions can be configured simultaneously without conflicting to each other.

Steps



Note

The supported parameters vary with different models. The actual device prevails.

1. Go to **Configuration** → **Network** → **Network Parameters** → **Network Interface** .
2. Select **Dual-NIC Mode**.

Dual-Network Backup

Select it when the two network interfaces are connected to two network cables respectively. When one network interface fails, the other network interface will be employed automatically without influencing the data transmission.

NIC Settings

NIC Type	10M/100M/1000M Auto	DHCP	☐
IPv4 Address		IPv4 Subnet Mask	
IPv4 Default Gateway		IPv6 Address	
IPv6 Mode	☐ Manual ☒ DHCP ☐ Route Advertisement	IPv6 Default Gateway	
IPv6 Prefix Length	64	Mac Address	
MTU		Multicast Address	
Preferred DNS Server			

Figure 3-1 Dual-Network Backup

Multi-Network Isolation

Select it when different LANs are connected. Set the IP addresses of different network segments.

The screenshot displays a network configuration interface with three main sections: **NIC Settings**, **NIC 2 Router**, and **Network Parameters**.
The **NIC Settings** section includes tabs for **LAN 1** and **LAN 2**. Under **LAN 1**, there is a dropdown for **NIC Type** (set to 10M/100M/1000M Auto), input fields for **IPv4 Address**, **IPv4 Default Gateway**, **IPv6 Mode** (with radio buttons for Manual, DHCP, and Route Advertisement; DHCP is selected), **IPv6 Prefix Length** (set to 64), and **MTU** (set to 1500). To the right, there is a **DHCP** checkbox, input fields for **IPv4 Subnet Mask**, **IPv6 Address**, **IPv6 Default Gateway**, **Mac Address**, and **Multicast Address**.
The **NIC 2 Router** section contains four input fields for **Route Address1**, **Route Address2**, **Route Address3**, and **Route Address4**, all set to 0.0.0.0. To the right, there are four input fields for **Subnet Mask**, all set to 0.0.0.0.
The **Network Parameters** section has a **Preferred DNS Server** input field. At the bottom center is a blue **Save** button.

Figure 3-2 Multi-Network Isolation

Note

The dual-NIC mode varies with different models. The actual device prevails.

3. Set network parameters.

NIC Type

Select a NIC (Network Interface Card) type according to your network condition.

IPv4

Two modes are available.

DHCP

The device automatically gets the IP parameters from the network if you check **DHCP**. The device IP address is changed after enabling the function. You can use SADP to get the device IP address.

Note

The network that the device is connected to should support DHCP (Dynamic Host Configuration Protocol).

Manual

You can set the device IP parameters manually. Enter **IPv4 Address**, **IPv4 Subnet Mask**, and **IPv4 Default Gateway**.

IPv6

Three IPv6 modes are available.

Route Advertisement

The IPv6 address is generated by combining the route advertisement and the device Mac address.



Route advertisement mode requires the support from the router that the device is connected to.

DHCP

The IPv6 address is assigned by the server, router, or gateway.

Manual

Enter **IPv6 Address**, **IPv6 Prefix Length**, and **IPv6 Default Gateway**. Consult the network administrator for required information.

MTU

It stands for maximum transmission unit. It is the size of the largest protocol data unit that can be communicated in a single network layer transaction.

The valid value range of MTU is 1280 to 1500.

Multicast Address

Multicast is group communication where data transmission is addressed to a group of destination devices simultaneously. After setting the IP address of the multicast host, you can send the source data efficiently to multiple receivers.

Router

Enter **Route Address** and **Subnet Mask** if the device is connected to a router in multi-network isolation mode.

DNS

It stands for domain name server. It is required if you need to visit the device with domain name. And it is also required for some applications (e.g., sending email). Set **Preferred DNS Address** properly if needed.

4. Click **Save**.

3.2 Set Port

The device port can be modified when the device cannot access the network due to port conflicts.

Go to **Configuration → Network → Network Parameters → Port** for port settings.

☒ Enable HTTP Port	80
☐ Enable HTTPS Port	443
☒ Enable RTSP Port	554
☐ Enable SRTP Port	322
☐ Enable SDK Port	8000
☒ Enable WebSocket Port	7681
☐ Enable WebSocketS Port	7682
☒ Enable SADP Port	
☐ Enable SDK over TLS Port	8443

Save

Figure 3-3 Set Port

Enable HTTP Port

It refers to the port through which the browser accesses the device. For example, when the HTTP port is modified to 81, you need to enter ***http://192.168.1.64:81*** in the browser address bar for login.

Enable HTTPS Port

It refers to the port through which the browser accesses the device, but certificate verification is needed.

Enable RTSP Port

RTSP (Real-Time Streaming Protocol) is a communication protocol used to control servers that stream media content over the Internet. It helps in setting up and managing connections between devices for streaming audio or video. RTSP ensures that media players and servers can communicate smoothly, allowing users to play, pause, adjust volume, and perform other actions while streaming content.

Enable SRTP Port

SRTP (Secure Real-Time Transport Protocol) is an extension to RTP (Real-Time Transport Protocol) that incorporates enhanced security features.

Enable SDK Port

It refers to the port through which the client adds the device.

Enable WebSocket Port

It refers to the full-duplex communication protocol port based on TCP. Enable the port for live view without plug-in.

Enable WebSocketS Port

It refers to the full-duplex communication protocol port based on TCP. Enable the port for live view without plug-in. It can only be accessed via certificate verification with high security.

Enable SADP Port

It refers to the port through which the SADP software searches the device.

Enable SDK over TLS Port

It refers to the port that adopts TLS protocol over the SDK service, to provide safer data transmission.



Note


- After editing the port, access to the device via the new port.
 - Reboot the device to bring the new settings into effect.
 - The supported ports vary with different models. The actual device prevails.
-

3.3 Set IEEE 802.1X

IEEE 802.1X is a port-based network access control. It enhances the security level of the LAN/WLAN. When devices connect to the network with IEEE 802.1X standard, the authentication is needed.

Steps

1. Go to **Configuration → Network → Network Parameters → 802.1X**.
2. Enable 802.1X.



Protocol Type	EAP-MD5
EAPOL Version	1
User Name	admin
Password	*****
Confirm Password	*****

Save

Figure 3-4 Set IEEE 802.1X

3. Select **Protocol Type** and **EAPOL Version**.

Protocol Type

The authentication server must be configured. Register a user name and password for 802.1X in the server in advance. Enter the user name and password for authentication.

EAPOL Version

The EAPOL version must be identical with that of the router or the switch.

4. Enter **User Name** and **Password** registered in the server.

5. Confirm the password.
6. Click **Save**.

3.4 Set DDNS

You can use the Dynamic DNS (DDNS) for network access. The dynamic IP address of the device can be mapped to a domain name resolution server to realize the network access via domain name.

Before You Start

- Register the domain name on the DDNS server.
- Set the LAN IP address, subnet mask, gateway, and DNS server parameters. Refer to **Set IP Address** for details.
- Complete port mapping. The default ports are 80, 8000, and 554.

Steps

1. Go to **Configuration → Network → Network Parameters → DDNS**.
2. Enable DDNS.




Figure 3-5 Set DDNS

3. Enter the server address and other information.



Note

You can select **IPServer**, **DynDNS**, and **NO-IP** for the DDNS type.

4. Click **Save**.
5. Access the device.

- | | |
|---------------------------|--|
| By Browsers | Enter the domain name in the browser address bar to access the device. |
| By Client Software | Add domain name to the client software. Refer to the client software manual for specific adding methods. |

3.5 Set SNMP

You can set the SNMP network management protocol to get the alarm event and exception messages in network transmission.

Before You Start

Download the SNMP software and manage to receive the device information via SNMP port.

Steps

1. Go to **Configuration → Network → Network Parameters → SNMP**.

The screenshot displays the SNMP configuration page with three main sections:

- SNMP v1/v2c:** Contains two checkboxes, "Enable SNMPv1" and "Enable SNMPv2c", both of which are currently unchecked.
- SNMP v3:** This section is expanded and contains multiple configuration options:
 - "Enable SNMPv3" is checked with a blue checkmark.
 - "Read User Name" is an empty text input field.
 - "Security Level" has three radio button options: "Authentication and Not Encryption", "Not Authentication or Encryption" (which is selected), and "Authentication and Encryption".
 - "Authentication Algorithm" has two radio button options: "MD5" (selected) and "SHA".
 - "Authentication Password" is an empty text input field.
 - "Encryption Algorithm" has two radio button options: "DES" (selected) and "AES".
 - "Encryption Password" is an empty text input field.
 - "Write User Name" is an empty text input field.
 - A second set of "Security Level", "Authentication Algorithm", and "Encryption Algorithm" options is present below the first set, with the same selections.
- SNMP Other Settings:** Contains a single text input field for "SNMP Port" with the value "161" entered.

Figure 3-6 Set SNMP

2. Check **Enable SNMPv1/Enable SNMP v2c/Enable SNMPv3**.

Note

- The SNMP version you select should be the same as that of the SNMP software.
- Use different versions according to the security levels required. There exists information leakage using SNMP v1 or v2. You're recommended to use SNMP v3, which provides encryption and is safer. If you use v3, HTTPS protocol must be enabled.

3. Set the SNMP parameters.

Note

For SNMP v3, you need to set **Authentication Algorithm** and **Authentication Password**, and **Encryption Algorithm** and **Encryption Password**.

4. Click **Save**.

3.6 Set QoS

QoS (Quality of Service) can help improve the network delay and network congestion by setting the priority of data sending.

Note

QoS needs support from network devices such as routers and switches.

Steps

1. Go to **Configuration → Network → Network Parameters → QoS** .
 2. Enable DSCP according to the actual needs and set the value.
-

Note

Network can identify the priority of data transmission. The bigger the DSCP value is, the higher the priority is. Same settings need to be set in the router for configuration.

3. Click **Save**.

3.7 Set Multicast

Multicast is group communication where data transmission is addressed to a group of destination devices simultaneously.

Steps

1. Go to **Configuration → Network → Network Parameters → Multicast** .




Figure 3-7 Set Multicast

2. Set the parameters.

Stream Type

The stream type as the multicast source.

IP Address

It stands for the address of multicast host.

Port

The port of the selected stream.

TTL

TTL (Time to Live) is a crucial setting in networking and computing that determines how long data packets remain valid and available within a network before being discarded by a router. It is used in various contexts, including DNS, IP headers, and caching mechanisms.


3. Click **Save**.

3.8 Set RTMP

RTMP (Real-Time Messaging Protocol) is designed for transmitting audio and video over the Internet. It is used to stream multimedia content on demand and supports live streaming.

Steps

1. Go to **Configuration → Network → Network Parameters → RTMP**.



The screenshot shows a configuration form with two input fields. The first field is labeled 'RTMP Stream Channel' and contains the value '4096'. The second field is labeled 'RTMP URL' and contains the value 'rtmp://0.0.0.0:1935/live/livestream'. Below these fields is a blue button with a floppy disk icon and the text 'Save'.

Figure 3-8 Set RTMP

2. Set the parameters.

RTMP Stream Channel

The size of the RTMP stream channel. It is 4096 by default.

RTMP URL

The RTMP streaming URL. It is ***rtmp://192.168.1.64:1935/live/livestream*** by default.

3. Click **Save**.

3.9 Connect to Platform

3.9.1 Set Arming Host

The device can upload the captured pictures via the arming host.

Steps

1. Go to **Configuration → Network → Data Connection → Arm Upload**.

Protocol Type ☒ License Plate Alarm ☐ Mixed Target

VCA Alarm for Target Picture Matting ☒ Enable

Upload Binary Image ☒ Enable

Output Binary Image in BMP Format ☒ Enable

Cloud Storage **Enabled** ⓘ

Save

Figure 3-9 Set Arming Host

2. Select **Protocol Type**.



Note

Supported functions vary with different models. The actual device prevails.

License Plate Alarm

Uploads arming alarm images of the license plate. You can enable the functions below.

VCA Alarm for Target Picture Matting

If you have enabled motor vehicle/non-motor vehicle/pedestrian capture and target picture matting, you can enable the function to upload a scene picture, a license plate picture, and a target matting picture for the captured target.

Upload Binary Image

Enable the function to upload binary images full of black or white pixel points.

Output Binary Image in BMP Format

Enable the function to output images in BMP format. Disable the function to output images in JPEG format by default.

Mixed Target

Uploads images of multiple targets such as humans and vehicles. You can enable the body property to recognize clothes, bags, and other properties.

- 3. Optional:** If you want to save the alarm information and pictures to the cloud storage, go to **Configuration → Network → Data Connection → Cloud Storage** to set the parameters. Refer to [Set Cloud Storage](#) for details.

- 4. Click **Save**.**

3.9.2 Set SDK Listening

The SDK listening can be used to receive the uploaded information and pictures of the device arming alarm.

Before You Start

The listening service has been enabled for the SDK listening, and the network communication with the device is normal.

Steps

1. Go to **Configuration → Network → Data Connection → SDK Listening**.
2. Enable SDK listening.

Listening Host IP Address/Domain

Listening Host Port

Enable Picture Uploading Listening ☒ Enable

Protocol Type ☒ License Plate Alarm ☐ Mixed Target

Upload Binary Image ☒ Enable

Output Binary Image in BMP Format ☒ Enable

Cloud Storage Enabled ⓘ

Save

Figure 3-10 Set SDK Listening

3. Set **Listening Host IP Address/Domain** and **Listening Host Port** if you need to upload the alarm information and pictures.
4. **Optional:** The device will transmit images via the SDK listening if you enable picture uploading listening.
5. Select **Protocol Type**.



Note

Supported functions vary with different models. The actual device prevails.

License Plate Alarm

Uploads arming alarm images of the license plate. You can enable the functions below.

Upload Binary Image

Enable the function to upload binary images full of black or white pixel points.

Output Binary Image in BMP Format

Enable the function to output images in BMP format. Disable the function to output images in JPEG format by default.

Mixed Target

Uploads images of multiple targets such as humans and vehicles. You can enable the body property to recognize clothes, bags, and other properties.

6. **Optional:** If you want to save the alarm information and pictures to the cloud storage, go to **Configuration → Network → Data Connection → Cloud Storage** to set the parameters. Refer to **Set Cloud Storage** for details.
7. Click **Save**.

3.9.3 Set FTP

Set FTP parameters if you want to upload the captured pictures to the FTP server.

Before You Start

Set the FTP server, and ensure the device can communicate normally with the server.

Steps

1. Go to **Configuration → Network → Data Connection → FTP**.
2. Enable the FTP server.



Note

- You can only enable one FTP if the device does not support the violation capture. If more than one FTP is enabled, you should set **Upload Content** for each FTP according to your needs.
- Enable **FTP1** if you want to upload to only one FTP server.

3. Set FTP parameters.

Figure 3-11 Set FTP

- 1) Select **Sever IP Address** type and enter corresponding information.
- 2) Enter **Port**.
- 3) Enter **User Name** and **Password**, and confirm the password.
- 4) Select **Upload Protocol Type**.

SFTP

SFTP (SSH File Transfer Protocol) is a network protocol that provides file transfer and manipulation functionality over any reliable data stream. SFTP service is typically used with

the SSH-2 protocol (TCP port 22) to provide secure file transfer, but is intended to be usable with other protocols as well.

FTPS

FTPS (File Transfer Protocol Secure) is used to provide a number of ways that FTP software can perform secure file transfers. Each way involves the use of a SSL/TLS layer below the standard FTP protocol to encrypt the control and/or data channels. It requires a certificate, and needs the additional configuration of a supported FTP server.

5) Select **Directory Structure**.



Note

You can customize the directory structure according to your needs.

6) Select **Path/Picture Name Encoding Mode**.

UTF-8

UNICODE encoding.

7) Select **Connection Mode**.

Transitory Connection

The connection is temporarily made for one data transmission task. After this task, the connection will be broken.

Persistent Connection

The connection is made for long-term data transmission, which will be broken only when the device is disconnected from the FTP server.

4. **Optional**: Enable upload functions.



Note

Supported functions vary with different models. The actual device prevails.

Not Upload Plate Close-up

The close-up pictures of a license plate will not be uploaded.

Upload Face Picture

Upload face close-up pictures to the FTP server.

Upload Target Picture

Upload the pictures of the target detection area to the FTP server.

Upload Additional Information to FTP

Add related information when uploading data to the FTP server.

Upload CSV Vehicle Passing Statistics Information to FTP

Upload the CSV vehicle passing statistics information to the FTP server.

5. **Optional**: Click **FTP Test** to check the FTP server.

6. Click the text filed of **Name Rule** to set the directory and separator for the file storage.



Note

For the European version, select **Custom** and enter **adr** or **ADR** in the text field, and the ADR (Authorisation Dangerous Road) vehicle plate number will be added in the corresponding vehicle picture name.

7. **Optional:** Edit **OSD Information** which can be uploaded to the FTP server with the pictures to make it convenient to view and distinguish the data.
8. Click **Save**.

3.9.4 Set ISAPI Listening

ISAPI listening and SDK listening are mutually exclusive protocols. If you enable the picture uploading listening, the device will transmit images via the SDK listening. If not, the device will upload images via ISAPI protocol after the ISAPI parameters are set.

Before You Start

The listening service has been enabled for the ISAPI host, and the network communication with the device is normal.

Steps

1. Go to **Configuration → Network → Data Connection → ISAPI Listening**.
2. Enable **ISAPI1** or **ISAPI2**.



Note

For some application modes, only one ISAPI is supported. The actual interface prevails.

Version ☒ HTTP ☐ HTTPS

Host IP Address/Domain Name

Host Port

Host URL

Heartbeat Interval (s) ⓘ

Uploaded Picture Type Control ☒ All ☐ License Plate Picture ☐ Detection Picture ☐ Not Upload Picture

Authentication Mode ☒ None ☐ Base64 ☐ Digest

Upload Binary Image ☒ Enable

Output Binary Image in BMP Format ☒ Enable

Upload Violation Pre-Record ☐

Platform Response Verification ☒

Cloud Storage Enabled ⓘ

Save

Figure 3-12 Set ISAPI Listening

3. Select **Version**.

4. Set **Host IP Address/Domain Name**, **Host Port**, and **Host URL**.

5. Set the parameters.

Heartbeat Interval

If you set it as 0, the heartbeat is disabled.

Uploaded Picture Type Control

You can upload license plate pictures and detection pictures (the capture scene pictures), or do not upload pictures.

Authentication Mode

Only the authorized users can access the device. If you select **None**, the device will not verify the authentication condition of the access users. It is recommended to select an authentication mode to guarantee the device information security.

Upload Binary Image

Enable the function to upload images which are full of black or white pixel points.

Output Binary Image in BMP Format

Enable the function to output images in BMP format. Disable the function to output images in JPEG format by default.

Upload Violation Pre-Record

Enable the function to upload the pre-recorded videos of violations to the host.

Platform Response Verification

Enable the function, and the device will get the platform response result.

Incident Mode

For the application modes of incident detection and data collection, select the data to be uploaded. If you select **All**, all the data will be uploaded. If you select **Specified**, select corresponding **Alarm Event** to be uploaded.

6. Optional: If you want to save the alarm information and pictures to the cloud storage, go to **Configuration → Network → Data Connection → Cloud Storage** to set the parameters. Refer to **Set Cloud Storage** for details.

7. Click **Save**.

3.9.5 Connect to ISUP Platform

ISUP is a platform access protocol. The device can be remotely accessed via this platform.

Before You Start

- Create the device ID on ISUP platform.
- Ensure the device can communicate with the platform normally.

Steps

- 1.** Go to **Configuration → Network → Data Connection → ISUP**.
- 2.** Enable ISUP Platform Index1 or 2.

^ ISUP Platform Index1
☒

Protocol Version
v5.0

Address Type
IP Adc

Server Port

Device ID

Encryption Key
.....

8 to 32 letters or digits, case sensitive. You are recommended to use a combination of letters or digits.

Registration Status
Offline

Platform Status

Server Type	Server IP Address	Server Port	Upload Type
Alarm Ser...	0.0.0.0	1	Upload D
Picture Se...	0.0.0.0	1	Upload D

Unable to send picture to ISUP platform at the first access. Please restart the system and try again.

Upload Binary Image
☐ Enable

^ ISUP Platform Index2
☐

Figure 3-13 Connect to ISUP Platform

3. Select **Protocol Version**.
4. Select **Address Type** and enter IP address or domain name of the platform.
5. Enter **Server Port**, **Device ID**, and **Encryption Key**.



Note

The device ID should be the same with the added one on the platform.

6. **Optional:** You can enable **Upload Binary Image** if you need to upload images which are full of black or white pixel points.



Note

- The function varies with different models. The actual device prevails.
- Enable **Output Binary Image in BMP Format** if you want to output images in BMP format.

7. Click **Save**.

What to do next

When the registration status is online, you can manage the device via the platform or server.

3.9.6 Connect to OTAP

The device can be accessed to the platform via OTAP protocol to realize live view, view incident information, manage the devices, etc. via the platform.

Before You Start

- Set the network parameters including device IP address, gateway, DNS, etc. to get access to the network.
- Disable the other platform accesses conflicting with OTAP.

Steps

1. Go to **Configuration → Network → Data Connection → OTAP**.
2. Select **Platform Access Mode** as **Private Deployment**.
3. Enable **OTAP Server**.

Figure 3-14 Connect to OTAP

4. Set corresponding parameters.

Address Type

Select the address type of the connected platform or server, and enter the IP address or domain name.

Server Port

The port of the connected platform or server.

Device ID

The device ID should be the same with the added one on the OTAP platform.

Key

Set a custom key to encrypt the data connection between the device and the platform or server.

5. Click **Save**.

What to do next

When the registration status is online, you can manage the device via the platform or server.

3.9.7 Connect to Hik-Connect

The device can be remotely accessed via Hik-Connect.

Before You Start

- Set the network parameters including device IP address, gateway, DNS, etc. to get access to the network.
- OTAP connection is disabled.

Steps



Note

This function varies with different models. The actual device prevails.

1. Go to **Configuration → Network → Data Connection → OTAP**.
2. Select **Platform Access Mode** as **Hik-Connect**.
3. Enable the function.

Platform Access Mode ☐ Private Deployment ☒ Hik-Connect

Enable ☒

Server Domain Name ☐ Custom

Registration Status Offline

Offline Reason Unknown

Offline Code 0

Binding Status Unknown

Verification Code

Enable Video Encryption ☒

Video Encryption Password

8 to 16 letters or digits, case sensitive. You are recommended to use a combination of letters or digits.

Confirm Video Encryption Password

Figure 3-15 Connect to Hik-Connect

- Optional:** If you have allocated a custom server, check **Custom** and enter the custom **Server Domain Name**.
- Enter a custom **Verification Code** used to add the device via **Hik-Connect**.



Caution

The verification code should be 6 letters or digits, case sensitive. You are recommended to use a combination of letters or digits.

- Optional:** Check **Enable Video Encryption** and set **Video Encryption Password** to encrypt the videos transmission. Confirm the password.
- Click **Save**.
- Add the device to Hik-Connect.
 - 1) Get and install Hik-Connect application by the following ways.

- Visit <https://appstore.hikvision.com> to download the application according to your mobile phone system.
- Visit the official site of our company. Then go to **Support → Tools → Installation & Maintenance Tools → Hikvision APP Store**.
- Scan the QR code below to download the application.



Figure 3-16 Hik-Connect



Note

If errors like "Unknown app" occur during the installation, solve the problem in two ways.

- Visit <https://appstore.hikvision.com/static/help/index.html> to refer to the troubleshooting.
- Visit <https://appstore.hikvision.com/>, and click **Installation Help** at the upper right corner of the interface to refer to the troubleshooting.

2) Start the application and register a user account to log in.

3) Add device by the serial No. on the device body and the verification code.



Note

Refer to the user manual of Hik-Connect application for details.

3.9.8 Set Integration Protocol

You can connect the device via ONVIF protocol.

Steps

1. Go to **Configuration → Network → Data Connection → Integration Protocol**.
2. Enable **ONVIF**.
3. Select **Authentication Mode**, and click **Save**.
4. Add a user.
 - 1) Click **Add**.
 - 2) Set user name, password, and user type, and confirm the password.
 - 3) Click **OK**.
 - 4) **Optional:** You can select the added user and click  to edit the user information, or click  to delete the user.

Result

Only the added users can access the device via ONVIF protocol.

3.9.9 Set Cloud Storage

Cloud storage is a kind of network storage. It can be used as the extended storage to save the captured pictures.

Before You Start

- Arrange the cloud storage server.
- You have enabled listening or arming.

Steps

1. Go to **Configuration → Network → Data Connection → Cloud Storage**.
2. Enable **Cloud Storage**.

The screenshot displays a configuration window for cloud storage. It contains the following fields and controls:

- Version:** A dropdown menu currently set to "V2.0".
- Server IP Address:** A text input field.
- Port:** A text input field.
- Access Key:** A text input field masked with six dots.
- Secret Key:** A text input field masked with six dots.
- Resource Pool ID:** A text input field.
- Save:** A blue button with a floppy disk icon and the text "Save".

Figure 3-17 Set Cloud Storage

3. Select **Version**.

- V1.0**
- a. Enter **Server IP Address** and **Port**
 - b. Enter **User Name** and **Password**.
 - c. Enter **Cloud Storage ID** and **Violation Cloud Storage ID** according to the server storage area No.
- V2.0**
- a. Enter **Server IP Address** and **Port**
 - b. Enter **Access Key** and **Secret Key**.
 - c. Enter **Resource Pool ID** according to the server storage area No. of uploading pictures.

4. Click **Save**.

Chapter 4 Application Mode Configuration



Note

- The supported application modes vary with different models. The actual device prevails.
- When you draw lane lines or detection areas on **Application Mode** interface, you can refer to the drawing guide displayed below the live view window. You can click **Guide Disable** to hide the guide, or click **Drawing Guide** to display the guide.



Caution

You can click **Default** on **Application Mode** interface to restore all the set parameters to the default settings. Please operate with care.

4.1 Set Incident Detection

The device supports to capture various traffic incidents.

Steps

1. Go to **Configuration → Capture → Application Mode**.
2. Select **Trigger Mode** as **Incident Detection**.
3. Click **Incident Detection**.
4. Set the parameters according to the instructions below, and click **Save**.

4.1.1 Set Linked Lane Parameters

You can set the properties and parameters of the linked lanes.

Steps



Note

The linked lane parameters vary with different models. The actual device prevails.

1. Click **Lane Configuration**.
2. Select **Total Lanes**.
3. Select a lane No. to set the lane parameters.

Lane Configuration

Total Lanes3

Lane No.1

Lane No.2

Lane No.3

Right Borderline

Lane Line TypeWhite Solid Line

Linked Lane No.1

DirectionFrom Top to Bottom

Lane DirectionUnknown

Lane PropertyUnknown

Linkage Output☐ F1

Supplement Light Flashing ...☒ Simultaneous ☐ Sequential

Copy to☒ Lane No.1 ☐ Lane No.2 ☐ Lane No.3

Figure 4-1 Lane Configuration of Incident Detection

Lane Line Type

Select the lane line type according to the actual scene.

Linked Lane No.

The device will number the lane in ascending order from left to right automatically. The lane No. will be marked in the capture pictures and alarm information.

Direction

If you select **From Top to Bottom**, the targets from the approaching direction towards the device will be captured. If you select **From Bottom to Top**, the targets from the leaving direction away from the device will be captured.

Lane Direction

The guidance direction of the lane.

Lane Property

Select the current lane property according to its usage.

Linkage Output

Check the capture linked supplement light channel(s).

Supplement Light Flashing Mode

Select **Simultaneous**, and the supplement lights will flash simultaneously. Select **Sequential**, and the supplement lights will flash one by one.

4. **Optional**: Check the other lane(s) to copy the same settings.

5. Click **Save**.

4.1.2 Set Violation Incident

The device can capture pictures of the targets passing the checkpoint in the linked lanes according to the set rules.

The screenshot displays the configuration interface for the incident detection system, divided into two main sections: 'Capture Mode' and 'Violation Incident'.

Capture Mode:

- Scene Mode:** A dropdown menu currently set to 'Unknown'.
- Radar Track:** A checkbox that is checked.
- Close Range Capture:** A checkbox that is checked.

Violation Incident:

This section contains a list of incident types on the left and configuration options on the right.

Incident Types (Left Panel):

- + Add Incident** (button)
- ☒ Select All
- ☒ Congestion
- ☒ Construction
- ☒ Roadblock
- ☒ Pedestrian Detect...
- ☒ Fallen Object
- ☒ Accident
- ☒ Checkpoint
- ☒ Stopped Vehicle

Configuration Options (Right Panel):

- Number of Captures:** A dropdown menu set to '1'.
- Sensitivity:** A slider bar ranging from 0 to 100, currently set at 50.
- Alarm Interval (min):** A slider bar ranging from 0 to 10, currently set at 2.
- Duration (s):** A slider bar ranging from 0 to 300, currently set at 234.
- Vehicle Number Threshold:** A slider bar ranging from 0 to 10, currently set at 5.
- Repeat Alarm Before Cancel...:** An unchecked checkbox.
- Linked Area:** An unchecked checkbox labeled 'Select All'.
- Area Selection:** Three checkboxes labeled 'Area1', 'Area2', and 'Area3', all of which are checked. An 'Expand' button with a downward arrow is located to the right of these checkboxes.
- Associated marked area:** An unchecked checkbox labeled 'Select All'.

Figure 4-2 Set Violation Incident

Capture Mode

Go to **Violation Incident** → **Capture Mode** . Set the parameters, and click **Save**.

Scene Mode

Select the scene according to the actual device installation environment.

Radar Track

When the radar is connected, enable it to generate and overlay the radar tracks.



Note

The function is only available for the device supporting radar.

Close Range Capture

The device will track the target until one more picture is captured in close distance.

Violation Incident

Go to **Violation Incident** → **Violation Incident** . Click **Add Incident** to select the incident types to detect, and click **OK**. Check the incident types to enable the functions and click each type to set the corresponding parameters.



Note

The supported incident types vary with different models. The actual device prevails.

Table 4-1 Incident Type Description

Incident Type	Parameters Description
Congestion	The motor vehicles are queuing and the roads are blocked. Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the congestion will be captured. • Alarm Interval: The interval between two alarms. • Duration: When the congestion on the lane lasts for more than the set duration, capture will be triggered. • Vehicle Number Threshold: When the number of queuing vehicles exceeds the threshold, the condition is judged as congestion. • Repeat Alarm Before Canceling Congestion: If you enable the function, alarms will be repeated before the congestion status is removed.

Incident Type	Parameters Description
	• Linked Area: Check the area(s) within which the detection will take effect. Set Duration for each linked area. When the congestion in the area lasts for more than the set duration, capture will be triggered. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Construction	Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the construction will be captured. • Alarm Interval: The interval between two alarms. • Duration: When the construction lasts for the set duration, capture will be triggered. • Alarm Once Before Canceling: If you enable the function, alarm will be reported only once before the construction status is removed. Or alarms will be repeated. • Filter Other Events: Check it to detect the construction only to avoid the interferences from other incident detections. • Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Roadblock	Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the roadblock will be captured. • Alarm Interval: The interval between two alarms. • Duration: When the roadblock lasts for the set duration, capture will be triggered. • Alarm Once Before Canceling: If you enable the function, alarm will be reported only once before the roadblock status is removed. Or alarms will be repeated.
Pedestrian Detection	Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the pedestrian will be captured. • Duration: When the pedestrian stops for the set duration, capture will be triggered. • Pedestrian Type: Select the pedestrian type(s) to be detected according to the actual needs.

Incident Type	Parameters Description
	• Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Fallen Object	Objects are thrown from the window of the motor vehicle. Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Duration: When the incident lasts for the set duration, capture will be triggered. • Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Accident	To detect the incident of single vehicle breakdown or traffic accident between multiple vehicles. Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Alarm Interval: The interval between two alarms. • Duration: When the incident lasts for the set duration, capture will be triggered. • Accident: Select the accident type. • Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Checkpoint	Check it and select the number of captured picture(s). Select Capture Type. • Capture Mode: The function is only available for the device supporting supplement light. Select the supplement light type. • Capture Type: Select the target type(s) to be detected.
Stopped Vehicle	The motor vehicle stops at the positions where parking is forbidden. Check it, select the number of captured picture(s), and set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Alarm Interval: The interval between two alarms.

Incident Type	Parameters Description
	• Duration: When the vehicle stops at the positions for more than the set duration, capture will be triggered. • Repeat Alarm: If you enable the function, alarms will be repeated before the stopped vehicle status is removed. • Linked Area: Check the area(s) within which the detection will take effect. Set Duration for each linked area. When the congestion in the area lasts for more than the set duration, capture will be triggered. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.  Note When the device judges that the current lane is in congestion status, the stopped vehicles will not be captured.
Driving on the Lane Line	The motor vehicle is driven out of the lane and over the lane lines that cannot be crossed. Check it, select the number of captured picture(s), and set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Checkout Mode: If you select By Lane, the captured pictures will link with the lane No. If you select By Area, the captured pictures will link with the set Linked Area No.
Lane Change	Most part of the vehicle body crosses over the lane line and enters into another lane. Check it, select the number of captured picture(s), and set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Checkout Mode: If you select By Lane, the captured pictures will link with the lane No. If you select By Area, the captured pictures will link with the set Linked Area No.
Wrong-Way Driving	The vehicle is driven in the direction opposite to the guidance direction of the lane. Check it, select the number of captured picture(s), and set the sensitivity.
Speeding	The motor or non-motor vehicle is driven in the speed larger than the max. speed limit of the lane. Check it and select the number of captured picture(s). Set the parameters.

Incident Type	Parameters Description
	• Interval: The interval between two captures. • Speed Limit for Small/Large-Sized Vehicle: The max. speeds for the small-sized and large-sized vehicles respectively. When the vehicle speed exceeds the value, speeding capture will be triggered. • Enable Speed Limit for Non-Motor Vehicle: Check it to enable the speeding capture for the non-motor vehicles. Set Speed Limit for Non-Motor Vehicle. • Checkout Mode: If you select By Triggering Line, when the vehicle passes over the triggering line and the passing ratio is larger than the set Capture Position Ratio, speeding capture will be triggered. If you select By Duration, when the speeding incident lasts for more than the set Duration, speeding capture will be triggered.  Note The Checkout Mode function varies with different models. The actual device prevails.
Low-Speed	The motor vehicle is driven in the speed lower than the min. speed limit. Check it, select the number of captured picture(s), and set the parameters. • Speed Limit for Small/Large-Sized Vehicle: When the vehicle speed is lower than the value, low-speed capture will be triggered. • Actual Distance Between Measuring Lines: Set the distance between the measuring lines according to the actual scene. When the speed detection within the distance is lower than the min. speed limit, low-speed capture will be triggered.  Note The Actual Distance Between Measuring Lines function varies with different models. The actual device prevails.
Not Slowing Down at Crosswalk	The vehicle does not slow down when approaching near the crosswalk. Check it, select the number of captured picture(s), and set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Highest/Lowest Speed Limit: When the vehicle speed approaching near the crosswalk is larger than the highest speed limit, capture will be triggered. When the vehicle speed approaching near the crosswalk is lower than the lowest speed limit, capture will not be triggered.

Incident Type	Parameters Description
Continuous Lane Change	Check it, select the number of captured picture(s), and set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Driving Distance: If a vehicle has changed a lane but is driven a distance shorter than the set Driving Distance on the lane, and then changes another lane to the direction same with the first lane change, it is judged as continuous lane change and the capture will be triggered.
Emergency Lane Occupation	To detect the violation of occupying emergency lane. Check it and select the number of captured picture(s). Set the parameters. • Duration: When the incident lasts for the set duration, capture will be triggered. • Checkout Mode: If you select By Triggering Line, when the vehicle passes over the triggering line and the passing ratio is larger than the set Capture Position Ratio, speeding capture will be triggered. If you select By Duration, when the speeding incident lasts for more than the set Duration, speeding capture will be triggered.
Smoke	Check it and select the number of captured picture(s). Set the corresponding parameters to detect the smoke on the lane. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Alarm Interval: The interval between two alarms. • Duration: When the incident lasts for the set duration, capture will be triggered. • Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Fire	Check it and select the number of captured picture(s). Set the corresponding parameters to detect the fire on the lane. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Alarm Interval: The interval between two alarms. • Duration: When the incident lasts for the set duration, capture will be triggered.

Incident Type	Parameters Description
	• Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.
Rapid Deceleration	The motor vehicle slows down suddenly in a short period. Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Actual Distance Between Measuring Lines: Set the distance between the measuring lines according to the actual scene. When the speed within the distance slows down suddenly in a short period, rapid deceleration capture will be triggered.
Occupied by Animal	To detect if the lanes are occupied by animals. Check it and select the number of captured picture(s). Set the parameters. • Sensitivity: The higher the sensitivity is, the more easily the incident will be captured. • Linked Area: Check the area(s) within which the detection will take effect. • Associated Masked Area: Check corresponding areas and incidents occurred in those areas will not be detected.

4.1.3 Set Linked Area

For some incident types, you need to set the linked area types. The detection only takes effect in the linked areas.

Steps



Note

The function varies with different models. The actual device prevails.

1. Click **Linked Area**.

Linked Area	Area Type
Linked Area1	Highway Emergency Lane Area ▾
Linked Area2	Normal Lane Area ▾
Linked Area3	Non-Motor Vehicle Lane Area ▾

Figure 4-3 Set Linked Area

2. Select **Area Type** of the corresponding linked areas.
3. Click **Save**.

4.1.4 Draw Lane Lines and Incident Areas

Draw lane lines and incident areas to detect and capture the violations or incidents in the linked areas.

Before You Start

Set lane and violation incident parameters.

Steps

1. Refer to the drawing guide below the live view image on the interface.
2. Select the default lane lines, right border line, and trigger line, and drag the two end points of the line or drag the whole line to adjust its position according to the actual scene.
3. **Optional:** You can select a lane line, and click  on the right of **Lane Line** to delete the lane. Or click  on the right of **Lane Line** to add a new lane line if the icon is available.



Note

The lane right borderline and trigger line cannot be deleted.

4. Click  on the right of **Incident Area**, and click the left button of the mouse to draw a rectangular or polygonal frame, and then click the right button of the mouse to save the area.
5. **Optional:** You can select an area, and click  on the right of **Incident Area** to delete the area. Or click  on the right of **Incident Area** to add a new area.




Figure 4-4 Draw Lane Lines and Incident Areas

6. Click **Save**.

4.2 Set Data Collection

The device supports to detect the traffic flow, POS, and other information.

Steps

1. Go to **Configuration → Capture → Application Mode**.
2. Select **Trigger Mode** as **Incident Detection**.
3. Click **Data Collection**.
4. Set the parameters according to the instructions below, and click **Save**.

4.2.1 Set Linked Lane Parameters

You can set the properties and parameters of the linked lanes.

Steps



The linked lane parameters vary with different models. The actual device prevails.

1. Click **Lane Configuration**.
2. Select **Total Lanes**.
3. Select a lane No. to set the lane parameters.

Lane Configuration

Total Lanes 3

Lane No.1

Lane No.2

Lane No.3

Enable POS of Lane ☒

Linked Lane No. 1

Direction Forward

Lane Direction From East to West

Copy to ☒ Lane No.1 ☐ Lane No.2 ☐ Lane No.3

Figure 4-5 Set Lane Parameters

Enable POS of Lane

Check it to enable the POS information (feature information) collection of the lane.

Linked Lane No.

The device will number the lane in ascending order from left to right automatically. The lane No. will be marked in the capture pictures and alarm information.

Direction

If you select **Forward**, the targets from the approaching direction towards the device will be captured. If you select **Backward**, the targets from the leaving direction away from the device will be captured.

Lane Direction

The guidance direction of the lane.

4. **Optional:** Check the other lane(s) to copy the same settings.

5. Click **Save**.

4.2.2 Set Traffic Flow Detection

Steps

1. Click **Traffic Flow Detection**.

Upload Data

Upload Real-Time Data	☒	Enable	
Upload Statistic Data	☒	Enable	Interval 1 min
Protocol Type	Unicoil		
Distance to Stop Line ⓘ	0		m
Calibration Distance	20		m

Figure 4-6 Set Traffic Flow Detection

2. Set the data upload parameters.



Note

The supported functions vary with different models. The actual device prevails.

Upload Real-Time Data

The device will upload the real-time data to the server. The real-time data include road status, time, lane No., instantaneous speed, space headway, time headway, congestion traffic flow, driving direction, queue length, congestion level, and intersection dedicated data such as the signals when leaving the left turn line, right turn line, going straight line, and stop line at intersections (only supported for multi-coils protocol).

Upload Statistic Data

The device will upload the statistic data to the server according to the set **Interval**. The statistic data include lane No., traffic, average speed, traffic state, lane queue length, time interval of vehicle head, headway distance, lane space occupancy, lane time occupancy, average delay, and average number of stops.

Protocol Type

Unicoil

One coil for each lane.

Double Coil

Two coils for each lane.

Multi-Coils

Multi-coils for each lane. Select **Number of Coils**.

Distance to Stop Line

It is the distance from the device blind spot to the stop line at the intersection.

Enable Intersection

If you select **Protocol Type** as **Multi-Coils**, you can enable intersection and the scene will be an intersection with a stop line, a left turn border line, and a right turn border line.

Traffic Jam over Stop Line in Intersection

In multi-coils protocol, if you enable intersection, you can enable the function to detect the traffic jam at intersection, and set **Threshold**. When the vehicle queue over the stop line has lasted for the set threshold, it is regarded as traffic jam over stop line at intersection.

Calibration Distance

If you select double coils, set the distance between the coils.

3. Draw lane lines and virtual coil areas.

- 1) Refer to the drawing guide below the live view image on the interface. The left drawing guide is applicable to the scene with an intersection in multi-coils protocol. The right drawing guide is applicable to the scene without an intersection.
- 2) Select the default lines and coils, and adjust their positions and shapes according to the actual scene.
- 3) **Optional:** You can select a lane line, and click  on the right of **Lane Line** to delete the lane. Or click  on the right of **Lane Line** to add a new lane line if the icon is available.



Note

The lane right borderline and trigger line cannot be deleted.

- 4) **Optional:** If you want to redraw the coil areas, you can select the default coil on the live view image, and click  on the right of **Coil** to delete it. Then click  on the right of **Coil**. Select the corresponding coil, and click the left button of the mouse to draw a rectangular or polygonal frame, and then click the right button of the mouse to save the coil area. You can enable **Aided Line Drawing with Virtual Coil** to generate the coils automatically.

Note

- It is recommended that the virtual coil height is half of the small-sized vehicle length and the width is the lane width.
- The virtual coils should be set at the positions where the radar and video can both detect.

5) **Optional:** You can click , and drag the mouse on the live view image to zoom the area in. Click the icon again to exit from digital zoom.

Note

The digital zoom function is only available after you download the plug-in.




Figure 4-7 Draw Lane Lines and Virtual Coils Areas

4. Click **Save**.

4.2.3 Set Traffic Flow Information Overlay

Steps

1. Click **Overlay Traffic Flow Info.**

Enable POS Information ☒ Enable

Font Size

X Position

Y Position

Real-Time Data ☒ Select All

☒ Lane No. ⓘ	☒ Lane Traffic F... ⓘ
☒ Traffic Flow o...	☒ Traffic Flow o...
☒ Traffic Flow o...	☒ Average Spe... ⓘ
☒ Passing Status ⓘ	☒ Lane Queue ... ⓘ
☒ Headway Time ⓘ	☒ Headway Dis... ⓘ
☒ Large-Sized ... ⓘ	☒ Small-Sized ... ⓘ
☒ Non-Motor ... ⓘ	

Statistics Data ☒ Average Lan... ⓘ ☒ Average Lan... ⓘ

☒ Average Delay ⓘ ☒ Average Nu... ⓘ

Scheduled Clearing ☒ Enable

Daily Clearing Time

Figure 4-8 Set Traffic Flow Information Overlay

2. Set the information overlay.

Enable POS Information

Check it to overlay the feature information on the video stream and display on the live view image.

Font Size

Select the font size for the overlaid information.

X/Y Position

Enter **X Position** and **Y Position** to display on the image.

Real-Time Data

Select the real-time data to overlay on the image.

Statistics Data

Select the statistics data to overlay on the image.

3. Optional: Clear the traffic flow data if needed.

- Click **Quick Clear** to clear all the traffic flow data quickly.
- If you want to clear the traffic flow data at the fixed time daily, enable **Scheduled Clearing** and set **Daily Clearing Time**.

4. Click **Save**.

Chapter 5 Capture Parameters Configuration

5.1 Set License Plate Recognition Parameters

When there are vehicles of different types passing from different directions, set the license plate recognition parameters.

Steps



Note

The supported parameters vary with different models. The actual device prevails.

1. Go to **Configuration → Capture → Capture Parameters → LPR Parameters**.

Country/Region Middle East

License Plate Recognition ☐ Forward ☐ Backward ☒ Bidirection

License Plate Supplementary Recognition ☒

Save

Figure 5-1 Set License Plate Recognition Parameters

2. Set **Country/Region** according to the actual needs.
3. Select **License Plate Recognition**.
 - Select **Forward** when license plates of vehicles from the approaching direction need to be recognized.
 - Select **Backward** when license plates of vehicles from the leaving direction need to be recognized.
 - Select **Bidirection** when license plates of vehicles from both the approaching direction and the leaving direction need to be recognized.
4. **Optional:** Enable **License Plate Supplementary Recognition** to re-recognize the targets whose license plates are not recognized for the first time.
5. Click **Save**.

5.2 Set Supplement Light Parameters

Supplement light can enhance the image stabilization and adjust the brightness and color temperature.

Steps



Note

- This chapter is only applicable to the device supporting supplement light.
- The supported parameters vary with different models. The actual device prevails.

1. Go to **Configuration → Capture → Capture Parameters → Supplement Light Parameters** .

	F1	F2	F3	F4	F5
	F6	F7			

Output Mode Flash Light Mode

Usage Description

Output in Advance (μs)

Output Dwell Time (μs)

Effective Status High

Default Status Low

Light Compensation Mode ☒ Checkpoint

Enable Mode ☒ Default

☐ Time Schedule

☐ Environment Brightness

Copy to ☐ F2 ☐ F3 ☐ F4 ☐ F5

☐ F6 ☐ F7

Figure 5-2 Set Supplement Light Parameters

2. Select the I/O and set the supplement light parameters.

Output Mode

Flash Light Mode

The flash light will be triggered by the signals and output high intensity illumination instantaneously. The light can pass through the windshield and help to capture the details.

Housing Fan Mode

You can select this mode to enable the housing fan of the device.

Usage Description

Enter the usage description of the supplement light or housing fan.

Output in Advance

It is the preact time [0 to 1000 μ s] of the flash light, to ensure that the flash light is on when capture is triggered.

Output Dwell Time

It is the dwell time [0 to 10000 μ s] after the flash light responds. The actual flash light supplement time is the result of the dwell time minus advanced time.

Effective Status

Select the effective status of the supplement light according to the actual condition.

High/Low

When high/low level signal is output to the supplement light, the light will flash.

The effective status should stay different with the default status for I/O to take effect. And the default status changes according to the selection of the effective status. If you set the effective status as high level, the default level goes to low level.

Pulse

When pulse signal is output to the supplement light, the light will flash.

If you set the effective status as pulse, you can select **Default Status** as high level or low level, and set other parameters.

Frequency Coefficient

It is the frequency multiplication of 25 of output pulse by flash light, to keep the flash light as constant. You can set it as default value.

Duty Ratio

It is the time occupation of the high level in a certain period. The higher the duty ratio, the brighter the light. High duty ratio will cut life span of the light.

Light Compensation Mode

Select **Checkpoint** to enable checkpoint capture light supplement.

3. Set the supplement light control mode.

- Select **Default** to disable the supplement light.
- Select **Time Schedule** when you want the supplement light to be enabled during a fixed time period. Set the start time and end time.
- Select **Environment Brightness** when you want the supplement light to be controlled by detecting the surroundings brightness automatically. Set the brightness threshold. The higher the threshold is, the harder the supplement light can be enabled.
- Select **License Plate Brightness** to enable the supplement light automatically when the light is insufficient for license plate capture.

4. Optional: Select other I/O(s) to copy the same settings.

5. Click **Save**.

5.3 Set Feature Recognition

Set the feature parameters for different targets if you need to detect the features of the corresponding targets.

Steps



The parameters vary with different models. The actual device prevails.

1. Go to **Configuration → Capture → Capture Parameters → Feature Recognition Settings**.
2. Check the feature(s) that needed to be detected, and set the corresponding sensitivity if supported.
3. Click **Save**.

5.4 Set Target Picture Matting

Set target picture matting first if you need to upload target pictures to the platform.


Steps



The function varies with different models. The actual device prevails.

1. Go to **Configuration → Capture → Capture Parameters → Target Picture Matting**.
2. Check **Enable Target Picture Matting**.

Target Picture Matting



Enable Target Picture Matting ☒

Target Cutting Ratio ☒ Small ☐ Medium ☐ Large

Target Zooming Ratio Small ▼

 Save

Figure 5-3 Set Target Picture Matting

3. Select **Target Cutting Ratio** to be small, medium, or large.
4. Set **Target Zooming Ratio**.
5. Click **Save**.

Result

If the device is level 1 armed, the matting pictures will be uploaded to this device directly.

5.5 Set Information Overlay

5.5.1 Set Single Picture Overlay

If you want to overlay information on the captured single pictures, set capture overlay.

Steps



Note

The supported parameters vary with different models. The actual device prevails.

1. Go to **Configuration** → **Capture** → **Capture Parameters** → **Capture Overlay Configuration** .
2. Click the single type.
3. Enable text overlay.
4. Set **Overlay Style**.

Overlay Style

Percentage 100

Transparency 0

Date Format YYYY-MM-DD

Time Format ☐ 12-hour ☒ 24-hour

Font Size 16 x 32

Foreground Color ffffff

Background Color 000000

Overlay Position ☐ Overlay on the Picture
☐ Overlay Above the Picture
☒ Overlay Below the Picture

More ☒ Overlay Number Zeroizing
☐ Overlay OSD on Close-up Picture
☐ Overlay Plate Close-up

Figure 5-4 Set Single Picture Overlay Style

Percentage

It is the percentage that the overlaid information occupies on the picture. For example, if you set the percentage to 50, the overlaid information in a row will occupy up to half of the image width, and the excess content will be overlaid from a new line.

Transparency

It is the condition of viewing the live view image through the overlaid information.

Overlay Number Zeroizing

When the overlaid number digits are smaller than the fixed digits, 0 will be overlaid before the overlaid number. E.g., the fixed digits for lane No. is 2. If the lane No. is 1, 01 will be overlaid on the picture.

Overlay OSD on Close-up Picture

Check it to overlay the OSD information on the close-up pictures.

Overlay Plate Close-up

Check it to overlay license plate close-up pictures on the captured pictures. Set **Plate Picture Close-Up Zooming Ratio** to adjust the close-up picture size.

Sync. Video Overlay

Enable the function to overlay OSD information on the captured pictures. If you select to overlay on the picture, make sure that the video OSD and picture overlay information does not overlap.

Font Color Inversion

Enable the function to detect the gray level of the image overlaid position automatically. When the image color is dark, the overlaid characters will be displayed as white automatically. When the image color is light, the overlaid characters will be displayed as black automatically.

Capture Time Type

Select the time type to overlay information on the captured pictures.

Picture Upload Time

The information will be overlaid when the captured picture starts to upload.

Picture Generation Time

The information will be overlaid when the captured picture is output.

Picture Exposure Time

The information will be overlaid when the captured picture is exposed.

5. Set Overlay Content.

Overlay Content

Text Overlay Prefix English Set

+Add Overlay Item

Default Type	Type	Space	Line Break Characters	Overlay Information	Overlay Position	Operation
Device No.	Device ...	0	0		☒	
Capture ...	Capture...	0	0	☐ Accurate to ...	☐	
Plate Nu...	Plate N...	0	0		☐	↑ ↓ 🗑️
Violation...	Violatio...	0	0		☐	
Speed Li...	Speed L...	0	0		☐	

Figure 5-5 Set Single Picture Overlay Content

- 1) Select **Text Overlay Prefix** language to overlay the information in corresponding language, and click **Set** to save.

 Note

The supported languages depend on the selected LPR **Country/Region** in **Configuration** → **Capture** → **Capture Parameters** → **LPR Parameters** .

Result: You can edit the custom information name in the selected language.

- 2) Click **Add Overlay Item** to select the information to overlay, and click **OK**.

 Note

The overlay information varies with different models. The actual device prevails.

- 3) Set the parameters below.

- **Default Type:** You can view the default overlay information name. If you have edited the name, you can refer to the default name for the definition.
- **Type:** You can edit a custom overlay information name.
- **Space:** Edit the number of space between the current information and the next one from 0 to 255. 0 means there is no space.
- **Line Break Characters:** Edit the number of characters from 0 to 100 between the current information line and the previous information line. 0 means no line break.
- **Overlay Information:** For some information types, you can edit the detailed information.
- **Overlay Position:** If you check it, the current information will be displayed from a new line.
- **Operation:** You can click  /  to adjust the display sequence of the overlay information, or click  to delete the item.

6. **Optional:** Check the other channel(s) to copy the same settings.
7. Click **Capture Test** to test the information overlay effect.
8. Click **Save**.

5.5.2 Set Composite Picture Overlay

If you want to overlay information on the composite pictures, set composite picture overlay.

Steps

1. Go to **Configuration → Capture → Capture Parameters → Capture Overlay Configuration**.
2. Click the composite type.
3. Enable text overlay.
4. Set **Overlay Style**.

Overlay Style

Percentage 100

Transparency 0

Date Format YYYY-MM-DD

Time Format ☐ 12-hour ☒ 24-hour

Font Size 16 x 32

Foreground Color ffffff

Background Color 000000

Overlay Position ☐ Overlay on the Picture
☐ Overlay Above the Picture
☒ Overlay Below the Picture

Font Color Inversion ☐

Capture Time Type Picture Upload Time ⓘ

Composite Picture Capture Time First

Figure 5-6 Set Composite Picture Overlay Style

Percentage

It is the percentage that the overlaid information occupies on the picture. For example, if you set the percentage to 50, the overlaid information in a row will occupy up to half of the image width, and the excess content will be overlaid from a new line.

Transparency

It is the condition of viewing the live view image through the overlaid information.

Font Color Inversion

Enable the function to detect the gray level of the image overlaid position automatically. When the image color is dark, the overlaid characters will be displayed as white automatically. When the image color is light, the overlaid characters will be displayed as black automatically.

Capture Time Type

Select the time type to overlay information on the captured pictures.

Picture Upload Time

The information will be overlaid when the captured picture starts to upload.

Picture Generation Time

The information will be overlaid when the captured picture is output.

Picture Exposure Time

The information will be overlaid when the captured picture is exposed.

Composite Picture Capture Time

The capture time of the selected picture sequence will be overlaid on the composite picture.

5. Set **Overlay Content**.

Overlay Content

Text Overlay Prefix

English

Set

+Add Overlay Item

Default Type	Type	Space	Line Break Characters	Overlay Information	Overlay Position	Operation
Device No.	Device ...	0	0		☒	
Capture ...	Capture...	0	0	☐ Accurate to ...	☐	
Plate Nu...	Plate N...	0	0		☐	↑ ↓ 🗑
Violation...	Violatio...	0	0		☐	
Speed Li...	Speed L...	0	0		☐	

Figure 5-7 Set Composite Picture Overlay Content

- 1) Select **Text Overlay Prefix** language to overlay the information in corresponding language, and click **Set** to save.



The supported languages depend on the selected LPR **Country/Region** in **Configuration → Capture → Capture Parameters → LPR Parameters** .

Result: You can edit the custom information name in the selected language.

- 2) Click **Add Overlay Item** to select the information to overlay, and click **OK**.



The overlay information varies with different models. The actual device prevails.

- 3) Set the parameters below.
 - **Default Type**: You can view the default overlay information name. If you have edited the name, you can refer to the default name for the definition.
 - **Type**: You can edit a custom overlay information name.
 - **Space**: Edit the number of space between the current information and the next one from 0 to 255. 0 means there is no space.
 - **Line Break Characters**: Edit the number of characters from 0 to 100 between the current information line and the previous information line. 0 means no line break.
 - **Overlay Information**: For some information types, you can edit the detailed information.
 - **Overlay Position**: If you check it, the current information will be displayed from a new line.
 - **Operation**: You can click  /  to adjust the display sequence of the overlay information, or click  to delete the item.
6. **Optional**: Check the other channel(s) to copy the same settings.
7. Click **Capture Test** to test the information overlay effect.
8. Click **Save**.

5.6 Set Image Encoding Parameters

If the captured pictures are not clear, set the resolution, size, and quality of the captured pictures.

Steps

1. Go to **Configuration → Capture → Capture Parameters → Image Encoding and Composition → Image Encoding** .

Image Encoding

Capture Resolution	1920*1200	▼
Close-up Picture Resolution	1920*1080	▼
Picture Size (KB)	512	
Composite Picture Size (KB)	1024	
Picture EXIF Format Transmission	☐	
Large Picture Quality (Scene/Composite)	100	
Middle Picture Quality (Close-up)	85	
Small Picture Quality (License Plate/Target...)	30	

Save

Figure 5-8 Set Image Encoding Parameters

2. Set the parameters below.

Capture Resolution

Select the resolution of the captured scene picture. When the picture size keeps the same, the higher the resolution, the more the picture will be compressed, and the slower the picture will be handled.

Close-up Picture Resolution

Select the resolution of the target close-up picture. When the picture size keeps the same, the higher the resolution, the more the picture will be compressed, and the slower the picture will be handled.

Picture Size

The size of the compressed captured picture. The actual size is related to the scene complexity.

Composite Picture Size

The size of the compressed composite picture. The actual size is related to the scene complexity.



Note

Only the device supporting picture composition supports composite picture size settings. The actual device prevails.

Picture EXIF Format Transmission

The captured pictures will be transmitted in the EXIF format.

Large Picture Quality (Scene/Composite)

Set the quality of the scene pictures and composite pictures. The value ranges from 1 to 100. The higher the value, the better the quality of the captured pictures.

Middle Picture Quality (Close-up)

Set the quality of the target close-up pictures. The value ranges from 1 to 100. The higher the value, the better the quality of the captured pictures.

Small Picture Quality (License Plate/Target/Face)

Set the quality of the license plate, target, or face pictures. The value ranges from 1 to 100. The higher the value, the better the quality of the captured pictures.

3. Click **Save**.

5.7 Set Picture Composition

You can enable the picture composition to composite several pictures into one to make it convenient to view the violation captured pictures.

Steps



Note

Functions and parameters vary with different models. The actual device prevails.

1. Go to **Configuration → Capture → Capture Parameters → Image Encoding and Composition → Picture Composition**.

Checkpoint Picture Composition

Enable Composition ☒

One Picture
N/A

Two Pictures
201

Three Pictures
301

Four Pictures
N/A

Composition Type ☐ Disable ☐ No Close-up ☒ With Close-up

 203	 204	 205	 206
 207	 208	 209	 210

Close-up Zooming Ratio 2

Non-Motor Vehicle Close-up Zooming Ratio 2

Close-up Picture No. 1

Output Close-up Independently ☐

Figure 5-9 Set Picture Composition

2. Check **Enable Composition**.
3. Set **Composition Type** for different picture quantities. Refer to the layout displayed on the interface to view the composition effect.
4. Set other composition parameters.

Close-up Zooming Ratio

The higher the value, the larger the close-up picture.

Non-Motor Vehicle Close-up Zooming Ratio

The higher the value, the larger the non-motor vehicle close-up picture.

Close-up Picture No.

It is the scene picture No. where the close-up comes from.

Output Close-up Independently

Enable the function to output a close-up picture before or after the scene picture independently.

 Note

Enabling composition and outputting close-up independently functions conflict with each other. You can only enable one.

5. Click **Save**.

5.8 Set Capture Schedule

You can set the schedule for the violation behavior capture or checkpoint capture if needed.

Steps

 Note

The function varies with different models. The actual device prevails.

1. Go to **Configuration → Capture → Capture Parameters → Capture Schedule**.
2. Click  to set the capture schedule according to the actual needs.

Edit

X

Capture Schedule

Lane

☒ Select All

☒ Lane1

☒ Lane2

☒ Lane3

No Plate Vehicle Capture

☒

Schedule

☒ Scheduled

Select All

Delete

Mon	0	2	4	6	8	10	12	14	16	18	20	22	24	
Tue	0	2	4	6	8	10	12	14	16	18	20	22	24	
Wed	0	2	4	6	8	10	12	14	16	18	20	22	24	
Thu	0	2	4	6	8	10	12	14	16	18	20	22	24	
Fri	0	2	4	6	8	10	12	14	16	18	20	22	24	
Sat	0	2	4	6	8	10	12	14	16	18	20	22	24	
Sun	0	2	4	6	8	10	12	14	16	18	20	22	24	

Cancel

OK

Figure 5-10 Set Capture Schedule

3. Select **Lane**.
4. **Optional:** Check **No Plate Vehicle Capture** according to the actual needs.
5. Adjust the time period.

- Click on the selected time period, and enter the desired value. Click **Save**.
- Click on the selected time period. Drag the both ends to adjust the time period.

6. **Optional:** Click  to copy the same settings to other days.

7. Click **OK**.

8. **Optional:** Check **Upload to Mailbox** to email the capture schedule to the user.

9. Click **Save**.

5.9 Set Captured Image Parameters

Set the parameters of captured images to raise the image quality.

Steps

1. Go to **Configuration → Capture → Capture Images → Image Parameters** .




Figure 5-11 Set Captured Image Parameters

2. Set the captured image parameters.



Note

You can click **Default** to restore all the set parameters to the default settings.

Image Enhancement

Contrast Enhancement

Check **Contrast Enhancement** to capture clearer images. Select **Contrast Enhancement Mode**, and set corresponding parameters.

Contrast Enhancement Mode	Description
Enable	The contrast enhancement mode is always enabled.
Time	The contrast enhancement mode is enabled during the set start time and end time. In other time, it is disabled.
Brightness	The contrast enhancement mode is enabled according to the brightness of the surroundings. In this case, you can set Brightness Grade .

Contrast Enhancement Grade

The higher the grade is, the more the contrast is enhanced.

Halo Suppression Grade

Halo suppression is to suppress the halo of the vehicle headlights. The higher the grade is, the more the halo is suppressed.

5.10 Set ICR

ICR adopts mechanical IR filter to filter IR in the day to guarantee the image effect, and to remove the IR filter at night to guarantee full-spectrum rays can get through the device.

Steps

Note

For the device supporting black and white mode at night, when the day-night mode is night, and **Black and White Mode at Night** has been enabled in **Configuration → Video → Camera Parameters → Camera Parameters → Image Enhancement**, the image displays as black and white. When **Black and White Mode at Night** is disabled, the image displays as color.

1. Go to **Configuration → Capture → Capture Images → ICR**.




Figure 5-12 ICR

2. Select **ICR Mode**.

Auto Switch	The ICR mode will switch to day or night mode automatically according to the surrounding light conditions. When the surrounding light is sufficient and higher than the set Threshold , the ICR mode will switch to day. When the surrounding light is insufficient and lower than the set Threshold , the ICR mode will switch to night.
Manual Switch	Select Day-night Mode to switch to the day or night manually.
Scheduled Switch	Set Day-night Mode , Start Time , and End Time to switch to the day or night mode only during the set time period.

3. Click **Save**.

5.11 Advanced Configuration



Note

The advanced configurations below are only provided to debug the device by the professionals.

5.11.1 System Service

You can enable the functions to debug the device.

Steps

1. Go to **Configuration → Capture → Advanced → System Service**.
2. Enable the functions according to your needs.



Note

The supported parameters vary with different models. The actual device prevails.

Enable Algorithm POS Information Debug

The algorithm POS information will be overlaid on the playback image when you play back the video with the dedicated tool.

Enable Positioning Frame Debug

The positioning frames of vehicle bodies and license plates will be overlaid on the captured pictures.

Enable Closed Positioning Frame

The bottom lines of the positioning frames on the captured pictures will be displayed. The frames will be closed.

Enable License Plate Frame

The license plate frames will be overlaid on the captured pictures.

Enable Multi-Way Upload

Data will be uploaded in multiple set ways simultaneously.

Enable Lane Line Debug

Check it to overlay lane lines on a captured picture.

Thermal working time

Set the working time of the thermal module.



Note

The function is only applicable to the Bi-Spectrum Incident Detection Camera.

3. Click **Save**.

5.11.2 Vehicle Capture and Recognition Service

Set the vehicle capture and recognition service to debug the device.

Steps



Note

The function varies with different models. The actual device prevails.

1. Go to **Configuration → Capture → Advanced → Vehicle Capture and Recognition Service**.
 2. Check the service(s) according to your needs.
-



Note

The supported services vary with different models. The actual device prevails.

Checkpoint Parameters

Filter Checkpoint Capture of Same Vehicle

It is used to debug the device with the same vehicle. When the same vehicle is triggered many times during a short period in the scene, the checkpoint pictures of the vehicle will not be captured. Set **Time of Filtering Checkpoint Duplicate License Plates** to filter the vehicle during the set time.

Do Not Capture Reverse-driving Vehicle

The reverse-driving vehicles will not be captured. For example, if you need to capture the vehicles driven from the west to the east, enable the function and the vehicles driven from the east to the west will not be captured.

Enable Non-Motor Vehicle Flow Statistics

Enable the function to count the upload the non-motor vehicle flow data.

Filter Two-Wheelers Without License

Check it to not capture the two-wheelers without license plates.

Enable ANR

Enable ANR (Automatic Network Replenishment) to save the videos in the condition of network disconnection, and synchronize data after the network is recovered.

Capture Frame Priority Mode

Check it to adopt license plate recognition results that processed by the single frame recognition algorithm.



Note

The function is only valid when **Capture Mode** is set as **Flash** for the application mode configuration.

Enable Multi-License Plates Recognition

Enable the function to recognize multi-license plates.

Violation Parameters

Add No. After Violation Type

The No. of the captured pictures will be added after the overlaid violation type on the pictures.

Filter Violation Capture of Motorcycle

The violation pictures of motorcycles will not be captured.

3. Click **Save**.

5.11.3 Set Image Format

You can enable smartJPEG which can save the storage space without influencing the resolution.

Steps

1. Go to **Configuration → Capture → Advanced → Image Service**.
2. Check **smartJPEG**.
3. **Optional:** Set **Expansion Ratio of License Plate Image** to expand the cutout scale of license plate image.
4. Click **Save**.

Chapter 6 Radar Detection

Radar is used to detect the target and link the capture. Set radar detection parameters before capturing vehicle pictures.



The function is only applicable to the device supporting radar.

6.1 Set Detection Parameters

For speed detection via radar, there is no strong relationship between the detected speed results and vehicle targets, which may result in the consequence that the speed result is linked to incorrect target or the speed result is lost. To solve the problems, speed detection via both radar and video is recommended. In this mode, the radar not only outputs the speed result of the target, but also outputs the coordinates of the position relationship between the target and radar. You can create the relationship between the radar position coordinates and vehicle pixel coordinates in the video via calibration to realize the linkage of the speed result and the vehicle target.

Before You Start

- Go to **Configuration → System → System Settings → Device Status** to view the radar status. If the status is normal, you can debug it. If the radar is in upgrading status, do not reboot the device.
- Go to **Configuration → Local** to enable **Rules Information** and **Radar Track**.

Steps

1. Go to **Radar → Lane Parameters → Radar** .




Figure 6-1 Set Radar Parameters

2. Set the basic parameters of the radar.

Scene Mode

Select the scene mode according to the actual construction scene of the device.

Horizontal Correction

It is the horizontal position deviation between the radar detected lane and the actual lane. You can set it in two ways.

- Method 1: Move the detected lane in the diagram leftwards or rightwards to overlap it with the actual lane to correct the difference.
- Method 2: Enter the horizontal distance(m) from the radar installation position to the middle line of the actual lane to correct the difference.

Angle Deviation

It is the angle deviation between the radar detected lane and the actual lane. Rotate the angle of the detected lane in the diagram to overlap it with the actual lane to correct the difference.

Construction Height

Set the construction height of the radar according to construction at the actual scene.

Radar Prediction

It is only used for debug by the professionals. Enable the function, and the radar will predict the target track which can be displayed on the interface according to the detected coordinates.

Radar Port Mapping

Enable the function and **SSH Service**, and the debugging command with radar configuration information will be sent to the device. The radar specified port can be mapped to the camera, and the radar can be debugged via the camera IP address with the radar debug software.

Debug Mode

Select **Debug Mode**. In this mode, the vehicles outside the drawn area will be displayed, to make it convenient to debug the radar. After debug, you should switch to **Normal Mode**.

Auto Angle Correction

After enabling radar debug mode, you can enable it to get the radar deviation angle according to the moving path of vehicle.

3. Click **Advanced Settings** to expand the advanced settings menu. Set advanced parameters of the radar.

Wave Band ID

0 to 4 stand for five frequencies. Set different wave bands for different radars in the same scene to prevent the radars in the same wave band from influencing each other.

Target Dwell Time

The dwell time of the vehicle. If the target dwell time is longer than the set time, vehicle data statistics will not be operated. Set it as 0 when measuring the queue length. It is only effective for the static targets.

Radar Detection Distance

It is the farthest distance that the radar can detect. The default value is 200 m. You can select the value to match the radar detection distance.

Distance to Stop Line

It is the distance from the point on the ground just below the installed radar to the stop line at the intersection. The targets detected in this range will be filtered.

Course Angle Calibration

Set the angle between the driving direction and the device installation direction. The radar course angle information of the current frame will be included when matching the video detected targets and radar detected targets.

Sensitivity

The lower the sensitivity is, the more sensitive the detection will be. For the detection which is too sensitive (e.g., some fixed facilities, such as the bus station on the lane, are detected as vehicles), you can adjust the sensitivity higher.

4. Click **Settings**.

5. **Optional:** You can click the icons on the upper right corner of the target track area to adjust the display status.

Table 6-1 Icon Description

Icon	Description
	Click to enable or disable the radar targets tracks display.
	Click to switch to the radar track or fusion track. The fusion track refers to the target track fused with the video detection and radar detection. In fusion track mode, you can view the targets detected by single radar, single video, or both radar and video according to the different colors displayed on the interface, and the detected vehicle information will be displayed in the vehicle list.

6.2 Set Lane Parameters

Set the parameters of the radar detected lanes.

Steps

1. Go to **Radar → Lane Parameters → Lane** .

Radar

Lane

Vehicle Direction

Trigger Vehicle Head and Tail

Number of Lanes

3

Lane Width

Lane01

3.75

m

Lane02

3.75

m

Lane03

3.75

m

Isolation Belt

Isolation Belt Location

Please Select

Isolation Belt Width

0.500

m

Approaching Lane

☐ Select All

☒ Lane1

☒ Lane2

☐ Lane3

Leaving Lane

☐ Select All

☐ Lane1

☐ Lane2

☒ Lane3

Figure 6-2 Set Lane Parameters

- Set the lane parameters below.

Vehicle Direction

Trigger Vehicle Head

The vehicles are driven towards the construction position of the camera.

Trigger Vehicle Tail

The vehicles are driven far away from the construction position of the camera.

Trigger Vehicle Head and Tail

There are vehicles driven both towards and far away from the construction position of the camera.

Number of Lane

The number of lanes should be consistent with the total lanes in the application mode settings.

Lane Width

Set the width of corresponding lane according to the actual scene.

Isolation Belt

When there is a isolation belt between the lanes of opposite directions, enable the function. Select the lane No. on the left of the isolation belt as **Isolation Belt Location**, and set **Isolation Belt Width** according to the actual scene.

Approaching/Leaving Lane

When you select **Vehicle Direction** as **Trigger Vehicle Head and Tail**, you need to select the approaching lane No. and leaving lane No.

3. Click **Settings**.

6.3 Set Radar Calibration

Calibrate radar in order to transfer the detected vehicle actual distance into the positions in the video.

Before You Start

Enable **Rules Information** and **Radar Track** in **Configuration** → **Local** to display the recognized license plate number, red speed frames, and green target frames in the live view image to make it convenient for calibration.

Steps

1. After enabling debug mode, click **Coordinate Calibration**.
2. Set the radar calibration.
 - Set manual calibration. Refer to **Manual Calibration** for details.
 - Set auto calibration. Refer to **Auto Calibration** for details.
 - Set force auto calibration. Refer to **Force Auto Calibration** for details.



Note

You're recommended to use auto calibration.

6.3.1 Manual Calibration

Steps




Figure 6-3 Manual Calibration Flow

1. Click **Coordinate Calibration**.
2. Select **Calibration Mode** as **Manual Calibration**.




Figure 6-4 Manual Calibration

3. Drag the two end points of the default lines on the live view image or drag the whole lines to adjust their positions according to the actual scene.
4. Draw the calibration area.

1) Select **Calibration Point**.



Note

4-point calibration by default.

- 2) Adjust the default calibration area on the live view image according to the actual scene, or click **Calibration** to redraw the area.
- 3) Click the left button of the mouse to locate the vertexes of the calibration area on the live view image clockwise, and click the right button of the mouse to finish the drawing.



Note

The number of vertexes should be consistent with the selected number of **Calibration Point**.

- 4) Measure the X-coordinates and Y-coordinates of the calibration points with measurement tool at site accurately, and enter the values in the corresponding coordinate text fields.



Note

- X-coordinate stands for the horizontal distance from the calibration point to the origin of the radar coordinates. Y-coordinate stands for the vertical distance from the calibration point to the origin of the radar coordinates. The origin (0, 0) of the radar coordinates locates in the middle of the whole lanes detected by the radar. You can refer to the schematic diagram on the right of the interface.
- If there are 4 points for the calibration area, the X-coordinates of point 1 and 2 should be negative values.
- If the speed displayed on the live view image is 0, you need to calibrate again. The best calibration effect is that the center of the red speed frame locates at the center of the lower boundary of the green target frame.

- 5) **Optional:** Click **Clear** to clear the drawn calibration area.

5. **Optional:** If there is no condition to measure the coordinates of the calibration points accurately at site, you can draw a calibration area and estimate the coordinates of the calibration points first, and then perform fine adjustment to the coordinates as the steps below.

- 1) Find a vehicle passing the calibration point in the live view image, and observe the relative position relationship between the vehicle target and the red speed frame. The distance between the position of the red speed frame and that of the green target frame may be large before calibration. You need to observe the moving tendency of the target frame and the speed frame. As shown below, you can see that the red speed frames and the green target frames are moving relatively.




Figure 6-5 Fine Adjustment Example

- 2) According to the relative positions, if the red speed frame is in front of the green target frame, decrease the Y-coordinate value. If the red speed frame is behind the green target frame, increase the Y-coordinate value. Adjust the values until the lower boundaries of the red speed frame and the green target frame are on the same horizontal line.
- 3) According to the relative positions, if the red speed frame is in the left position of the lower boundary center of the green target frame, decrease the X-coordinate value. If the red speed frame is in the right position of the lower boundary center of the green target frame, increase the X-coordinate value. Adjust the values until the lower boundaries of the red speed frame and the green target frame are on the same vertical line.
- 4) Adjust the other calibration points according to the methods above until all the vehicles in the detection area satisfy the requirement.

6. Optional: Check **Hide Calibration Lines** to hide the lines on the live view image.

7. Click **OK**.

6.3.2 Auto Calibration

Steps

- 1.** Click **Coordinate Calibration**.
- 2.** Select **Calibration Mode** as **Auto Calibration**.




Figure 6-6 Auto Calibration

3. Enable or disable independent lane settings.
 - If you disable independent lane settings, the device will recognize the lane lines in the scene and match the drawn lines according to the selected number of total lanes.
 - If you enable independent lane settings and select the number of total lanes, the corresponding number of lane lines will display on the live view image, and you need to adjust the lines according to the scene manually.



Note

If the lanes are bidirectional ways, or the lane range to be calibrated is inconsistent with the lanes set in the application mode, you are recommended to enable independent lane settings to draw the lane lines independently.

4. **Optional:** Select the lane line No. and click **Draw Lane Line** to redraw the corresponding lane line.



Note

The lane lines must be set accurately before auto calibration. For the scenes to which auto calibration is not applicable, like congestion, vehicles are waiting for the red traffic light, there are too few vehicles passing, etc., manual calibration is recommended.

5. Click **Start**.
The auto calibration starts, and you can view the calibration status and progress. 100% means the auto calibration is finished.
6. **Optional:** Click **End** if the speed detection effect via radar and video fusion mode has met the requirement during the process.
7. **Optional:** Click **Copy Parameters to Coordinate Mode** to copy the auto calibrated coordinates to the manual calibration mode.

8. Click **OK**.

What to do next

- After auto calibration, exit from the interface. Observe the calibration effect after a period of time. As shown below, if the red speed frame locates at the lower boundary center of the green target frame, that is, the red speed frame locates at the license plate position, the calibration effect satisfies the requirements. Otherwise, you need to calibrate again, or perform fine adjustment to the coordinates by the methods for the manual calibration. Refer to step 5 of **Manual Calibration** for details.



Figure 6-7 Good Calibration Effect Example

- For the scene with multiple lanes and congestion, observe the auto calibration effect. If the fusion effect is not good after the auto calibration is finished, you need to calibrate again manually. Refer to **Manual Calibration** for details.

6.3.3 Force Auto Calibration

You can select force auto calibration for the scene that the personnel at the site drives a car or SUV to pass in the visual field of the device to complete the calibration quickly.

Before You Start

- There is up to one moving target (a car or a SUV) in the visual field of the device during calibration.
- The vehicle speed keeps 20 to 40 km/h during calibration.

Steps

- The personnel at the site drives a car or SUV to pass far away from the visual field of the device along the far left/right lane until the vehicle disappears from the video/radar detection area

completely, and then enter into the video/radar detection area along the far left/right lane alternately for four times. If there is only one lane in the scene, drive along the far left/right lane line. You're recommended to drive the vehicle along the marked routes shown in the figure below.



Figure 6-8 Recommended Driving Routes for Force Auto Calibration

2. Click **Coordinate Calibration**.
3. Select **Calibration Mode** as **Force Auto Calibration**.




Figure 6-9 Force Auto Calibration

4. Enable or disable independent lane settings.

- If you disable independent lane settings, the device will recognize the lane lines in the scene and match the drawn lines according to the selected number of total lanes.
- If you enable independent lane settings and select the number of total lanes, the corresponding number of lane lines will display on the live view image, and you need to adjust the lines according to the scene manually.



Note

If the lanes are bidirectional ways, or the lane range to be calibrated is inconsistent with the lanes set in the application mode, you are recommended to enable independent lane settings to draw the lane lines independently.

-
5. **Optional:** Select the lane line No. and click **Draw Lane Line** to redraw the corresponding lane line.



Note

The lane lines must be set accurately before auto calibration. For the scenes to which auto calibration is not applicable, like congestion, vehicles are waiting for the red traffic light, there are too few vehicles passing, etc., manual calibration is recommended.

-
6. Click **Start**.
The auto calibration starts, and you can view the calibration status and progress. 100% means the auto calibration is finished.
 7. **Optional:** Click **End** if the speed detection effect via radar and video fusion mode has met the requirement during the process.
 8. **Optional:** Click **Copy Parameters to Coordinate Mode** to copy the auto calibrated coordinates to the manual calibration mode.
 9. Click **OK**.

What to do next

- After auto calibration, exit from the interface. Observe the calibration effect after a period of time. As shown below, if the red speed frame locates at the lower boundary center of the green target frame, that is, the red speed frame locates at the license plate position, the calibration effect satisfies the requirements. Otherwise, you need to calibrate again, or perform fine adjustment to the coordinates by the methods for the manual calibration. Refer to step 5 of **Manual Calibration** for details.



Figure 6-10 Good Calibration Effect Example

- For the scene with multiple lanes and congestion, observe the auto calibration effect. If the fusion effect is not good after the auto calibration is finished, you need to calibrate again manually. Refer to [Manual Calibration](#) for details.

6.4 Search Detected Vehicles

You can search the radar detected vehicles and export the information.

Steps

- 1. Click **Radar**.
- 2. View the detected vehicle information in the vehicle list.

Vehicle List

Search

Export

Refresh

☒ Auto Download(Default 200)

0/200

ID	Position	Speed(km/h)
0	0.00,0.00	0.00
231	-1.10,20.40	19.10
236	0.30,33.90	32.70
235	6.40,39.60	45.80
237	3.20,47.50	39.90

Figure 6-11 Vehicle List

- 3. Enter the vehicle No. in the text field, and press **Enter** to search the vehicle information.

4. Optional: Export the vehicle information.

- Search the vehicle first, and click **Export** to export the searched vehicle information to the selected directory of the computer.
- Click **Export** directly to export the information of all the detected vehicles to the selected directory of the computer.

5. Optional: In no plug-in mode, you can enable **Auto Download** to download the captured pictures to the computer directly.



Note

- If you have downloaded and installed plug-in, auto download is not supported.
 - The latest captured pictures will be downloaded and compressed as a file in the format of .zip automatically. There are up to 200 pictures in one compressed file. If you exit from the current interface, the auto downloading will stop. The auto downloaded files will be saved to the default downloading directory of the browser in the format of .zip. You can go to the directory, decompress the file, and view the captured pictures.
 - If you disable **Auto Download**, when you exit from the current interface, the dialogue box will pop up to prompt you if you need to download the arming captures. Click **OK** and the latest captured pictures will be downloaded and compressed as a file in the format of .zip automatically.
-

Chapter 7 View Real-Time Picture

You can view the real-time captured pictures and license plate information.

Steps



- The supported parameters vary with different models. The actual device prevails.
 - The supported functions are different in plug-in mode and no plug-in mode. In no plug-in mode, level 2 arming, measuring license plates, and enabling ruler are not supported.
-

1. Go to Live View → Real-Time Capture .

2. Click Arming.

The device will capture pictures automatically according to the set application mode parameters.

3. Select an item from the list, and you can view the capture scene picture, vehicle type, violation type, speed, and recognized license plate information.




Figure 7-1 Real-Time Capture (No Plug-in)




Figure 7-2 Real-Time Capture (with Plug-in)

4. Optional: You can do the following operations.



- **Level 1 Arming:** Only the current computer can arm the device and receive the captured pictures in real time. The pictures will not be stored in the storage card. The pictures in the storage card will be uploaded to the level 1 arming terminal.
- **Level 2 Arming** can connect three clients or webs. The pictures will be uploaded to the client/web, and stored in the storage card.
- **Disarming:** Disable the real-time capture function.



Click it to capture a picture manually.



Click the arrow to set continuous capture parameters and then click the icon to enable continuous capture manually. The device will capture pictures according to the set interval.

- **Trigger Channel:** If the camera has multiple channels, enter the channel No. to enable continuous capture.
- **Waiting Time:** Set the interval between continuous captures when triggering continuous capture continuously.
- **Capture Times:** Select the number of captured pictures per continuous capture.
- **Interval:** Set the interval between each capture in the continuous capture. Up to four intervals can be set, and the default interval is 100 ms.



The function is only available in plug-in mode. Click it to measure the license plate pixel. Click it again to disable the measurement.



The function is only available in plug-in mode. Click it to enable the ruler to measure the license plate.



Click it to display the captured picture in full screen mode. Press **Esc** on the keyboard to exit from the full screen mode.

Open Folder

The button is available in plug-in mode. You can click it to open the saving path of captured pictures.

Auto Download

In no plug-in mode, you can enable **Auto Download** to download the captured pictures to the computer directly. The latest captured pictures will be downloaded and compressed as a file in the format of .zip automatically. The max. number of pictures in one compressed file depends on the selected **Number of Auto Captured Pictures in Configuration → Local** in no plug-in mode. If you disarm, the auto downloading will stop. You can view the downloading progress on the interface. The auto downloaded files will be saved to the default downloading directory of the browser in the format of .zip. You can go to the directory, decompress the file, and view the captured pictures.

If you disable **Auto Download**, when you disarm, the dialogue box will pop up to prompt you if you need to download the arming captures. Click **OK** and the latest captured pictures will be downloaded and compressed as a file in the format of .zip automatically.

Chapter 8 Live View and Local Configuration

8.1 Live View

8.1.1 Start/Stop Live View

Click  to start live view. Click  to stop live view.

8.1.2 Select Image Display Mode

Click  to select an image display mode.

8.1.3 Select Window Division Mode

Click  to select a window division mode.

8.1.4 Select Stream Type

Click  to select the stream type. It is recommended to select the main stream to get the high-quality image when the network condition is good, and select the sub-stream to get the fluent image when the network condition is not good enough. The third stream is custom.



Note

The third stream varies with different models. The actual device prevails.

8.1.5 Capture Picture Manually

You can capture pictures manually on the live view image and save them to the computer.

Steps

1. Click  to capture a picture.
2. **Optional:** Go to **Configuration** → **Local** → **Live View Parameters** and select **Image Format**.
3. **Optional:** Go to **Configuration** → **Local** → **Picture and Clip Settings** to view the saving path of snapshots in live view.

8.1.6 Record Manually

You can record videos manually on the live view image and save them to the computer.

Steps

1. Click  to start live view.
2. Click  to start recording.
3. Click  to stop recording.
4. **Optional:** Go to **Configuration → Local → Record File Settings** to view the saving path of record files.

8.1.7 Enable Digital Zoom

You can enable digital zoom to zoom in a certain part of the live view image.

Steps

1. Click  to start live view.
2. Click  to enable digital zoom.
3. Place the cursor on the live view image position which needs to be zoomed in. Drag the mouse rightwards and downwards to draw an area.
The area will be zoomed in.
4. Click any position of the image to restore to normal image.
5. Click  to disable digital zoom.

8.1.8 Enable Regional Focus

Steps



Note

The function varies with different models. The actual device prevails.

1. Click .
2. Drag the cursor from the upper left corner to the lower right corner to select the area that needs to be focused.

Result

The selected area is focused.

8.1.9 Select Video Mode

Set the video mode when adjusting the device focus during construction.

Click  and select the normal mode when the device is running normally.

8.2 Set Snapshot Mode

Click **Live View**, and you can enable or disable snapshot mode on the upper right corner of the interface.

-  : The snapshot mode is enabled. In this mode, only the image in the live view interface is in real-time streaming, and the live view images in other interfaces are just pictures. You can refresh the interfaces to refresh the pictures. For the conditions that the network is unstable, or the computer performance is not that good, you're recommended to enable snapshot mode to raise the operation efficiency.
-  : The snapshot mode is disabled. All the live view images are in real-time streaming.



Note

Disable snapshot mode before drawing areas for cropping capture pictures, ROI, privacy mask, and regional exposure.

8.3 PTZ Operation

Click **Live View**. The **PTZ Control** menu is displayed on the left.



Note

- The PTZ supports power-off memory. When the device is suddenly cut off power or restarted normally, it can automatically return to the position before the power cut or reboot.
 - The PTZ function varies with different models. The actual device prevails.
 - Other unmentioned buttons are reserved buttons.
-




Figure 8-1 PTZ Control Panel

Table 8-1 Button Description

Button	Description
	Adjust the PTZ speed.
	Zoom + and Zoom - - Hold  to zoom in the scene. - Hold  to zoom out the scene.
	Focus + and Focus - - Hold  to make near objects become clear and distant objects become vague. - Hold  to make distant objects become clear and near objects become vague.
	Iris + and Iris - - Hold  to increase the iris diameter when in a dark environment. - Hold  to decrease the iris diameter when in a bright environment.
	Lens Initialization

Button	Description
	It is applicable to devices with motorized lenses. You can use this function when overcoming image blurs caused by overtime zooming or focusing.
	Auxiliary Focus It is applicable to devices with motorized lenses. Use this function to focus the lens automatically and make images become clear.

8.4 Local Configuration

Go to **Configuration** → **Local** to set the live view parameters and change the saving paths of videos, captured pictures, scene pictures, etc.



Note

The interfaces in no plug-in mode and plug-in mode are different.

Local Configuration in Plug-in Mode

Live View Parameters

Protocol Type ☒ TCP ☐ UDP ☐ HTTP ☐ HTTPS
Stream Type ☒ Main Stream ☐ Sub-Stream
Live View Performance ☐ Shortest Delay ☒ Balanced ☐ Fluency
Decoding Type ☒ Software Decoding ☐ Hardware Decoding
Rules Information ☐ Enable ☒ Disable
Algorithm Information ☐ Enable ☒ Disable
Image Size ☒ Auto-Fill ☐ 4:3 ☐ 16:9
Image Format ☒ JPEG ☐ BMP
Rendering Engine ☐ D3D9 ☒ D3D11
Radar Track ☐ Enable ☒ Disable

Record File Settings

Record File Size ☐ 256M ☒ 512M ☐ 1G
Save record files to C:\Users\ \PluginWeb\RecordFiles
Save downloaded files to C:\Users\ \PluginWeb\DownloadFiles

Picture and Clip Settings

Save snapshots in live view to C:\Users\ \PluginWeb\CaptureFiles
Save downloaded pictures to C:\Users\ \PluginWeb\ViewPics
Save scene pictures to C:\Users\ \PluginWeb\ScenePics
Save snapshots when playback to C:\Users\ \PluginWeb\PlaybackPics
Save clips when playback to C:\Users\ \PluginWeb\PlaybackFiles

Figure 8-2 Local Configuration in Plug-in Mode

Protocol Type

Select the network transmission protocol according to the actual needs.

TCP

Ensures complete delivery of streaming data and better video quality, but the real-time transmission will be affected.

UDP

Provides real-time audio and video streams.

HTTP

Gets streams from the device by a third party client.

HTTPS

Gets streams in https format.

Stream Type

Main Stream

Select it to get the high-quality image when the network condition is good.

Sub-Stream

Select it to get the fluent image when the network condition is not good enough.

Live View Performance

Shortest Delay

The video is real-time, but its fluency may be affected.

Balanced

Balanced mode considers both the real time and fluency of the video.

Fluency

When the network condition is good, the video is fluent.

Decoding Type

Software Decoding

Decode via software. It takes up more CPU resources but provides images with better quality when it compares to the hardware decoding.

Hardware Decoding

Decode via GPU. It takes up less CPU resources but provides images with worse quality when it compares to the software decoding.

Rules Information

If you enable this function, tracking frames will be displayed on the live view interface when there are vehicles passing.

Algorithm Information

Enable it to overlay algorithm information of the stream.

Image Size

The display ratio of the live view image.

Image Format

The saving format of manually captured images.

Rendering Engine

Select the rendering API of the browser. D3D9 uses fixed rendering pipeline. D3D11 uses programmable graphics pipeline, in which the shader replaces the traditional fixed rendering pipeline to improve visual effects and enhance the picture quality.

Radar Track

When the radar is connected, enable it to generate and overlay the radar tracks.



Note

The function is only applicable to the device supporting radar.

Record File Size

Select the packed size of the manually recorded video files. After the selection, the max. record file size is the value you selected.

Save record files to

Set the saving path of the manually recorded video files.

Save downloaded files to

Set the saving path of the download files.

Save snapshots in live view to

Set the saving path of the manually captured pictures in live view mode.

Save downloaded pictures to

Set the saving path of the downloaded pictures.

Save scene picture to

Set the saving path of the captured pictures in **Live View → Real-Time Capture** .

Save snapshots when playback to

Set the saving path of the manually captured pictures in playback mode.

Save clips when playback to

Set the saving path of the clips in playback mode.

Local Configuration in No Plug-in Mode

Picture and Clip Settings

Number of Auto Captured Pictures ☐ 50 ☐ 100 ☐ 150 ☒ 200

Rules Information ☐ Enable ☒ Disable

! In no plug-in mode, the rule information feature requires HTTPS login to use.

Radar Track ☒ Enable ☐ Disable

Save

Figure 8-3 Local Configuration in No Plug-in Mode

Number of Auto Captured Pictures

Select the max. number of auto downloaded pictures in one compressed file in **Live View → Real-Time Capture** in no plug-in mode.

Rules Information

If you enable this function, tracking frames will be displayed on the live view interface when there are vehicles passing.



Note

In no plug-in mode, the rule information function requires access via HTTPS.

Radar Track

When the radar is connected, enable it to generate and overlay the radar tracks.



Note

The function is only applicable to the device supporting radar.

Chapter 9 Record and Capture

9.1 Set Storage Card

If you want to store the files to the storage card, make sure you insert and format the storage card in advance.

Before You Start

Insert the storage card to the device.

Steps

1. Go to **Configuration → Storage → Storage Management → HDD Management**.




Figure 9-1 Set Storage Card

2. Format the storage card in two ways.
- Check the storage card, and click **Format** to format it manually.

Note

For the newly installed storage card, you need to format it manually before using it normally.

- If you want to format the storage card automatically when the card is abnormal, enable **Auto-Initialize Redundant Storage**.

Note

If you enable **Auto-Initialize Redundant Storage**, reboot the device to take the settings into effect.

3. Set other parameters.

Auto-Upload Data in Redundant Storage

If the device has been connected to the platform, and you want to upload the storage card information automatically, enable the function and set the interval.

4. Set **Capture Quota Ratio** and **Video Quota Ratio** according to the actual needs.



Note

The percentage sum of the capture and video quota ratio should be 100%.

5. Click **Save**.

9.2 Set Record Schedule

Set record schedule to record video automatically during configured time periods.

Before You Start

Install the storage card.

Steps

1. Go to **Configuration → Storage → Schedule Settings → Record Schedule**.
2. Select **Record Stream**.
3. **Optional:** Enable the functions below according to your needs.

Enable Overwritten Recording

When the storage is full, the earliest videos will be overwritten.

Enable Storing Expiration

Enable the function and set **Expired Time** for the recorded videos stored in the storage card.
Beyond the time, the files will be overwritten.

4. Enable the record schedule.

Advanced

Record Stream ☒ Main Stream ☐ Sub-Stream

Enable Overwritten Recording ☒

Enable Storing Expiration ☒






Expired Time (day)

Record Configuration

Enable Record Schedule ☒

☒ Scheduled

Select All Delete

Mon		
Tue		
Wed		
Thu		
Fri		
Sat		
Sun		

Save

Figure 9-2 Set Record Schedule

- Click **Select All** to enable the device to record the whole days. Or drag the cursor on the time bar to set a recording time.

 Note

Up to 8 time periods can be set on a time bar.

- Adjust the recording time.
 - Click a set recording period and enter the start time and end time in the pop-up window.
 - Drag two ends of the set recording period bar to adjust the length.
 - Drag the whole set recording period bar and relocate it.
- Optional:** Delete recording periods.
 - Click a set recording period and click **Delete** in the pop-up window.
 - Click **Delete** on the record configuration interface to delete all the schedules.
- Optional:** Click  to copy the settings to other days.
- Click **Save**.

Result

The device will only record at the set periods.

9.3 Set Snapshot Schedule

You can enable storage expiration of the snapshots saved in the storage card.

Before You Start

Install the storage card.

Steps

1. Go to **Configuration → Storage → Schedule Settings → Snapshot Schedule**.
2. Enable storing expiration.




Figure 9-3 Set Snapshot Schedule

3. Set **Expired Time**.
4. Click **Save**.

Result

Beyond the set expired time, the snapshots saved in the storage card will be overwritten.

9.4 Search Picture

You can search the captured pictures stored in the storage card and export the pictures you need.

Before You Start

Install the storage card, and ensure the storage status is normal.

Steps

1. Click **Picture**.
2. Set search conditions.



Note

Search conditions vary with different models. The actual device prevails.

3. Click **Search**.

The searched pictures information will be displayed in the picture list.



Note

If you have set level 1 arming for the device, the captured pictures will not be saved in the storage card. Go to the saving path of scene pictures to view them. You can go to **Configuration** → **Local** to check the saving path.

4. Optional: You can do the following operations.

Download pictures	Check picture(s) and click Download to save them to local. The downloaded picture(s) will be marked as "Downloaded". You can go to Configuration → Local to check the saving path.
View picture details	Click Live View to view the picture details, such as the license plate number, vehicle type, etc.

9.5 Playback

You can search, play back, and download videos that stored on the storage card.

Steps

1. Click **Playback**.
2. Select a channel.
3. Select a date.
4. Click **Search**.
5. Click  to start playback.
6. **Optional:** You can also do the following operations.

Set playback time	• Drag the time bar to the target time and click  to play the video. • Click the current time point showed above the time bar and enter the target time point in the popup window. Click OK and click  to play the video.
Capture image	Click  to capture an image.
Clip record	Click  /  to start/stop clipping the record.
Play back in single frame	Click  once to play back the video in one frame.
Download record	a. Click . b. Select the start time and end time. c. Click Search. d. Check record files that need to be downloaded. e. Click Download.
Stop playback	Click  to stop playback.
Slow forward	Click  to slow down the playback.
Fast forward	Click  to speed up the playback.

Digital zoom

Click  to enable digital zoom.

Click  to disable digital zoom.

Chapter 10 Encoding and Display

10.1 Set Camera Parameters

You can adjust the image parameters to get clear image.

Steps



Note

The supported parameters may vary with different models. The actual device prevails.

1. Go to **Configuration** → **Video** → **Camera Parameters** → **Camera Parameters** .
2. Set the camera parameters.

▼ Picture Adjustment Default

Saturation 50

Sharpness 50

Contrast 50

White Balance ▼

White Balance Level 50

Hue Range ☒ 0-255 ☐ 16-235

Gamma Correction ☐ Enable

WDR Mode ▼

> Exposure Parameters Default

> Image Enhancement Default

Figure 10-1 Set Camera Parameters



Note

- The supported parameters vary with different models. The actual device prevails.
- You can click **Default** to restore the parameters to default settings.

Picture Adjustment

Saturation

It refers to the colorfulness of the image color.

Sharpness

It refers to the edge contrast of the image.

Contrast

It refers to the contrast of the image. Set it to adjust the levels and permeability of the image.

White Balance

It is the white rendition function of the device used to adjust the color temperature according to the environment. Set **White Balance Level**.

Hue Range

Select the range to adapt to the display.

Gamma Correction

The higher the gamma correction value is, the stronger the correction strength is.

WDR Mode

Wide Dynamic Range (WDR) can be used when there is a high contrast of the bright area and the dark area of the scene.

Select **WDR Switch Mode** and set corresponding parameters according to your needs.

Enable

Set **WDR Level**. The higher the level is, the higher the WDR strength is.

Time

Enable WDR according to the set time period and level.

Brightness

Set **Brightness Threshold** and **WDR Level**. When the brightness reaches the threshold, WDR will be enabled.

Lens Type

Select the lens type according to the actual needs.

Exposure Parameters

Brightness

It refers to the brightness the image.

Shutter

If the shutter speed is quick, the details of the moving objects can be displayed better. If the shutter speed is slow, the outline of the moving objects will be fuzzy and trailing will appear.

Gain

It refers to the upper limit value of limiting image signal amplification. It is recommended to set a high gain if the illumination is not enough, and set a low gain if the illumination is enough.

Slow Shutter

This function can be used in underexposure condition. It lengthens the shutter time to ensure full exposure. The higher **Slow Shutter Level** is, the slower the shutter speed is.

Video Standard

Select the video standard according to the actual power supply frequency.

Image Enhancement

Brightness Enhancement at Night

The scene brightness will be enhanced at night automatically.

Plate Brightness Compensation

Check it. The plate brightness compensation can be realized, and various light supplement conditions can be adapted via setting license plate expectant brightness and supplement light correction coefficient. The higher the sensitivity is, the easier this function can be enabled.

3D DNR

Digital Noise Reduction (DNR) reduces the noise in the video stream.

In **Normal Mode**, the higher the **3D DNR Level** is, the stronger the noise will be reduced. But if it is too high, the image may become fuzzy.

In **Expert Mode**, set **Spatial Intensity** and **Time Intensity**. If the space domain intensity is too high, the outline of the image may become fuzzy and the details may lose. If the time domain intensity is too high, trailing may appear.

2D DNR

The higher the **2D DNR Level** is, the stronger the noise will be reduced. But if it is too high, the image may become fuzzy.

Defog

Enable defog to get a clear image in foggy days.

Black and White Mode at Night

When ICR is in night mode, you can check it to keep the video in black and white mode at night.

3. Optional: Click **Capture Test** to check the image effect.

10.2 Set OSD

You can customize OSD information on the live view.

Steps

1. Go to **Configuration → Video → Text Overlay on Video** .

Text Overlay on Video

Font Size

96 x 96

Alignment

Align Right

Min. Horizontal Margin

None

Min. Vertical Margin

1 Character

OSD Property

Not Transparent & Not Flashing

OSD Color

Black and White Self-adaptive

Overlay Information

Camera Name

☒ Enable

Camera 01

Display Date

☒ Enable

Date Format

DD-MM-YYYY

Time Format

☐ 12-hour

☒ 24-hour

More

☒ Display Week

☐ Millisecond

Custom Information

+ Add

No.	Custom Information	Operation
1	test	

Save

Figure 10-2 Set OSD

2. Set display properties (font, color, etc.).

Alignment

If you select **Align Left** or **Align Right**, set **Min. Horizontal Margin** and **Min. Vertical Margin**.

3. Set display contents.

- 1) Enable **Camera Name**, and enter the camera name.
- 2) Enable **Display Date**, and set the time and date format.

3) Enable **Display Week** or **Millisecond** according to your needs.

4. **Optional:** Click **Add** and enter information if you want to add custom information.



Note

Up to 6 items of custom information can be added.

5. Drag the red frames on the live view image to adjust the OSD positions.

6. Click **Save**.

Result

The set OSD will be displayed in live view image and recorded videos.

10.3 Set Video Encoding Parameters

Set video encoding parameters to adjust the live view and recording effect.

- When the network signal is good and the speed is fast, you can set high resolution and bitrate to raise the image quality.
- When the network signal is bad and the speed is slow, you can set low resolution, bitrate, and frame rate to guarantee the image fluency.
- When the network signal is bad, but the resolution should be guaranteed, you can set low bitrate and frame rate to guarantee the image fluency.
- Main stream stands for the best stream performance the device supports. It usually offers the best resolution and frame rate the device can do. But high resolution and frame rate usually means larger storage space and higher bandwidth requirements in transmission. Sub-stream usually offers comparatively low resolution options, which consumes less bandwidth and storage space. Third stream is offered for customized usage.

Steps



Note

The supported parameters vary with different models. The actual device prevails.

1. Go to **Configuration → Video → Video Encoding → Video Encoding** .

2. Set the parameters for different streams.

Stream Type

Select the stream type according to your needs.



Note

The supported stream types vary with different models. The actual device prevails.

Bitrate

Select relatively large bitrate if you need good image quality and effect, but more storage spaces will be consumed. Select relatively small bitrate if storage requirement is in priority.

Frame Rate

It is to describe the frequency at which the video stream is updated and it is measured by frames per second (fps). A higher frame rate is advantageous when there is movement in the video stream, as it maintains image quality throughout.

Resolution

The higher the resolution is, the clearer the image will be. Meanwhile, the network bandwidth requirement is higher.

SVC

Scalable Video Coding (SVC) is an extension of the H.264/AVC and H.265 standard. Enable the function and the device will automatically extract frames from the original video when the network bandwidth is insufficient.

Bitrate Type

Select the bitrate type to constant or variable.

Video Quality

When bitrate type is variable, 6 levels of video quality are selectable. The higher the video quality is, the higher requirements of the network bandwidth.

Profile

When you select H.264 or H.265 as video encoding, you can set the profile. Selectable profiles vary according to device models.

I Frame Interval

It refers to the number of frames between two key frames. The larger the I frame interval is, the smaller the stream fluctuation is, but the image quality is not that good.

Video Encoding

The device supports multiple video encoding types, such as H.264, H.265, and MJPEG. Supported encoding types for different stream types may differ. H.265 is a new encoding technology. Compared with H.264, it reduces the transmission bitrate under the same resolution, frame rate, and image quality.

3. Click **Save**.

10.4 Set ROI

ROI (Region of Interest) encoding helps to assign more encoding resources to the region of interest, thus to increase the quality of the ROI whereas the background information is less focused.

Before You Start

Please check the video encoding type. ROI is supported when the video encoding type is H.264 or H.265.

Steps

1. Go to **Configuration → Video → Video Encoding → ROI** .

Stream Type

Stream Type

☒ Main Stream

☐ Sub Stream

☐ Third Stream

Fixed Area

Area No.	ROI Level	Area Name	Enable	Operation
1	1		☒	Draw Area Clear
2	1		☐	
3	1		☐	
4	1		☐	
5	1		☐	
6	1		☐	
7	1		☐	
8	1		☐	

Save

Figure 10-3 Set ROI

2. Select **Stream Type**.
3. Set ROI area.

1) Enable the corresponding area.

2) Select **ROI Level**.



Note

The higher the ROI level is, the clearer the image of the detected area is.

- 3) Enter **Area Name**.
- 4) Click **Draw Area**.
- 5) Drag the mouse on the live view image to draw the fixed area.
- 6) Select the fixed area that needs to be adjusted and drag the mouse to adjust its position.
- 7) Click **Stop Drawing**.

- 8) Repeat the steps above to set more areas. Up to 8 areas are supported.
- 9) **Optional:** If you want to delete the area, click **Clear** to delete.
4. Click **Save**.

10.5 Set Privacy Mask

The privacy mask can be used to protect personal privacy by concealing parts of the image from view or recording with a masked area.

Steps

1. Go to **Configuration → Video → Video Encoding → Privacy Mask**.
2. Enable privacy mask.

Enable Privacy Mask ☒

Fixed Area

Area No.	Type	Enable	Operation
1	Black ▼	☒	Draw Area Clear
2	Black ▼	☐	
3	Black ▼	☐	
4	Black ▼	☐	

Save

Figure 10-4 Set Privacy Mask

3. Set the privacy mask area.
 - 1) Enable the corresponding privacy mask area.
 - 2) Select **Type**.
 - 3) Click **Draw Area**.
 - 4) In the live view image, drag the mouse to draw the privacy mask area of the selected area No.
 - 5) Click **Stop Drawing**.
 - 6) Repeat the steps above to set more areas. Up to 4 areas are supported.
 - 7) **Optional:** If you want to delete the area, click **Clear** to delete.
4. Click **Save**.

10.6 Enable Regional Exposure

Enable regional exposure to expose partial area of the live view image.

Steps

1. Go to **Configuration → Video → Video Encoding → BLC** .
2. Enable **Regional Exposure**.
3. Drag the mouse to draw an area in the live view image.
The drawn area will be exposed.
4. Click **Save**.

Chapter 11 Serial Port Configuration

11.1 Set RS-485

Set RS-485 parameters if the device needs to be connected to other peripheral devices controlled by RS-485 serial port.

Before You Start

The corresponding device has been connected via the RS-485 serial port.

Steps



Note

The number of available RS-485 serial port varies with different models.

1. Go to **Configuration → System → System Settings → Serial Port → RS-485**.
 2. Set **Baud Rate, Data Bit, Stop Bit**, etc.
-



Note

The parameters should be same with those of the connected device.

3. Set **Work Mode**.
-



Note

- The supported work modes vary with different models. The actual device prevails.
 - You need to reboot the device after editing the work mode to take effect.
-

Application Trigger

Select it when a signal trigger device (such as a radar) is connected to the RS-485 serial port of the device.

Transparent Channel

Select it when the other peripheral device is connected to the RS-485 serial port of the device for communication transmission.

GPS

Select it when a GPS device is connected to the RS-485 serial port of the device to receive positioning information.

Traffic Signal Controller Mode

Select it when a traffic signal controller is connected to the RS-485 serial port of the device for communication transmission.

4. Click **Save**.

11.2 Set RS-232

Set RS-232 parameters if you need to debug the device via RS-232 serial port.

Before You Start

The debugging device has been connected via the RS-232 serial port.

Steps

1. Go to **Configuration → System → System Settings → Serial Port → RS-232**.
2. Set **Baud Rate, Data Bit, Stop Bit**, etc.



Note

The parameters should be same with those of the connected device.

3. Select **Work Mode**.



Note

- The supported work modes vary with different models. The actual device prevails.
- You need to reboot the device after editing the work mode to take effect.

Console

Select it when you need to debug the device via RS-232 serial port.

Transparent Channel

Select it, and the network command can be transmitted to RS-232 control command via the RS-232 serial port.

Narrow Bandwidth Transmission

Reserved.

4. Click **Save**.

Chapter 12 Event and Alarm

12.1 Exception Alarm

Set exception alarm when the network is disconnected, the IP address is conflicted, etc.

Steps



Note

The supported exception types vary with different models. The actual device prevails.

1. Go to **Configuration → Event → Alarm Linkage → Exception**.
2. Select the exception type(s) and the linkage method.
3. Click **Save**.

12.2 Set Email

When the email is enabled and set, the device will send an email notification to all designated receivers if an alarm event is detected.

Before You Start

Set the DNS server before using the email function. Go to **Configuration → Network → Network Parameters → Network Interface** for DNS settings.

Steps

1. Go to **Configuration → Network → Data Connection → Email**.
2. Enable Email.

Enable Email ☒

Email

Sender

Sender's Address

SMTP Server

SMTP Port

Email Encryption

Upload No-Plate Data ☒ Enable

Server Authentication ☒ Enable

User Name

Password

Confirm Password

Receiver

No.	Receiver	Receiver's Address	Test
1			Test
2			Test
3			Test

Figure 12-1 Set Email

3. Set email parameters.

1) Enter the sender's email information, including **Sender**, **Sender's Address**, **SMTP Server**, and **SMTP Port**.

2) Select **Email Encryption**.

None

Emails are sent without encryption.

TLS

Emails are sent after being encrypted by TLS.

3) **Optional**: If you want to upload no-plate data, enable **Upload No-Plate Data**.

4) **Optional**: If your email server requires authentication, enable **Server Authentication** and enter your user name and password to log in to the server.

5) Enter the receiver's information, including the receiver's name and address.

6) **Optional**: Click **Test** to test if the function is well configured.

4. Click **Save**.

12.3 Set Email Event

When the set event occurs, the device can be set to send an email with alarm information to the user.

Before You Start

The email has been enabled and related email parameters have been configured.

Steps

1. Go to **Configuration → Event → Alarm Linkage → Email Event** .

2. Enable linkage to trigger an email for login alarm.

3. Click **Save**.

Chapter 13 Safety Management

13.1 Manage User

The administrator can add, modify, or delete other accounts, and grant different permissions to different user levels.

Steps

1. Go to **Configuration → System → User Management → User List**.
2. Add a user.

Figure 13-1 Add User

- 1) Click **Add**.
- 2) Enter **User Name** and select **User Type**.
- 3) Select **Password Level**. The password level of the added user should conform to the selected level.
- 4) Enter **Admin Password**, **New Password**, and confirm the password.



Caution

To increase security of using the device on the network, please change the password of your account regularly. Changing the password every 3 months is recommended. If the device is

used in high-risk environment, it is recommended that the password should be changed every month or week.

-
- 5) Assign remote permissions to users based on needs.

User

Users can be assigned permissions of viewing live video and changing their own passwords, but no permissions for other operations.

Operator

Operators can be assigned all permissions except for operations on the administrator and creating accounts.

- 6) Enable **Link to DN** and set the DN value. Then the added user can log in to the device via PIN code, user name, and password.
- 7) Click **OK**.

3. **Optional:** You can do the following operations.

Edit the login mode Click **Login Mode** and select the login mode. If you select **Login via PIN Code, User Name, and Password**, you need to enable **Link to DN** and set the DN value when adding the user. Then the user can only log in to the device by entering correct PIN code, user name, and password. You can refer to **Set Login Mode** for details.

Edit the user information Click  to edit the user information.

Delete the user Click  to delete the user.

13.2 Enable User Lock

To raise the data security, you are recommended to lock the current IP address.

Steps

1. Go to **Configuration → System → Security → Security Service → Software**.
2. Check **Enable User Lock**.
3. Click **Save**.

Result

When the times you entered incorrect passwords have reached the limit, the current IP address will be locked automatically.

13.3 Set SSH

To raise network security, you are recommended to disable SSH service. The configuration is only used to debug the device for the professionals.

Steps

1. Go to **Configuration → System → Security → Security Service → Software** .
2. Enable or disable **SSH Service**, and set **SSH Port** if you enable the function.
3. Click **Save**.

13.4 Prohibit PING

You can prohibit the external devices to operate network connection volume test to the current device.

Steps

1. Go to **Configuration → System → Security → Security Service → Software**
2. Enable **Prohibit PING**.
3. Click **Save**.

13.5 Set SDK Protocol Authentication Mode

When you need to operate development integration or data collection via SDK protocol, you are recommended to enable SDK protocol authentication to enhance the information security.

Steps

1. Go to **Configuration → System → Security → Security Service → Authentication Settings** .
2. Select **SDK Protocol Authentication Mode**.



Note

You are recommended to select **Safety Mode**. In this mode, the device cannot be logged in via an invertible password of SDK protocol, which can enhance the information security.

3. Click **Save**.

13.6 Set RTSP Authentication

You can improve network access security by setting RTSP authentication.

Steps

1. Go to **Configuration → System → Security → Security Settings → Authentication Settings** .
2. Select **RTSP Authentication**.

digest

The device only supports digest authentication.

3. Click **Save**.

13.7 Set Timeout Logout

You can improve network access security by setting timeout logout.

Steps

1. Go to **Configuration → System → Security → Security Service → Login Management**.
2. Enable timeout logout for static page.
3. Set **Max. Timeout**.
4. Click **Save**.

Result

When the page static time exceeds the set time, the device will automatically log out.

13.8 Set Password Validity Period

You can improve network access security by setting password validity period.

Steps

1. Go to **Configuration → System → Security → Security Service → Login Management**.
2. Select **Password Validity Period**.
 - Select **Permanent**. The password will be permanently valid.
 - Select **Daily** and set **Password Expiry Time**. It will prompt you that the password is expired according to the set password expiry time, and you need to set the new password.
3. Click **Save**.

13.9 Set Login Mode

You can select the login mode for the current user.

Steps

1. Go to **Configuration → System → Security → Security Service → Login Management**.
2. Select **Login Mode**.
 - **Login via User Name and Password**: The users can log in to the device by entering user name and password directly.
 - **Login via PIN Code, User Name, and Password**: In this mode, users can only log in to the device by entering PIN code, user name, and password to raise the security. You need to enable **Link to DN** and set the DN value when adding the user. When logging in to the device, you need to insert a USB flash drive including the ukey to the computer. Enter the set PIN code of the ukey in the popup window to log in.



Note

The computer should be equipped with the reading and writing permissions of the USB flash drive. After the USB flash drive is inserted to the computer, a service certificate should be applied.

3. Click **Save**.

13.10 Set IP Address Filtering

You can set the IP addresses allowable and not allowable to access the device.

Steps

1. Go to **Configuration → System → Security → Security Settings**.
2. Enable IP address filtering.
3. Set **Filtering Mode**.

Blocklist Mode

The added IP addresses are not allowed to access the device.

Allowlist Mode

The added IP addresses are allowed to access the device.

4. Click **Add**, enter the IP address, and click **OK**.
-



Note

The IP address only refers to the IPv4 address.

5. **Optional:** Edit, delete, or clear the added IP addresses.
6. Click **Save**.

13.11 Set HTTPS

13.11.1 Create and Install Self-signed Certificate

HTTPS is a network protocol that enables encrypted transmission and identity authentication, which improves the security of remote access.

Steps

1. Go to **Configuration → Network → Network Parameters → HTTPS**.
2. Select **Create Self-signed Certificate**.
3. Click **Create**.
4. Follow the prompt to enter **Country/Region, Domain/IP, Validity**, and other parameters.
5. Click **OK**.

Result

The device will install the self-signed certificate by default.

13.11.2 Install Authorized Certificate

If the demand for external access security is high, you can create and install authorized certificate via HTTPS protocol to ensure the data transmission security.

Steps

1. Go to **Configuration → Network → Network Parameters → HTTPS**.
2. Select **Create certificate request first and continue the installation**.
3. Click **Create**.
4. Follow the prompt to enter **Country/Region, Domain/IP, Validity**, and other parameters.
5. Click **Download** to download the certificate request and submit it to the trusted authority for signature.
6. Import certificate to the device.
 - Select **Signed certificate is available, start the installation directly**. Click **Browse** and **Install** to import the certificate to the device.
 - Select **Create the certificate request first and continue the installation**. Click **Browse** and **Install** to import the certificate to the device.
7. Click **Save**.

Chapter 14 Maintenance

14.1 View Device Information

Basic Information and Algorithms Library Version

Go to **Configuration → System → System Settings → Basic Information** to view the basic information and algorithms version of the device.

You can edit **Device Name** and **Device No.** The device No. is used to control the device. It is recommended to reserve the default value.

Device Status

Go to **Configuration → System → System Settings → Device Status** to view the device status, live view and arming status, and data upload monitoring.




Figure 14-1 Device Status

You can click **24h Data Monitoring**, and select the IP address of the picture upload server to view the data upload statistics in 24 hours. The statistics data will be cleared if the device is rebooted by default. You can enable **Flash Storage** and set **Flash Storage Days** to keep the statistics data not to be cleared when the device is rebooted within the set time.




Figure 14-2 24h Data Monitoring

14.2 Synchronize Time

Synchronize the device time when it is inconsistent with the actual time.

Steps

1. Go to **Configuration → System → System Settings → Time Settings**.
2. Select **Time Zone**.
3. Select **Sync Mode**.

NTP Time Sync.

Select it to synchronize the device time with that of the NTP server. Set **Server IP**, **NTP Port**, and **Interval**. Click **NTP Test** to test if the connection between the device and the server is normal.

Manual Time Sync.

Select it to synchronize the device time with that of the computer. Set time manually, or check **Sync. with computer time**.

SDK

If the remote host has been set for the device, select it to synchronize time via the remote host.

ONVIF

Select it to synchronize time via the third-party device.

No

Select it to disable time synchronization.

All

Select it, and you can select any mode above.

Satellite Time Sync.

Select it to synchronize the device time with that of the satellite. Set **Interval**.

PTP Time Sync.

Select it to synchronize time more accurately. Precision Time Protocol (PTP) is a protocol to synchronize clocks in a computer network, similar to NTP. NTP is accurate, under ten milliseconds. PTP, however, is accurate up to less than a microsecond and is measured in nanoseconds.



Note

The time synchronization modes vary with different models. The actual device prevails.

4. Click **Save.**

14.3 Set DST

If the region where the device is located adopts Daylight Saving Time (DST), you can set this function.

Steps

1. Go to **Configuration → System → System Settings → DST**.
2. Enable **DST**.
3. Set **Start Time**, **End Time**, and **DST Bias**.
4. Click **Save**.

14.4 Set Positioning

If a GPS peripheral device is connected to the RS-485 serial port of the device, the longitude and latitude information of the device can be positioned.

Before You Start

Connect a GPS peripheral device to the device.

Steps



Note

The function varies with different models. The actual device prevails.

1. Go to **Configuration → System → Peripheral Configuration → Positioning**.
2. Select **Positioning Mode** as **GPS**.
3. Set **Positioning Upload Interval**.

When the device is connected to the platform, the positioning information will be uploaded to the platform according to the set interval.

4. Click **Save**.

14.5 Download Debug Data

You can search and download the diagnostics information, video BAYER, capture picture BAYER, and capture picture YUV of the device to debug the device.

Steps

1. Go to **Configuration → System → Maintenance → Debug Data Download**.

Data Type

Up to 30 records of data can be collected once. The collection will stop automatically for the data exceeding the limit.

Data List

☐	No.	File Name	Downloading Progress
☐	1	logFile.bin	Not downloaded.
☐	2	otapDbg.bin	Not downloaded.
☐	3	diagnosedData.txt	Not downloaded.

Figure 14-3 Download Debug Data

2. Select **Data Type**.

Diagnostics Information

The diagnostics information includes kernel, status, version information, etc.

Video BAYER/Capture Picture BAYER

Go to **Configuration → Capture → Advanced → System Service** to select the bayer data types to be saved. Click **Start** to start collection, and click **Finish** to finish collection.

Capture Picture YUV

To collect the YUV data of the captured pictures. Click **Start** to start collection, and click **Finish** to finish collection.



Note

Up to 30 records of data can be collected once. The collection will stop automatically for the data exceeding the limit.

3. Click **Search** to search the data list.
4. Select the file(s) to be downloaded, and click **Download** to download the file(s). You can view the downloading progress.
5. **Optional:** Select the file(s) to be deleted, and click **Delete** to delete the file(s).

14.6 Search Log

Log helps to locate and troubleshoot problems.

Steps

1. Go to **Configuration → System → Maintenance → Log Search**.
2. Set search conditions.
3. Click **Configuration** to select the logs to be searched according to modules or enable system log service.
 - 1) Select the module(s) from the dropdown list of **Enable According to Module**.
 - 2) Enable the functions below.

Disable Log Automatically

Enable the function to disable the log automatically, and set **Auto Disabling Time**.

Enable System Log Service

The security audit logs refer to the security operation logs. You can search and analyze the security log files of the device so as to find out the illegal intrusion and troubleshoot the security events. Security audit logs can be saved on device internal storage. The log will be saved every half hour after device booting. Due to limited storage space, you are recommended to save the logs on a log server. Enter **IP Address** and **Port** of the log server.

- 3) Click **OK**.
4. Click **Search**.

The matched log files will be displayed on the log list.
5. **Optional:** Click **Export** to save the log files to your computer.

14.7 Enable Maintenance Service

If you want to realize remote camera maintenance and debug via the platform server, enable maintenance service and set the access mode.

Steps

- 1. Go to **Configuration → System → Maintenance → Maintenance Service**.
- 2. Enable maintenance service.

Maintenance Service

Agent Settings

Address Type

IPv4 Address

Port

Client Identifier

IPv4 Address

Client Identifier Type

Custom

Authentication Information

User Name

admin

Heartbeat Cycle (s)

120

Status

Offline

Password

End Time

2025-04-16 15:29:41

Protocol Settings

Add

No.	Name	Transfer Protocol	Client Target IP Address	Client Target Port	Max. Number of Simultaneous Accesses via Client	Operation
1	SSH	TCP			5	

Save

Figure 14-4 Maintenance Service

- 3. Set agent parameters.
 - 1) Select **Address Type**.
 - 2) Set the IP address/domain name and port of the agent.
 - 3) Select **Client Identifier Type** and set **Client Identifier** according to the actual supporting conditions of the camera. The identifier serves as a unique mark of the camera.
- 4. Set the authentication information.

User Name/Password

The user name and password of the camera for the authentication via the platform server access.

Heartbeat Cycle(s)

You are recommended to keep the default value.

End Time

The camera will disconnect with the platform server when reaching the set end time.

- 5. Set protocol parameters.
 - 1) Click **Add** to add a protocol.
 - 2) Set the corresponding parameters of the protocol.



You can login and access up to 5 cameras (clients) simultaneously via HTTP or SSH protocol.

- 6. Click **Save**.

What to do next

After settings, refresh the interface and check the authentication status of the camera. If the status is online, you can access and debug the camera via the platform server.

14.8 Reboot

When the device needs to be rebooted, reboot it via the software instead of cutting off the power directly.

Steps

1. Go to **Configuration → Upgrade & Maintenance → Device Maintenance** .
2. Click **Reboot**.
3. Click **OK** to reboot the device.



Note

You can also click  on the upper right corner of the interface to reboot the device.

14.9 Restore Parameters

When the device is abnormal caused by the incorrect set parameters, you can restore the parameters.

Steps

1. Go to **Configuration → Upgrade & Maintenance → Device Maintenance** .
2. Select the restoration mode.
 - Click **Restore**, and select the parameters to be saved instead of being restored. Click **OK**. Then the parameters except the IP parameters, user parameters, and the saved parameters will be restored to the default settings.
 - Click **Restore Factory Settings** and click **OK** to restore all the parameters to the factory settings.
3. Click **OK**.

14.10 Export Parameters

You can export the parameters of one device, and import them to another device to set the two devices with the same parameters.

Steps

1. Go to **Configuration → Upgrade & Maintenance → Backup and Import Parameters** .
2. Click **Export** after **Configuration Parameters**.
3. Set an encryption password, confirm the password, and click **OK**.



Note

The password is used for importing the configuration file of the current device to other devices.

4. Select the saving path, and enter the file name.
5. Click **Save**.

14.11 Import Configuration File

Import the configuration file of another device to the current device to set the same parameters.

Before You Start

Save the configuration file to the computer.

Steps



Caution

Importing configuration file is only available to the devices of the same model and same version.

1. Go to **Configuration → Upgrade & Maintenance → Backup and Import Parameters**.
2. Select **Importing Method**.



Note

If you select **Import Part**, check the parameters to be imported.

3. Click **Browse** to select the configuration file.
4. Click **Import**.
5. Enter the password which is set when the configuration file is exported, and click **OK**.
6. Click **OK** on the popup window.

Result

The parameters will be imported, and the device will reboot.

14.12 Upgrade

Upgrade the system when you need to update the device version.

Before You Start

- Update the plugin before upgrade.
- Prepare the upgrade file in .dav format.

Steps

1. Go to **Configuration → Upgrade & Maintenance → Device Upgrade**.
2. Click **Browse** to select the upgrade file.
3. Click **Upgrade**.
4. Click **OK** in the popup window.



Note

The upgrading process will take minutes. Do not power off the device. The device will restart automatically after upgrading. If the network condition is poor, it may take more time.

Result

The device will reboot automatically after upgrade.



See Far, Go Further