



User Manual

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.

- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
 Danger	Indicates a hazardous situation which, if not avoided, will or could result in death or serious injury.
 Caution	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 Note	Provides additional information to emphasize or supplement important points of the main text.

Safety Instruction

CLASS 1 LASER PRODUCT
IEC 60825-1:2014

CLASS 1 LASER PRODUCT

The product meets the requirements of Class 1 laser products. Class 1 Laser products that are safe during use, including long-term direct intrabeam viewing, even when exposure occurs while using telescopic optics.

CONTENTS

Chapter 1 Device Activation	1
1.1 Activate the Device via SADP	1
1.2 Activate the Device via Browser	1
1.3 Activate the Device via Local Client	2
Chapter 2 Local Client Operation Instructions	3
2.1 Signal	3
2.1.1 Parameter Settings	3
2.1.2 Real-Time Generation	3
2.1.3 Data Saving and Playback	4
2.2 Analysis	5
2.2.1 Spectrum	6
2.2.2 Spatial Intensity Map	7
2.3 Search alarm information	8
2.4 Unit Management	8
2.4.1 Add Unit	9
2.4.2 Edit Unit	9
2.4.3 Delete Unit	10
2.5 Sensitivity Management	10
2.6 System Settings	11
2.7 Download File	11
2.8 Help	11
Chapter 3 Web Client Operation Instructions	12
3.1 Alarm Record Display	12
3.1.1 Map Configuration	13
3.1.2 Function	15
3.2 Alarm Record	18
3.2.1 Alarm Statistics	18
3.2.2 Historical Alarm Record	21
3.3 Configuration	21
3.3.1 System	21
3.3.2 Network	23
3.3.3 Storage Settings	24
3.3.4 Optical Fiber Monitoring Settings	25
3.3.5 Upload Event Report	29
3.4 Maintenance and Security	29
3.4.1 Device Status	30
3.4.2 Fiber Monitoring	30
3.4.3 Restart	33
3.4.4 Upgrade	34
3.4.5 Backup and Reset	34
3.4.6 Search and Manage Log	35

3.4.7 Security Audit Log..... 35

3.4.8 Device Debugging..... 35

3.4.9 Login Management..... 36

Chapter 1 Device Activation

To protect the security and privacy of the user account and data, you should set a login password to activate the device when access the device via network.



Note

Refer to the user manual of the software client for the detailed information about the client software activation.

1.1 Activate the Device via SADP

Search and activate the online devices via SADP software.

Before You Start

Access www.hikvision.com to get SADP software to install.

Steps

1. Connect the device to network using the network cable.
2. Run SADP software to search the online devices.
3. Check **Device Status** from the device list, and select **Inactive** device.
4. Create and input the new password in the password field, and confirm the password.



Caution

We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

5. Click **OK**.

Device Status changes into **Active**.

6. Optional: Change the network parameters of the device in **Modify Network Parameters**.

1.2 Activate the Device via Browser

You can access and activate the device via the browser.

Steps

1. Connect the device to the PC using the network cables.
2. Change the IP address of the PC and device to the same segment.



Note

The default IP address of the device is 192.0.0.64. You can set the IP address of the PC from 192.0.0.2 to 192.0.0.254 (except 192.0.0.64). For example, you can set the IP address of the PC to 192.0.0.100.

3. Input **192.0.0.64** in the browser.

4. Set device activation password.



Caution

We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

5. Click **OK**.
6. Input the activation password to log in to the device.
7. Optional: Go to **Configuration** → **Network** → **Network Settings** → **TCP/IP** to change the IP address of the device to the same segment of your network.

1.3 Activate the Device via Local Client

Before You Start

Get the client software from the technical support, and install the client according to the prompts.

Steps

1. Connect the device to network using the network cable.
2. Run the client software and double click **Add Device**.
3. Input **192.0.0.64** and click **Add**.
4. Find your device IP in the left list, and double click to enter the device.
4. Input new password (admin password) and confirm the password.



Caution

We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including at least three of the following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.

Chapter 2 Local Client Operation Instructions

Local client is mainly used for debugging.

Double-click **Add Device** in the upper-left corner, enter the device IP address, and click **Add**. After adding, you can find the device IP address in the left list, and double-click to enter the debugging interface.

Click **Log In** in the upper-left corner, enter administrator user name and password, and click **OK** to log in to client.

You can view the interface without logging in to local client, but cannot edit the parameters. Logging in is not recommended for normal user. Please contact professionals to edit parameters.

2.1 Signal

Click **Signal** to enter the interface.




Figure 2-1 Signal Interface

2.1.1 Parameter Settings

The photoelectric parameters and frequency settings are usually debugged and set by technical support personnel, and are not recommended for change. The acquisition card parameters cannot be configured by default.

2.1.2 Real-Time Generation

Click **OK** in real-time generation. The right-side chart area starts to generate real-time signal charts (slab chart and spatial intensity chart). Click **Stop** to stop generating.

The dual-channel device can switch between channel 1 and channel 2.

X.min/X.max/Y.min/Y.max

Adjust the max. and min. value of X and Y axis, and click enter key on the keyboard to confirm.

Waterfall Chart




Figure 2-2 Waterfall Chart

The vertical axis is the time, and the horizontal axis is the unit.

As shown in the above figure, the unit 1 to 200 on the left have signals and the signals are normal, and the bottom noise on the right indicates that units above 200 have no signals.

The integrated horizontal stripe of bright spot on the left indicates vibration.

Power Spectrum




Figure 2-3 Power Spectrum

As shown in the above figure, the lower-level line segment on the left indicates that the signals of unit 1 to 200 are normal, and the bottom noise on the right indicates that units above 200 have no signal.

When there is vibration, the left line segment will fluctuate according to the vibration intensity.

2.1.3 Data Saving and Playback

Save data in a certain time period. You can read the power map data through playback.

Data Saving

1. Click **Save** in the **Data Storage**.
2. Select **Save Raw Data** and **Save Power Map Data** as needed in pop-up window.




Figure 2-4 Save File

Saving Type

Save Event: When alarms occur in the selected unit No. range, the system records alarm data of the unit and the four units before and after it.

Save Manually: The phase data in the selected unit No. range can be saved.

Saving Channel

Select the channel to save data.

Unit No.

The unit No. to save data cannot be 0.

Raw Data and Power Map Data

The power map data is a wave band graph generated in the graph. Only power map data can be played back in playback. The raw data is only for professional analysis.

3. Click **OK** to save the raw data. Click **OK** in the Real-Time Generation window to generate power map data after setting the condition.
4. When data saving needs to be ended:
 - To disable **Save Raw Data**, you can cancel the selected items.
 - To disable **Save Power Map Data**, you can cancel the selected item, click **OK** to close the window, or close the client.
5. Set the path to save the file to local.

Playback

1. Go to **Signal** → **Playback**, and click **Import**.
2. Select **Path** and set **Playback Rate (Milliseconds)**.
3. Click **OK**.
4. View data playback in playback interface.

2.2 Analysis

Click **Analysis** to enter the interface. View spectrogram and spatial intensity map.

2.2.1 Spectrum

Click **Start** to generate spectrogram, and click **Stop** to stop generating.
Two-channel device can switch channel 1 or channel 2.




Figure 2-5 Spectrogram (With Vibration)




Figure 2-6 Spectrogram (No Vibration)

The vertical axis of the left picture is frequency, and the horizontal axis is unit No.
The vertical axis of the right picture is relative time, and the horizontal axis is frequency.
As shown in the above picture, the unit 1 to 250 on the left have signals and the signals are normal, and the bottom noise on the right indicates that units above 250 have no signals.

2.2.2 Spatial Intensity Map

Click **Start** to generate space intensity map. Click **Stop** to stop generating.

Two-channel device can switch channel 1 or channel 2.




Figure 2-7 Spatial Intensity Map (Normal Signal)

The vertical axis of the left picture is the vibration amplitude, and the horizontal axis is the unit. The larger the vibration amplitude, the stronger the signal.

The right axis is relative time, and the horizontal axis is phase.

As shown in the above picture, the unit 1 to 1000 on the left have signals and the signals are normal, and the units above 1000 have no signals.

The space intensity map is mainly used to display signal strength. When there is vibration, the left map fluctuates slightly. The initial signal peak value of the device should be around unit 2500. If it is lower, the signal is weak.




Figure 2-8 Spatial Intensity (Weak Signal)

2.3 Search alarm information.

Click **Alarm Info Search** to enter the interface.
After setting the condition, click **Search**.

Alarm Confidence

After enabling AI switch in unit management, the system will automatically judge if the alarm is true or false. Validity1 indicates that the alarm event is more likely to be true. Validity0 indicates that the alarm event is more likely to be false.

The screenshot shows the 'Alarm Info Search' interface. On the left, there are search filters: 'Start Time' (2024-04-17 00:00:00), 'End Time' (2024-04-18 00:00:00), 'Unit No.' (1 to 10600), 'Alarm Confidence' (checked for Confidence 0 and Confidence 1), and 'Alarm Level' (checked for First-Level Alarm, Second-Level Alarm, and Third-Level Alarm). A red 'Search' button is at the bottom left. The main area is a table with columns: Unit No., Alarm Level, Alarm Time, Confidence, Handle Method, Longitude, and Latitude. The table is currently empty. At the bottom, there is a status bar showing 'Total Number of Alarms (Within Query Time): 0' and navigation buttons: 'Before', 'Next', 'Current 1', 'Page Jump', 'Page', and 'Go'.

Figure 2-9 Search Alarm Information

The unit No. of channel 1 shows the original unit No.
If the device is the dual-channel device, the unit No. of channel 2 shows 10000 + original unit No. For example, channel 1 unit No. 502 is shown as 502, and channel 2 unit No. 502 is shown as 10502.

2.4 Unit Management

Click **Unit Management** to enter the interface.
This interface is used to configure the fiber optic unit.

User Manual

The screenshot shows the 'Unit Management' tab in a software interface. At the top, there are tabs for 'Signal', 'Analysis', 'Alarm Info Search', 'Unit Management', 'Sensitivity Management', 'System Settings', 'Download File', and 'Help'. The version 'V2.0.0 build 20240229_20:28:' is displayed on the right. Below the tabs are buttons for 'Add', 'Batch Delete', and 'Batch Edit'. A dropdown menu labeled 'Channel1' is also present. The main area contains a table with 16 rows of unit data. The table has columns for 'Unit No.', 'Sensitivity', 'AI Switch', 'Alarm Switch', 'Unit Type', 'Longitude', 'Latitude', 'A', 'F1', 'F2', 'B', 'F3', and 'F4'. All units are of type 'Indoor Fence' and have a sensitivity of 1. The 'AI Switch' and 'Alarm Switch' are set to 'Off'. The 'Unit Type' column has a dropdown arrow. The bottom of the interface shows a 'Total' count of 600, navigation buttons for 'Home', 'Previous Page', 'Next Page', and 'Last Page', a 'Go' button, and a status bar indicating 'Current:1 Page Total:6 Pages'.

Unit No.	Sensitivity	AI Switch	Alarm Switch	Unit Type	Longitude	Latitude	A	F1	F2	B	F3	F4
1	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
2	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
3	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
4	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
5	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
6	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
7	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
8	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
9	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
10	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
11	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
12	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
13	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
14	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
15	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250
16	1	Off	Off	Indoor Fence	E120.22...	N30.210...	0	1	2	1	4	250

Figure 2-10 Unit Management

Channel 1 or channel 2 can be switched by dual-channel device.

2.4.1 Add Unit

Click **Add** to enter the unit parameters in the pop-up window, and click **OK** to add the unit.

Start Unit/End Unit

The system will automatically generate the unit within the range. For example, if the start unit is 1, and the end unit is 5, then it will add 5 units, 1, 2, 3, 4, and 5.

Max. number of units varies with device models.

Unit Type

Select the unit type as your needs.

Sensitivity

Only preset sensitivity can be selected. You can configure sensitivity in [2.5 Sensitivity Management](#) in advance

Alarm Switch

After enabling, the unit will alarm according to the triggering type

AI Switch

After enabling, the system judges alarm confidence according to smart algorithm. The system will automatically judge if the alarm is true or false. 1 means that the alarm event is likely to be true. 0 means that the alarm event is likely to be false. If the AI switch is disabled, the confidence level of the alarm will be 0 by default.

2.4.2 Edit Unit

Edit **AI Switch**, **Alarm Switch**, and **Unit Type** of a single unit in the list.

Or click **Batch Edit** to edit the units and parameters in the pop-up window. Click **OK**.


A screenshot of the 'Unit Batch Edit' dialog box. It features a title bar with a close button. The main area contains four input fields: 'Start Unit' and 'End Unit' are text boxes; 'Unit Type' and 'Sensitivity' are dropdown menus. To the right of these are two more dropdown menus labeled 'AI Switch' and 'Alarm Switch'. At the bottom right, there are two buttons: a red 'OK' button and a grey 'Close' button.

Figure 2-11 Batch Edit Unit

2.4.3 Delete Unit

Click **Batch Delete**, enter the **Start Unit** and **End Unit** to delete the units, and click **OK**.


A screenshot of the 'Unit Batch Delete' dialog box. It has a similar layout to the 'Batch Edit' dialog, with a title bar, 'Start Unit' and 'End Unit' text boxes, 'Unit Type' and 'Sensitivity' dropdown menus, and 'AI Switch' and 'Alarm Switch' dropdown menus. The 'OK' button is red, and the 'Close' button is grey.

Figure 2-12 Batch Delete Unit

2.5 Sensitivity Management

Click **Sensitivity Management** to enter the interface.

Double-click the data to edit.

I stands for intensity. N stands for number of times. T stands for duration (ms).

Recommended Sensitivity: Third-Level Alarm: I0.2/N10/T2000, Second-Level Alarm: I1/N30/T5000, First-Level Alarm: I3/N50/T10000.

Alarm Intensity: First-Level Alarm Intensity > Second -Level Alarm Intensity > Third -Level Alarm Intensity.

Signal

Analysis

Alarm Info Search

Unit Management

Sensitivity Management

System Settings

Download File

Help

V2.0.0 build 20240229_20:28:27

Sensitivity	Third-Level			Second-Level			First-Level		
	I	N	T	I	N	T	I	N	T
1	0.1	3	2000	1	3	5000	3	3	10000
2	0.1	5	2000	1	5	5000	3	5	10000
3	0.1	7	2000	1	7	5000	3	7	10000
4	0.1	10	2000	1	10	5000	3	10	10000
5	0.2	3	2000	1.1	3	5000	3.1	3	10000
6	0.2	5	2000	1.1	5	5000	3.1	5	10000
7	0.2	7	2000	1.1	7	5000	3.1	7	10000
8	0.2	10	2000	1.1	10	5000	3.1	10	10000
9	0.3	3	2000	1.2	3	5000	3.2	3	10000
10	0.3	5	2000	1.2	5	5000	3.2	5	10000
11	0.3	7	2000	1.2	7	5000	3.2	7	10000
12	0.3	10	2000	1.2	10	5000	3.2	10	10000
13	0.4	3	2000	1.3	3	5000	3.3	3	10000
14	0.4	5	2000	1.3	5	5000	3.3	5	10000
15	0.4	7	2000	1.3	7	5000	3.3	7	10000
16	0.4	10	2000	1.3	10	5000	3.3	10	10000

Figure 2-13 Sensitivity Management

2.6 System Settings

Click **System Settings** to enter the interface.

Enable **Web Service**.

Web page will not be available when web service is disabled.

2.7 Download File

Click **Download File** to enter the interface.

The system will automatically search the data file stored by the client, or click **Refresh**.

If the device is connected to USB flash disk/HDD, the selected data file can be downloaded to USB flash disk/HDD.

2.8 Help

Click **Help** to view **Open Source Software Licenses**.

Chapter 3 Web Client Operation Instructions

3.1 Alarm Record Display

The alarm display interface will pop up prompt according to the missing configuration, and you can click to go to the corresponding interface.




Figure 3-1 Fiber Monitoring Prompt

Go to [3.4.2 Fiber Monitoring](#) to set parameters when you see the prompt above.




Figure 3-2 Unit Management Prompt

Go to [Sensitivity Preset](#) to set sensitivity and [Unit Management](#) to set unit when you see the prompt above.




Figure 3-3 Edit Map Prompt

Go to [3.1.1 Map Configuration](#) to finish map configuration when you see the prompt above..

3.1.1 Map Configuration

Steps

1. The pop-up window will be displayed when you enter the display screen for the first time. Click the pop-up window.





Figure 3-4 Edit Map Prompt

Otherwise, click  **Edit Map** on the upper right, and click **Import Map Again**.

2. Import map according to pop-up prompt and wait for the map to load.




Figure 3-5 Map Imported

3. Click **+ Add Axis Point**, and then left click to generate the axis of the map. You can enter longitude, latitude, and altitude. If the information filled is incorrect, click  to delete the axis point.




Figure 3-6 Add Axis Point

4. Click **+ Add Axis Point** again. Repeat the previous step to generate the second point. Only two axis points can be added.




Figure 3-7 Add Second Axis Point

5. Click **Save and Next**.
6. Enter the fiber shape adjustment interface. Number of units is set in the Unit Management.




Figure 3-8 Adjust Fiber Shape

7. Drag the end point to adjust the fiber shape. Check **Select All Unit Points** to drag all the points together.
8. Click **Save and Exit**.

3.1.2 Function

Fiber Monitoring

The upper-left page is displayed with fiber monitoring.

The dual-channel device can switch between channel 1 and channel 2.

Power Spectrum

Display the power statistics of each unit.

As shown in the figure below, the lower-level segment on the left indicates that the signals of unit 1 to 500 are normal, and the bottom noise on the right indicates that units above 500 have no signals.




Figure 3-9 Power Spectrum

When there is vibration, the left part will fluctuate.




Figure 3-10 Power Spectrum (With Vibration)

Amplitude Curve

It is mainly used to check signal strength and whether the fiber is broken.

Under normal circumstances, it is fluctuating curve. If the fiber is broken, there is no curve. As shown in the following figure, the signals of unit 1 to 230 are normal (the vertical axis can be regarded as signal strength). Units above 230 have no signals.

You can see the broken unit through the amplitude curve.




Figure 3-11 Amplitude Curve

Alarm Statistics

The lower-left page shows alarm data.




Figure 3-12 Alarm Statistics

Alarm List

The screen on the right shows the alarm. You can select the handled alarms and unhandled alarms.





Figure 3-13 Alarm List

Click *Handle* to view alarm type, time, unit No., and alarm level in pop-up window. Please select true or false alarm in handle method.



The screenshot shows a 'Handle Alarm' dialog box with a close button (X) in the top right corner. It is divided into two main sections: 'Alarm Basic Information' and 'Handle Method'. The 'Alarm Basic Information' section contains a table with the following data:

Alarm Type	Time
Perimeter Alarm	2024/02/04 16:56:01
Unit No.	Alarm Level
2	Third-Level

The 'Handle Method' section contains the text 'Correct alarm or not?' followed by two radio button options: 'True Alarm' (which is selected) and 'False Alarm'. At the bottom of the dialog are two buttons: 'OK' (in a red box) and 'Cancel'.

Figure 3-14 Alarm Basic Information

Click **More Unhandled Alarms** to go to the historical alarm record page.



Smart algorithm and alarm handling are two parallel mechanisms. Whether the alarm confidence is 1 or 0, you should handle the alarm manually and set it as true or false.

Alarm Type

Perimeter Alarm

The fiber is vibrating. Check if there are people crossing.

The preset sensitivity is divided into first to third level. Unit No. refers to the alarm triggering location.

Fiber Cut Alarm

The fiber is broken and has no signal. The default alarm level is first-level. The unit No. is the position of the fiber cut closest to the start of the fiber.

3.2 Alarm Record

Click **Alarm Record** in the list on the left to enter the interface.

You can view alarm data.

3.2.1 Alarm Statistics

Go to **Alarm Record** → **Alarm Statistics** to enter the interface.

User Manual




Figure 3-15 Alarm Statistics

Alarm uploading information and today's alarm details are displayed in the upper side of the interface. Set the filter conditions on the left, click **Generate** to generate the alarm statistics chart on the right.

Note

Hover the cursor over the alarm statistics chart. Slide the roller to zoom in or out the statistics chart.

Chart Depending on Unit No.

In the statistics chart, the vertical axis is the alarm number, and the horizontal axis is the unit No. The number of alarms in each unit that meet the selected condition in start time and end time will be displayed.

Alarm Statistics Chart




Figure 3-16 Chart Depending on Unit No.

Chart Depending on Time

In the statistics chart, the vertical axis is the alarm number, and the horizontal axis is the time. The number of alarms that meet the selected condition will be displayed by time.

Alarm Statistics Chart




Figure 3-17 Chart Depending on Time

Alarm Confidence

After enabling smart algorithm in unit management, the system will automatically judge if the alarm is true or false. Validity1 indicates that the alarm event is more likely to be true. Validity0 indicates that the alarm event is more likely to be false.

3.2.2 Historical Alarm Record

Go to **Alarm Record** → **Historical Alarm Record** to enter the interface.

Start Time *

2024/02/05 00:00:00

End Time *

2024/02/05 23:59:59

Fiber Channel *

☒ Channel 1
 ☐ Channel 2

Unit No. of Channel 1 *

1 — 600

Unit No. of Channel 2 *

1 — 600

Alarm Level *

☒ First-Level Alarm
 ☒ Second-Level Alarm
 ☒ Third-Level Alarm

Handling Status *

☒ Unhandled
 ☒ Handled-True Alarm
 ☒ Handled-False Alarm

Alarm Type *

☒ Perimeter Alarm
 ☒ Fiber Cut Alarm

Alarm Confidence *

☒ Validity0
 ☒ Validity1

Search

Batch Handle Alarm

☐	Time	Alarm T...	Alarm L...	Unit No.	Longitude and Latitude	Altitude	Handling Status	Validity	Operation
☐	2024/02/05 11:42:28	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:42:18	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:42:08	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:41:48	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:41:28	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:40:58	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:40:48	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:40:38	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:40:28	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:40:18	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:40:08	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:39:58	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:39:48	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:39:38	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:39:18	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:39:08	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:38:58	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:38:48	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:38:38	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle
☐	2024/02/05 11:38:28	Perimeter Al...	Third-Level	2	+42.557, +3.841	0m	Unhandled	1	Handle

Figure 3-18 Historical Alarm Record

Set the filter conditions on the left, and click **Search** to search historical alarm records. You can handle unhandled alarms here. Select true or false alarm.

Alarm Confidence

After enabling smart algorithm in unit management, the system will automatically judge if the alarm is true or false. Validity1 indicates that the alarm event is more likely to be true. Validity0 indicates that the alarm event is more likely to be false.



Note

Smart algorithm and alarm handling are two parallel mechanisms. Whether the alarm confidence is 1 or 0, you should handle the alarm manually and set it as true or false.

3.3 Configuration

3.3.1 System

Basic Information

You can view device information, such as Model, Serial No. and Version.

Enter **Configuration** → **System** → **System Settings** → **Basic Information** to view the device information, and you

can edit device name.

Time Settings

Synchronize Time Manually

Steps

1. Go to **Configuration** → **System** → **System Settings** → **Time Settings**.
2. Select **Time Zone**.
3. Click **Manual**.
4. Choose one time synchronization method.
 - Select **Set Time**, and manually input or select date and time from the pop-up calendar.
 - Check **Sync With Computer Time** to synchronize the time of the device with that of the local PC.
5. Click **Save**.

Set NTP Server

You can use NTP server when accurate and reliable time source is required.

Before You Start

Set up a NTP server or obtain NTP server information.

Steps

1. Go to **Configuration** → **System** → **System Settings** → **Time Settings**.
2. Select **Time Zone**.
3. Click **NTP**.
4. Set **Server Address**, **NTP Port** and **Interval**.



Server Address is NTP server IP address.

5. Click **Test** to test server connection.
6. Click **Save**.

Set DST

If the region where the device is located adopts Daylight Saving Time (DST), you can set this function.

Steps

1. Go to **Configuration** → **System** → **System Settings** → **DST**.
2. Check to enable **DST**.
3. Select **Start Time**, **End Time** and **DST Bias**.
4. Click **Save**.

User Management

Add Users



Caution

To increase security of using the device on the network, please change the password of your account regularly. Changing the password every 3 months is recommended. If the device is used in high-risk environment, it is recommended that the password should be changed every month or week.

Steps

1. Go to **Configuration** → **System** → **User Management** → **User Management**.
2. Click **+Add**. Enter **User Name**, select **User Role**, and enter **Password** and **Confirm Password**. Assign remote permission to users based on needs.

Administrator

The administrator has the authority to all operations and can add installers and operators and assign permission.

Installer

The administrator can select whether to enable the installer, and whether to grant the installer permission to configure the parameters.

The default password of the Installer is setter12345. Please change password after initial login.

Operator

The administrator can select whether to grant the operator permission to configure the parameters.

3. Click **Save**.

Edit Users

Steps

1. Go to **Configuration** → **System** → **User Management** → **User Management**.
2. Click . Edit the information as your needs.
3. Click **Save**.

Delete User

- Click  to delete a single user.
- Select the user in the list. Click  **Delete** to delete the user in a batch.



Note

The administrator and Installer cannot be deleted.

Online Users

Go to **Configuration** → **System** → **User Management** → **Online Users** to view the list of online users.

3.3.2 Network

Network Settings

TCP/IP settings must be properly configured before you operate the device over network.

Steps

1. Go to **Configuration** → **Network** → **Basic Settings** → **TCP/IP**.
2. Select **Network ID**.
3. Enable **DHCP**, or manually input IPv4 parameters.

DHCP

The device automatically gets the IPv4 parameters from the network if you check **DHCP**. The device IP address is changed after enabling the function. You can use SADP to get the device IP address.

4. Click **Save**.

Network Service

The device port can be modified when the device cannot access the network due to port conflicts. For debuggers only.

Go to **Configuration** → **Network** → **Network Service** to enter the interface.

Device Access

The device can be accessed to the maintenance platform via OTAP protocol, in order to search and acquire device information, upload device status and alarm information, reboot and update the device.

Steps

1. Go to **Configuration** → **Network** → **Device Access** → **OTAP** to enable the function
2. Set related parameters.
3. Click **Test** to check if the device connects to server.
4. Click **Save**.

Result

Register Status turns to **Online** when the function is correctly set.

3.3.3 Storage Settings



Only certain models support the function.

Go to **Configuration** → **Storage** → **Storage Management** → **HDD Management**.

You can view the HDD capacity and status.

HDD Information




Figure 3-19 HDD Information

3.3.4 Optical Fiber Monitoring Settings

Unit Management

Go to **Configuration** → **Optical Fiber Monitoring Settings** → **Optical Fiber Unit** → **Unit Management** to enter the interface.

You can configure the fiber unit. Each unit should be 10 meters.

The screenshot shows the Unit Management interface. At the top, there are buttons for '+ Add', 'Delete', 'Batch Edit', 'Import', 'Export', and 'Batch Enable/Disable Alarm Swit...'. Below these are three dropdown menus: 'Channel 1', 'All Unit Type', and 'All Enable Status'. The main part of the interface is a table with the following columns: Unit No., Fiber Channel, Unit Name, Unit Type, Sensitivity, Longitude and Lati..., Alarm Switch Status, Enable Smart Algo..., and Operation. There are two rows of data in the table.

☐	Unit No.	Fiber Channel	Unit Name	Unit Type	Sensitivity	Longitude and Lati...	Alarm Switch Status	Enable Smart Algo...	Operation
☐	1	Channel1	uu22	Indoor Fence	Preset1	38.45995423,-1.481...	Enable	Enable	
☐	2	Channel1	32tt	Indoor Fence	Preset1	42.55720824,3.8415...	Enable	Enable	

Figure 3-20 Unit Management

Filter Display Unit

Set the condition bar on the right to select the unit to be displayed in the list.

The screenshot shows the filter bar at the top of the Unit Management interface. It consists of three dropdown menus: 'Channel 1', 'All Unit Type', and 'All Enable Status'.

Figure 3-21 Unit Condition

Single Add/Edit Unit

- Click **+ Add**, enter unit parameters in the pop-up window on the right, and click **Save** to add unit.
- Click to enter unit parameter in the pop-up window on the right, and click **Save** to edit the unit.

Add Unit No.

Max. number of units varies with device models
Unit No. in each channel is unique.

Unit Name

It can be duplicated.

Sensitivity

Only preset sensitivity can be selected. You can configure sensitivity in **Sensitivity Preset** in advance.

Longitude and Latitude

Enter the latitude and longitude of the unit.

Enable Alarm Switch

After enabling, the unit will alarm according to the triggering type.

Enable Smart Algorithm

After enabling, the system judges alarm confidence according to smart algorithm. The system will automatically judge if the alarm is true or false. 1 means that the alarm event is likely to be true. 0 means that the alarm event is likely to be false. If the smart algorithm is disabled, the confidence level of the alarm will be 0 by default.

Batch Add Unit/Import&Export Unit Data

1. Click **Import**.
2. Click **Download Template** in the pop-up window. Enter relevant parameters according to template.



Note

- The batch import will clear all the original unit information. Please operate with care.
 - The imported form template is English.
-

Figure 3-22 Batch Import

3. Click **Import**.
4. Select the completed template.
5. **Optional Operation:** Click **Export** to export the unit parameters. Only all unit parameters can be exported.

Batch Edit Unit

1. Select the unit in the list.
2. Click **Batch Edit**.
3. Edit the parameters to be edited in the pop-up window.
You can batch edit unit name, unit type, and sensitivity. You can also enable or disable alarm switches and smart algorithms in a batch.
4. Click **Save**.

Batch Edit Alarm Switch

Select the unit in the list. Click **Bath Enable/Disable Alarm Switches**. Select **Bath Enable the Above Units** or **Bath Disable the Above Units** in a pop-up window. Click **Save**.


Delete Unit

- Click  to delete the unit.
- Select the units, click  **Delete** , and delete them in a batch.

Sensitivity Preset

Go to **Configuration → Fiber Monitoring Configuration → Optical Fiber Unit → Sensitivity Preset** to enter the interface.

Click  to edit and save the parameters in the pop-up window.



Alarm Level	I *	N *	T *
First-Level Alarm	3	3	10000
Second-Level Alarm	1	3	5000
Third-Level Alarm	0.1	3	2000

Figure 3-23 Edit Sensitivity

I stands for intensity. N stands for number of times. T stands for duration (ms).

Recommended Sensitivity: Third-Level Alarm: I0.2/N10/T2000, Second-Level Alarm: I1/N30/T5000, First-Level Alarm: I3/N50/T10000.

Alarm Intensity: First-Level Alarm Intensity > Second -Level Alarm Intensity > Third -Level Alarm Intensity.

Optical Fiber Basic Information

Go to **Configuration → Optical Fiber Monitoring Settings → Optical Fiber Unit → Optical Fiber Basic Information** to enter the interface.

Select **Channel**, and enter the usage length and laying length. The system will read the actual length automatically.

Note

Only certain models support setting laying length.

The actual length depends on the fiber cut position.

Photoelectric Parameters Settings

 Note

Only certain models support the function.

Go to **Configuration → Optical Fiber Monitoring Settings → Photoelectric Parameters** to enter the interface.
You can view FBG parameters, pumping parameters and photoelectric parameters and set **VOA(Attenuator)**.

FBG(Grating)

Temperature

41.000000°C

TEC Current

16.66mA

Pumping Parameter

Pumping Current

282.899994mA

TEC Current

-166.600006mA

Pumping Temperature

24.799999°C

Photoelectric

Working Mode

ACC

Output Power

13dBm

Module Temperature

26.6°C

Set

VOA(Attenuator)

37493

⬆⬇⬆

Save

Figure 3-24 Photoelectric Parameters

Processor Settings

 Note

Only certain models support the function.

Go to **Configuration → Optical Fiber Monitoring Settings → Processor** to enter the interface.

EDFA

*Pumping Current

92.70

mA ⬆⬇⬆

Save

Figure 3-25 Processor Settings

EDFA is a optical fiber amplifier used to amplify the power of the optical fiber.

Pumping Current

The higher the current value, the higher the power of the optical fiber.

Acquisition Card Settings

Go to **Configuration → Optical Fiber Monitoring Settings → Acquisition Card** to enter the interface.
You can view data collection parameters and pulse modulation parameters.

The screenshot displays the 'Acquisition Card' settings interface. It is divided into two main sections: 'Data Collection Parameters' and 'Pulse Modulation Parameters'. Each section has a title bar with a right-pointing arrow. Under 'Data Collection Parameters', there are three rows: 'Sampling Rate' set to '250MHz', 'Number of Samples' set to '124800', and 'Frame' set to '128'. Under 'Pulse Modulation Parameters', there are three rows: 'Data Collection Frequency' set to '2KHz', 'Pulse Width' set to '100ns', and 'Center Frequency' set to '80MHz'.

Data Collection Parameters	
Sampling Rate	250MHz
Number of Samples	124800
Frame	128

Pulse Modulation Parameters	
Data Collection Frequency	2KHz
Pulse Width	100ns
Center Frequency	80MHz

Figure 3-26 Processor Settings

3.3.5 Upload Event Report

Go to **Configuration → Upload Event Report** to enter the interface.
Set **Alarm Confidence** and **Alarm Uploading Priority**.

Alarm Confidence

After enabling smart algorithm in unit management, the system will automatically judge if the alarm is true or false. 1 indicates that the alarm event is likely to be true. 0 indicates that the alarm event is likely to be false.

The screenshot shows the 'Upload Event Report' settings interface. It contains two main sections: 'Alarm Confidence' and 'Alarm Uploading Priority'. Each section has a title bar with an information icon (i) and a right-pointing arrow. Under 'Alarm Confidence', there are two rows: 'Validity0' and 'Validity1', both with checked checkboxes. Under 'Alarm Uploading Priority', there are three rows: 'First-Level Alarm', 'Second-Level Alarm', and 'Third-Level Alarm', all with checked checkboxes. At the bottom center, there is a red 'Save' button.

Alarm Confidence	
☒ Validity0	
☒ Validity1	

Alarm Uploading Priority	
☒ First-Level Alarm	
☒ Second-Level Alarm	
☒ Third-Level Alarm	

Save

Figure 3-27 Upload Event Report

3.4 Maintenance and Security

Go to **Maintenance and Security** to enter the interface.

You can view device status, fiber monitoring, log, etc. Reboot or debug the device.

3.4.1 Device Status

Go to **Maintenance and Security** → **Maintenance** → **Device Status** to enter the interface.

View device status, device network status, device temperature, acquisition card status, etc. Click **Configure** to enter configuration interface.



Note

The interface varies with models.




Figure 3-28 Device Status

3.4.2 Fiber Monitoring

Go to **Maintenance and Security** → **Maintenance** → **Fiber Monitoring** to enter the interface.

Hover the cursor over the chart to zoom in or out. Hold the left mouse button to drag the chart.

Dual-Channel device can switch channel to view the chart of different channels. Click  to display the chart in full screen.



Note

The interface varies with models.

Power Spectrum

Display the power statistics of each unit.

As shown in the figure below, the lower-level segment on the left indicates that the signals of unit 1 to 500 are normal, and the bottom noise on the right indicates that units above 500 have no signal.




Figure 3-29 Power Spectrum

When there is vibration, the left part will fluctuate.




Figure 3-30 Power Spectrum (With Vibration)

Waterfall Plot

The vertical axis is the time, and the horizontal axis is the unit. It shows vibration ranges in past time with two-dimensional figure.

As shown in the figure below, the unit 1 to 500 on the left have signals and the signals are normal, and the bottom noise on the right indicates that units above 500 have no signals.




Figure 3-31 Waterfall Plot

When there is vibration, a white vibration band will be displayed.




Figure 3-32 Waterfall Plot (With Vibration)

Amplitude Curve

It is mainly used to check signal strength and whether the fiber is broken.

Under normal circumstances, it is fluctuating curve. If the fiber is broken, there is no curve. As shown in the following figure, the signals of unit 1 to 230 are normal (the vertical axis can be regarded as signal strength). Units above 230 have no signals.

You can see the broken unit through the amplitude curve.




Figure 3-33 Amplitude Curve

Current Alarm

Display current alarm event and alarm unit.

Alarm Time	Alarm Unit Point
2024-02-06 13:04:56	2
2024-02-06 13:05:06	2
2024-02-06 13:05:16	2
2024-02-06 13:05:46	2
2024-02-06 13:05:56	2
2024-02-06 13:06:06	2
① If the unit point coordinates have been recorded, please go to the optical fiber unit management page to edit the unit point information. Go To Fiber Unit Managemen...	

Figure 3-34 Current Alarm

3.4.3 Restart

Go to **Maintenance and Security** → **Maintenance** → **Restart** to enter the interface.
You can restart the device manually.

Manually Reboot

Reboot Device

Restart

Figure 3-35 Restart

3.4.4 Upgrade

Go to **Maintenance and Security** → **Maintenance** → **Upgrade** to enter the interface.
You can view the current version, select the upgrade module and upgrade files to upgrade.

Current Version V1.0.5 build 240201_11:13:22

Local Upgrade

Upgrade Module

Controller

▼

Upgrade Files

📁

Upgrade

Figure 3-36 Upload

3.4.5 Backup and Reset

Go to **Maintenance and Security** → **Maintenance** → **Backup and Reset** to enter the interface.

Backup

Export Device Parameters

Export

Default

Restore to Default Settings

Restore

All data except network parameters and user accounts will be cleared.

Restore to Factory Settings

Restore All

All functions and parameters will be restored to factory settings.

Import Config. File

Device Parameters

📁

Import

Figure 3-37 Backup and Reset

- Export Device Parameters
- Click **Export** to export configuration file. The configuration file contains parameter information of the device.
- Restore to Default Settings
- Click **Restore**, all data except network parameters and user accounts will be cleared.
- Restore to Factory Settings
- Click **Restore All**, all functions and parameters will be restored to factory settings.
- Import Config. File
- Select the file address and click **Import** to import the configuration file from the local computer to the device.

3.4.6 Search and Manage Log

Log helps locate and troubleshoot problems.

Steps

1. Go to **Maintenance and Security** → **Maintenance** → **Log**.
2. Set search conditions, **Major Type**, **Minor Type**, **Start Time**, and **End Time**.
3. Click **Search**.

The matched log files will be displayed on the log list.

4. Optional Operation: Click **Export** to save the log files in your computer.

Major Type

Minor Type

Time

All Type

All Type

2024-01-02 00:00:00 - 2024-02-06 23:59:59

Search

Default

Export TXT

No.	Time	Major Type	Minor Type	Description
01	2024/02/06 13:55:47	Alarm	Perimeter Alarm	Unit:2, Channel:1
02	2024/02/06 13:55:37	Alarm	Perimeter Alarm	Unit:2, Channel:1
03	2024/02/06 13:55:07	Alarm	Perimeter Alarm	Unit:2, Channel:1
04	2024/02/06 13:54:57	Alarm	Perimeter Alarm	Unit:2, Channel:1
05	2024/02/06 13:54:37	Alarm	Perimeter Alarm	Unit:2, Channel:1
06	2024/02/06 13:54:27	Alarm	Perimeter Alarm	Unit:2, Channel:1
07	2024/02/06 13:54:07	Alarm	Perimeter Alarm	Unit:2, Channel:1
08	2024/02/06 13:53:37	Alarm	Perimeter Alarm	Unit:2, Channel:1
09	2024/02/06 13:53:27	Alarm	Perimeter Alarm	Unit:2, Channel:1
10	2024/02/06 13:52:57	Alarm	Perimeter Alarm	Unit:2, Channel:1
11	2024/02/06 13:52:47	Alarm	Perimeter Alarm	Unit:2, Channel:1
12	2024/02/06 13:52:17	Alarm	Perimeter Alarm	Unit:2, Channel:1
13	2024/02/06 13:52:07	Alarm	Perimeter Alarm	Unit:2, Channel:1
14	2024/02/06 13:51:57	Alarm	Perimeter Alarm	Unit:2, Channel:1

Figure 3-38 Log

3.4.7 Security Audit Log

Go to **Maintenance and Security** → **Maintenance** → **Security Audit Log** to enter the interface.

Enable **Enable Log Upload Server**, input **Log Server IP Address** and **Log Server Port**, and click **Save**.

Enable Log Upload Server

* Log Server IP Address

* Log Server Port

0

Save

Figure 3-39 Security Audit Log

3.4.8 Device Debugging

Go to **Maintenance and Security** → **Maintenance** → **Device Debugging** to enter the interface.

You can enable SSH for debugging. It is recommended to disable SSH during daily use.




Figure 3-40 Device Debugging

3.4.9 Login Management

It helps to improve the security when accessing the device via Internet.

Steps

1. Go to **Maintenance and Security** → **Security** → **Login Management** to enter the interface.
2. Enable **Illegal Login Lock**.
3. Set parameters.

Number of Error Attempts

When your login attempts with the wrong password reach the set times, the device is locked.

Lock Duration

The device releases the lock after the setting duration.


Illegal Login Lock ☒

* Number of Error Attempts

* Lock Duration s

Figure 3-41 Illegal Login Lock

4. Click **Save**.
5. Optional Operation: The user can be unlocked through the following operations.
 - Click  to unlock the locked user in the list.
 - Click  **Unlock All** to unlock all locked users.



See Far, Go Further