



DS-K6B630T(M)(E)X Series Swing Barrier

User Manual

Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss.

The precaution measure is divided into Dangers and Cautions:

Dangers: Neglecting any of the warnings may cause serious injury or death.

Cautions: Neglecting any of the cautions may cause injury or equipment damage.

	
Dangers: Follow these safeguards to prevent serious injury or death.	Cautions: Follow these precautions to prevent potential injury or material damage.

Danger:

- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region.
- The equipment must be connected to an earthed mains socket-outlet.
- Shock hazard! Disconnect all power sources before maintenance.
- Do not touch the bare metal contacts of the inlets after the circuit breaker is turned off. Electricity still exists.
- ⚡ indicates hazardous live and the external wiring connected to the terminals requires installation by an instructed person.
- This equipment is not suitable for use in locations where children are likely to be present.
- To prevent possible hearing damage, do not listen at high volume levels for long periods.
- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.
- Please use the power adapter, which is provided by normal company. The power consumption cannot be less than the required value.
- Do not connect several devices to one power adapter as adapter overload may cause over-heat or fire hazard.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
If the top caps should be open and the device should be powered on for maintenance, make sure:
 1. Power off the fan to prevent the operator from getting injured accidentally.
 2. Do not touch bare high-voltage components.
 3. Make sure the switch's wiring sequence is correct after maintenance.
- Please make sure that the power has been disconnected before you wire, install or dismantle the device.
- When the product is installed on wall or ceiling, the device shall be firmly fixed.

- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.
- Do not ingest battery, Chemical Burn Hazard.
This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.
Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- If the product does not work properly, please contact your dealer or the nearest service center. Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

Cautions:

- The equipment shall not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the equipment.
- Ensure correct wiring of the terminals for connection to an AC mains supply.
- The equipment has been designed, when required, modified for connection to an IT power distribution system.
- + identifies the positive terminal(s) of equipment which is used with, or generates direct current.
+ identifies the negative terminal(s) of equipment which is used with, or generates direct current.
- No naked flame sources, such as lighted candles, should be placed on the equipment.
- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc. The openings shall never be blocked by placing the equipment on a bed, sofa, rug or other similar surface.
- The serial port of the equipment is used for debugging only.
- Stainless steel may be corroded in some circumstances. You need to clean and care the device by using the stainless steel cleaner. It is suggested to clean the device every month.
- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).
- Do not place the device in extremely hot (refer to the specification of the device for the detailed operating temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.
- The device cover for indoor use shall be kept from rain and moisture.
- Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).
- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.
- Please use the provided glove when open up the device cover, avoid direct contact with the device cover, because the acidic sweat of the fingers may erode the surface coating of the device cover.

- Please use a soft and dry cloth when clean inside and outside surfaces of the device cover, do not use alkaline detergents.
- Please keep all wrappers after unpack them for future use. In case of any failure occurred, you need to return the device to the factory with the original wrapper. Transportation without the original wrapper may result in damage on the device and lead to additional costs.
- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufacturer.
- Biometric recognition products are not 100% applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.
- Do not stay in the lane when the device is rebooting.
- RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.
- SUITABLE FOR MOUNTING ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY.
- The instructions shall require connection of the equipment protective earthing conductor to the installation protective earthing conductor.

Contents

Chapter 1 Overview	1
1.1 Introduction	1
1.2 Main Features	1
Chapter 2 System Wiring	3
Chapter 3 Install Pedestals	5
Chapter 4 General Wiring	8
4.1 Components Introduction	8
4.2 Wiring Electric Supply	10
4.3 UART Description	13
4.4 Wiring	13
Chapter 5 Terminal Description	14
5.1 General Wiring	14
5.2 Main Control Board Terminal Description	14
5.3 Access Board	15
5.4 Alarm Input Wiring	18
5.5 Exit Button Wiring	19
Chapter 6 Device Settings via Button	20
6.1 Reset Device	20
Chapter 7 Activation	21
7.1 Activate via Web Browser	21
7.2 Activate via Mobile Web	22
7.3 Activate via SADP	23
Chapter 8 Configure Device via Mobile Web	25
8.1 Login	25
8.2 Overview	25
8.3 Configuration	28


8.3.1 Turnstile Basic Settings	28
8.3.2 Person Management	29
8.3.3 Keyfob Settings	31
8.3.4 Device Management	32
8.3.5 View Device Basic Information	34
8.3.6 Time Settings	34
8.3.7 User Management	36
8.3.8 Network	36
8.3.9 Sub Access Control Board Settings	40
8.3.10 Event Search	40
8.3.11 Audio Settings	41
8.3.12 Access Control Settings	42
8.3.13 Set Face Parameters	46
8.3.14 Set Palm Print Parameters	47
8.3.15 Set Face Mask Parameters	48
8.3.16 IR Detector Settings	49
8.3.17 People Counting Settings	49
8.3.18 Passing and Authentication Indicator Settings	50
8.3.19 Other Configurations	50
8.3.20 Upgrade and Maintenance	51
8.3.21 Device Debugging	52
8.3.22 View User Document	53
8.3.23 Open Source Software Licenses	54
8.3.24 Log Out	54
Chapter 9 Operation via Web Browser	55
9.1 Login	55
9.2 Forget Password	55
9.3 Quick Operation via Web Browser	55

9.3.1 Time Settings	55
9.3.2 Environment Settings	56
9.3.3 Privacy Settings	56
9.4 Person Management	57
9.5 Turnstile	58
9.5.1 Overview	58
9.5.2 Search Event	59
9.5.3 Paramenter Settings	60
9.5.4 Turnstile	70
9.6 System and Maintenance	78
9.6.1 View Device Information	78
9.6.2 Set Time	78
9.6.3 Change Administrator's Password	79
9.6.4 Online Users	79
9.6.5 View Device Arming/Disarming Information via PC Web	79
9.6.6 Network Settings	80
9.6.7 Set Video and Audio Parameters via PC Web	84
9.6.8 Set Image Parameters	85
9.6.9 Serial Port Settings	86
9.6.10 Preference Settings	87
9.6.11 Upgrade and Maintenance	90
9.6.12 Device Debugging	91
9.6.13 Test Protocol via PC Web	92
9.6.14 Set Network Penetration Service via PC Web	93
9.6.15 Component Status	93
9.6.16 View Log via PC Web	94
9.6.17 Advanced Settings via PC Web	94
9.6.18 Certificate Management	95

Chapter 10 Other Platforms to Configure	97
Appendix A. Event and Alarm Type	98
Appendix B. Legal Information	99

Chapter 1 Overview

1.1 Introduction



The swing barrier is designed to detect unauthorized passing from the entrance or exit. By adopting the swing barrier integratedly with the access control system, person should authenticate to pass through the lane via swiping IC or ID card, scanning QR code, etc. It is widely used in attractions, stadiums, construction sites, residences, etc.

1.2 Main Features

- 32-bit high-speed processor
- TCP/IP network communication
The communication data is specially encrypted to relieve the concern of privacy leak
- Permissions validation and anti-tailgating
- Remaining open/closed mode selectable
- Bidirectional (Entering/Exiting) lane

The barrier opening and closing speed can be configured according to the visitor flow

- The barrier will be locked or stop working when people are nipped
- Anti-forced-accessing

The barrier will be locked automatically without open-barrier signal. It can bear the force of up to 120 Nm

- Self-detection, Self-diagnostics, and automatic alarm
- Audible and visual alarm will be triggered when detecting intrusion, tailgating, reverse passing, and climbing over barrier
- Remote control and management
- Online/offline operation
- LED indicates the entrance/exit and passing status
- Barrier is in free status when powered down; If the device is installed with lithium battery (optional), the barrier remains open when powered down
- Fire alarm passing
When the fire alarm is triggered, the barrier will be open automatically for emergency evacuation
- Valid passing duration settings
System will cancel the passing permission if a person does not pass through the lane within the valid passing duration
- Opens/Closes barrier according to the schedule template
- Up to 3000 visitor cards and up to 60,000 cards except for visitor cards can be added
- Cross controller anti-passback

Chapter 2 System Wiring

The preparation before installation and general wiring.

Steps

1. Draw a central line on the installation surface of the left or right pedestal.
2. Draw other parallel lines for installing the other pedestals.



Note

The distance between the nearest two lines is $L+252$ mm.

3. Slot on the installation surface and drill installation holes after determining the hole positions.
Put 4 expansion bolts of M12*120 for each pedestal.




Figure 2-1 Hole Position Diagram

4. Bury cables.



Note

- High voltage: Middle lane 100-120V~/200-240V~, 50Hz/60Hz, 1.6A power input. Side lane: 100-240V~, 50Hz/60Hz, 0.8A power input.
 - Low voltage: network communication cable.
 - The inner diameter of the low voltage conduit and of the high voltage (AC power cord) conduit should be larger than 30 mm. If any high-power authentication device is required to install on the left pedestal, the diameter of its conduits should be larger.
 - If you want to bury both of the AC power cord and the low voltage cable, the two cables should be in separated conduits to avoid interference.
 - If more peripherals are required to connect, you should increase the conduit diameter or bury another conduit for the external cables.
 - The external AC power cord should be double-insulated.
 - The network cable must be CAT5e or other cables with better performance.
 - Before digging holes, evaluate the thickness of the installation surface to avoid puncturing.
-

Chapter 3 Install Pedestals

Before You Start


Prepare for the installation tools, check the device and the accessories, and clear the installation base.

Steps




Note

- Make sure the device is installed on flat surface. The foundation should be hard and the thickness should exceeds the length of the expansion bolt.
 - Make sure the device is powered off during installation and other operations.
 - The installation tools are put inside the package of the pedestal.
 - It is recommended to tear off the protective film after the device is installed.
 - Do not immerse the pedestal in the water.
 - If the installation area is close to the wall, make sure the distance between the pedestal and the wall should be more than 20 mm, or you might cause damage to the device or cannot open the pedestal's top panel.
 - If you knock on the expansion screw during installation, or when the wrench slips, it is easy to bump into the tempered glass and cause the glass to break.
 - The surface of the device is made of aluminum alloy, please pay attention to avoid scratching the surface with hard, sharp, or foreign objects, etc. When cleaning with a rag, avoid scratched surfaces such as hard grit.
 - If the device is prone to tipping over when installing a high barrier or a large barrier when the expansion screws are not fixed. The device can be leaned against the soft foam, or the expansion screws can be installed before installing the door wings.
 - The top cover can only be removed after the side cover is removed. The glass can only be removed after the side cover on both sides are removed. The glass is fragile, please place it firmly to avoid falling and bumping.
-



Front View



Side View

Unit: mm

Figure 3-1 Dimension

1. Prepare installation tools, check the components, and clean the installation base.
2. Align the pedestals with the pre-buried expansion bolts, and remove the bottom maintenance board.




Figure 3-2 Bottom Maintenance Board Position

3. Secure each pedestal with expansion bolts, and fix the maintenance board to its original position.

Chapter 4 General Wiring

Note

- When you should maintain or disassemble the high voltage modules, you should remove the entire high voltage modules and maintain it outside the turnstile. You should unplug the cables that connected to the peripherals before maintenance to avoid destroy of the device.
 - When disassembling the high voltage module, you should disconnect the power to avoid injury.
 - If only wiring is needed without maintenance, do not remove the high voltage modules.
 - The switch and the main lane control board are already connected. The 14 AWG cable to connect between the AC electric supply and the switch should be purchased separately.
-

4.1 Components Introduction

By default, basic components of the turnstile are connected well. The pedestals can communicate by wiring the interconnecting cables. And the turnstile supports wiring the AC electric supply for the whole system's power supply.

Note

The voltage fluctuation of the electric supply is between 100 VAC and 220 VAC, 50 to 60 Hz.

The picture displayed below describes each component's position on the turnstile.

Note

The diagram is for reference only.




Figure 4-1 Components Diagram

The picture displayed below describes the IR module and their corresponding number on the pedestal.




Figure 4-2 IR Module

4.2 Wiring Electric Supply

Wire electric supply with the switch in the pedestal. Terminal L and terminal N are on the switch, while terminal PE should connect to a ground wire (yellow and green wire).

Open bottom cover.





Figure 4-3 Open Bottom Cover



Note

- The cable bare part should be no more than 8 mm. It is suggested that you can immerse the bare part into the liquid tin. If possible, wear an insulation cap at the end of the bare cable. Make sure there's no bare copper or cable after the wiring.
 - The Terminal L and the Terminal N cannot be wired reversely. Do not wire the input and output terminal reversely.
 - To avoid people injury and device damage, when testing, the ground resistance of the equipotential points should not be larger than 2 Ω .
 - Use the device in conjunction with an UPS.
 - If the electric supply cannot be disconnected when replacing the motor, do not unscrew the customer's wire, and if you want to operate, make sure that the electric supply is disconnected.
-

4.3 UART Description

If the device is not installed with the card reader, QR code scanner, face recognition module, etc., you can use the reserved UARTs to wire.

The following picture describes the UARTs' position.




Figure 4-4 UART Description

4.4 Wiring

Scan the QR code to view the wiring guide video.



Chapter 5 Terminal Description

5.1 General Wiring

The general wiring of lane control board, access control board and optional board.





Figure 5-1 General Wiring

Note

- The power cable from power supply to the main lane control board has been connected. You will need to prepare the 14AWG power cable to connect the AC power input to power supply.
- Barrier opens at the entrance/exit: connect to BTN1/BTN2 and GND.

5.2 Main Control Board Terminal Description

The picture displayed below is the main control board diagram.



5.3 Access Board

Access board is mainly used for authority identification in places with high security levels such as public security or judicial place, external device accessing, and communication with the upper platform and lane controller.

Note

Only the main access board of the right pedestal contains SUB-1G antenna interface. Middle access board has no SUB-1G antenna interface.




Figure 5-2 Main Access Board




Figure 5-3 Sub Access Board

The wiring diagram of extended interface of access board is shown as follows.




Figure 5-4 Wring Diagram of BUS3 Interface

5.4 Alarm Input Wiring

On the main lane control board, you can wire the fire alarm input interface.




Figure 5-5 Remaining Open

5.5 Exit Button Wiring

You can view the exit button wiring diagram.




Figure 5-6 Exit Button Wiring

Chapter 6 Device Settings via Button

6.1 Reset Device

Steps

1. Hold the reset button.




Figure 6-1 Initialization Reset Position

2. Hold the reset button for 5 s, the device will beep twice (main access board only) and start restoring to factory settings.



Caution

The initialization of the device will restore all the parameters to the default setting and all the device events are deleted.



Note

Make sure no persons are in the lane when powering on the device.

The resetting is completed.

Chapter 7 Activation

You should activate the device before the first login. After powering on the device, the system will switch to Device Activation page.

Activation via the device, SADP tool and the client software are supported.

The default values of the device are as follows:

- The default IP address: 192.0.0.64
- The default port No.: 8000
- The default user name: admin

7.1 Activate via Web Browser

You can activate the device via the web browser.

Steps

1. Enter the device default IP address (192.0.0.64) in the address bar of the web browser, and press **Enter**.



Note

Make sure the device IP address and the computer's should be in the same IP segment.

2. Create a new password (admin password) and confirm the password.



Caution

- The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.
- Proper configuration of all passwords and other security settings is the responsibility of the service provider and/or end-user.
- Do not contain following characters in the password: the user name, 123, admin (case-insensitive), 4 or more continuously increasing or decreasing digits, or 4 or more consecutively repeated characters.
- Password cannot contain words such as hik, hkws, and hikvision (case insensitive).

3. Click **Activate**.

4. Edit the device IP address. You can edit the IP address via the SADP tool, the device, and the client software.

7.2 Activate via Mobile Web

You can activate the device via mobile web.

Steps

1. If device hotspot is disabled: Make sure your mobile phone and the device are connected to the same network. Place your phone to the NFC area and the device IP address will pop up, tap the address to go to the login page.
2. If device hotspot is enabled:
 - Android System: Place your phone to the NFC area and the name and password of the device hotspot will be obtained automatically. Confirm to connect, you will go to the login page.
 - iOS Ssystem: Enable the phone's Wi-Fi function, and connect to the current device's hotspot. After hotspot is connected, you will go to the login page.



Note

- Hotspot Name: AP_Serial No.
 - Hotspot Password: Device's Serial No.
-



Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.



Note

Characters containing admin and nimda are not supported to be set as activation password.

3. Create a new password (admin password) and confirm the password.
-



Caution

STRONG PASSWORD RECOMMENDED-We highly recommend you create a strong password of your own choosing (using a minimum of 8 characters, including upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you reset your password regularly, especially in the high security system, resetting the password monthly or weekly can better protect your product.



Note

Characters containing admin and nimda are not supported to be set as activation password.

4. Click **Activate**.
5. You can configure the turnstile basic parameters, keyfob settings, light settings, network settings, access control settings, etc.

- 1) Select the device.
- 2) Change the device IP address to the same subnet as your computer by either modifying the IP address manually or checking **Enable DHCP**.
- 3) Input the admin password and click **Modify** to activate your IP address modification.

Chapter 8 Configure Device via Mobile Web

8.1 Login

You can login via mobile browser.



Note

- Make sure the device is activated. For details, see the activation section.
 - Enable the device Wi-Fi function and set an IP for the device. Make sure the device and the mobile phone are in the same Wi-Fi. For details, see the Wi-Fi section.
-

Enter the device IP address in the address bar of the mobile browser and press Enter to enter the login page.

Or after enabling the device hotspot, you can search the device hotspot in the phone Wi-Fi settings page, enter the device activation password to enter the login page. For details, see the user manual.

Enter user name and device password, and tap **Login**.

8.2 Overview

You can view the device status, conduct remote control, etc.




Figure 8-1 Status and Quick Settings

You can view the device status. If there is exception, you can tap to view the component details. You can tap to fast enter the basic settings page, user page, keyfob page and network page batch device management page.




Figure 8-2 Remote Control

You can remotely control barrier by tap the icons.




Figure 8-3 Network Status and Basic Information

You can view network status, model, serial No. and firmware version, and you can tap to fast enter the basic information page.

8.3 Configuration

8.3.1 Turnstile Basic Settings

You can set the basic parameters of the turnstile.

Tap **Basic Settings** of the shortcut entry on the overview page or tap  → **Basic Settings** .




Figure 8-4 Turnstile Basic Parameters

Set **Lane Width**, **Barrier Height**, **Barrier Material**, **Opening Barrier Speed** and **Closing Barrier Speed**.

Tap **Regular Passing Settings** to set the entrance and exit's passing mode.

Tap **Lane Width Diagram** to view the device diagram.

Tap **Save**.

8.3.2 Person Management

Tap **Person** or tap  → **Person Management** to enter the page.

< Add Person Save

*Employee ID Please enter.

Name Please enter.

Long-Term Effective User ☐

Start Date 2024-08-07 00:00:00 >

End Date 2034-08-07 23:59:59 >

User Role Normal User >

Face Not added. >

Palm Print Not added. >

Card Not added. >

Figure 8-5 Person Management

Add Person Basic Information

On the person management page, tap +.
Create the person's employee ID, name, and select a user role.
Tap **Save**.

Add Face Picture

On the person management page, tap + → **Face**.
Tap +, take a picture or select a picture.
Tap **Save**.

Add Palm Print

On the person management page, tap + → **Palm Print** .

Tap +, and follow the instruction to add a palm print.

Tap **Save**.

Add Card

On the person management page, tap + → **Card**.

Tap +, enter the card No. and select a card property (type).

Tap **Save**.

Set Person Permission

On the person management page, tap +.

Enable **Long-Term Effective User** and set the start time and end time of the person.

Tap **Save**.

Edit Person

Edit the person information on the management page.

Tap a person and edit the information.

Tap **Save**.

8.3.3 Keyfob Settings

Tap **Keyfob** of the shortcut entry on the overview page.




Figure 8-6 Keyfob Settings

Tap **Management** to enter the page. Tap + → **Manually Add** to add a keyfob. Set keyfob's name, serial No. and remain open permission.

Tap **Save**.

8.3.4 Device Management

The mobile web can automatically detect online devices (main access controller) that are in the same network segment as the current mobile phone and automatically obtain the identified device information. You can view the model, activation status, IP, serial number, software version, gateway address, and IPv4 subnet mask of all devices in the same network segment. You can also view a single device's IP address of the main/sub access controller, synchronize the parameters with the sub access controller of the device, and edit the name of the main access controller of a the device. Batch network configuration, parameter synchronization, and device activation are also available for devices.

Tap **Batch Manage Devices** or tap  → **Device Management** → **Batch Manage Devices** to enter the page.

Inactivated Device

You can do the following operations for the inactivated devices.

Tap  and set the main access controller's network of the device. Enter the administrator's password and tap **OK**.

DHCP

If disable the function, you should manually set IPv4 address, IPv4 subnet mask, and IPv4 default gateway.

If enabled the function, the system will allocate IPv4 address, IPv4 subnet mask, and IPv4 default gateway.

IPv6 Mode

Manual

Manually set IPv6 address, IPv6 subnet prefix length, and IPv6 default gateway.

DHCP

The system will allocate IPv6 address, IPv6 subnet prefix length, and IPv6 default gateway.

Route Advertisement

A mechanism for automatic address configuration in the IPv6 protocol stack. The device can complete IPv6 address configuration as long as there are routers in the environment that can provide routing notification messages.

Click **View Route Advertisement** to view the IPv6 address list.

Activated Devices

You can do the following operations for the activated devices.

Click a device in the list. Tap **Network Settings**. You can view the main access controller and sub access controller's basic information and set the network. Enter the administrator's password and tap **OK**.

DHCP

If disable the function, you should manually set IPv4 address, IPv4 subnet mask, and IPv4 default gateway.

If enabled the function, the system will allocate IPv4 address, IPv4 subnet mask, and IPv4 default gateway.

IPv6 Mode

Manual

Manually set IPv6 address, IPv6 subnet prefix length, and IPv6 default gateway.

DHCP

The system will allocate IPv6 address, IPv6 subnet prefix length, and IPv6 default gateway.

Route Advertisement

A mechanism for automatic address configuration in the IPv6 protocol stack. The device can complete IPv6 address configuration as long as there are routers in the environment that can provide routing notification messages.

Click **View Route Advertisement** to view the IPv6 address list.

Click a device in the list. Tap **Sync Parameters**. You can synchronize the selected device with this device. Enter the administrator's password and tap **Confirm**.

Tap  and you can set the name of the main access controller of the device. Enter the administrator's password and tap **Save**.

Batch Settings

You can do the following batch operations for devices.

On the Activated page, tap **Set Network Parameters**. Select the devices that you need to set network, and tap **Set Network Parameters**. After network settings, tap **OK**.

DHCP

If disable the function, you should manually set IPv4 address, IPv4 subnet mask, and IPv4 default gateway.

If enabled the function, the system will allocate IPv4 address, IPv4 subnet mask, and IPv4 default gateway.

IPv6 Mode

Manual

Manually set IPv6 address, IPv6 subnet prefix length, and IPv6 default gateway.

DHCP

The system will allocate IPv6 address, IPv6 subnet prefix length, and IPv6 default gateway.

Route Advertisement

A mechanism for automatic address configuration in the IPv6 protocol stack. The device can complete IPv6 address configuration as long as there are routers in the environment that can provide routing notification messages.

Click **View Route Advertisement** to view the IPv6 address list.

On the Activated page, tap **Batch Parameters Sync**. Select the devices that you need to set network, and tap **Batch Parameters Sync**. You can synchronize the selected devices with this device. Enter administrator's password and tap **Confirm**.

On the Inactivated page, tap **Batch Activate**. Select the devices that you need to activate, and tap **Batch Activate**. Enter administrator's password and tap **Confirm**.

8.3.5 View Device Basic Information

You can view the device name, language, model, serial No., version, and Mac address, etc.

Tap  → **System Settings** → **Basic Information** .

You can change the device name.

You can view the device language, model, serial No., version, local RS-485 number, number of alarm input, number of alarm output, Mac address and factory information, etc.

Tap **Device Capacity** to view the quantity and capacity of person, face, card, event, and palm print.

Tap **Save**.

8.3.6 Time Settings

View current time and set the time zone.

Tap  → **System Settings** → **Time Settings** .

<

Time Settings

Save

Device Time

2023-09-07 18:50:17

Time Zone

(GMT+08:00) Beijing, Urumqi, Singapore, Perth >

Time Sync. Mode

Manual >

Set Time

2023-09-07 18:49:35 >

DST

Enable DST

Start Time

Apr First Sunday 02h

End Time

Oct Last Sunday 02h

DST Bias

30minute(s) >

Figure 8-7 Time Settings**Device Time**

You can view current time.

Time Zone

Select the time zone where the device is located from the drop-down list.

Time Sync. Mode**Manual**

By default, the device time should be synchronized manually. You can set the device time manually.

NTP

Set the NTP server's IP address, port No., and interval.

DST

Slide to enable DST, and set the start time, end time and DST bias.

Tap **Save**.

8.3.7 User Management

You can change user password.

Tap  → **User Management** on the home page.

Tap the user, enter the old password and create a new password, and confirm the password.

Tap **Save**.

8.3.8 Network

Wired Network

Set wired network.

Tap  → **Network Settings** → **TCP/IP** to enter the configuration page.

NIC Type

Select a NIC type from the drop-down list.

DHCP

If you disable the function, you should set the IPv4 address, IPv4 subnet mask, IPv4 default gateway, IPv6 mode, IPv6 address, IPv6 subnet prefix length, IPv6 default gateway.

If you enable the function, the system will allocate the IPv4 address, IPv4 subnet mask, the IPv4 default gateway automatically.

MAC Address and MTU

You can view the default MAC address and MTU.

IPv6 Mode

Route Advertisement

The IPv6 address is generated by combining the route advertisement and the device Mac address.



Note

Route advertisement mode requires the support from the router that the device is connected to.

Manual

Enter **IPv6 Address**, **IPv6 Subnet Mask**, and **IPv6 Default Gateway**. Consult the network administrator for required information.

DHCP

The IPv6 address is assigned by the server, router, or gateway.

DNS Server



Note

Only when DHCP is enabled can DNS server be set.

Set the preferred DNS server and the alternate DNS server according to your actual need.

Set Device Hotspot

After enabling the device hotspot, you can use the mobile phone to connect the hotspot and set.

On the home page, tap  → **Network Settings** → **Device Hotspot** .

Slide to **Enable Device Hotspot**, set hotspot's **Name**, enter password and confirm it. Tap **Save**.

Set Port Parameters

You can set the HTTP, HTTPS according to actual needs when accessing the device via network.

Tap  → **Network Service** → **HTTP(S)** to enter the setting page.

HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter **http://192.0.0.65:81** in the browser for login.

HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

Platform Access

Platform access provides you an option to manage the devices via platform.

Steps

1. Tap  → **Device Access** → **Hik-Connect** to enter the settings page.



Note

Hik-Connect is an application for mobile devices. With the App, you can view live image of the device, receive alarm notification and so on.

2. Slide to enable the function.
3. You can enable **Custom** to enter the server address.



Note

- 6 to 12 letters (a to z, A to Z) or numbers (0 to 9), case sensitive. You are recommended to use a combination of no less than 8 letters or numbers.

4. You can view **Register Status** and **Binding Status**.

5. You can tap **Bind An Account → View QR Code**, scan the QR code to bind an account.

6. Tap **Save** to enable the settings.

Set OTAP Protocol

You can access the device to the maintenance platform by OTAP protocol to realize searching and gaining device information, uploading device running status and exceptions, rebooting and upgrading.

Steps

1. Tap  → **Device Access** → **OTAP**.

The screenshot shows the OTAP configuration screen. At the top, there is a back arrow and the title 'OTAP'. Below this is a 'Select Central Group' dropdown menu currently showing '1'. Underneath is an 'Enable' toggle switch that is turned on (green). Following this are four input fields, each with a red asterisk indicating they are required: '* Server Address', '* Port' (which has the value '7660' entered), '* Device ID', and '* Encryption Key' (which has a series of dots for masking). Below these fields is a 'Register Status' section showing 'Offline' with a red 'x' icon. At the bottom of the form are two buttons: a blue 'Test' button and a large red 'Save' button.

Figure 8-8 OTAP

2. Select 1 or 2 from **Select Central Group**.
3. Slide **Enable**.
4. Set server address, port, device ID and encryption key.
5. Tap **Test**, and make sure the device can connect to the server and registration completed.
6. Tap **Save**.

Result

Refresh the web page or reboot the device to make sure the OTAP's **Register Status** turns to online.

Set Network Penetration Service

When the device is deployed on the LAN, penetration service can be enabled to achieve remote device management.

Steps

1. Tap  → **Device Access** → **Network Penetration Settings** to enter the configuration page.
2. Enable **Enable Penetration Service**.
3. Enter **Server IP Address** and **Server Port**.
4. Enter login **User** and **Password**.
5. Set **Heartbeat Timeout**. The range is 1 to 6000.
6. You can view **Online Status**. Click **Refresh** to view the latest status.
7. Tap **Save**.

8.3.9 Sub Access Control Board Settings

The mobile web automatically detects the sub access controller paired with the IP address of the current computer. You can view the information of the sub access controller of the device and set network parameters.

Steps

1. Tap  → **Device Management** → **Sub Access Control Board** .
2. Tap **Network Settings** and set the IP address, gateway address, subnet mask, and communication port. Enter the administrator's password and tap **Save**.
3. Tap **Device Details** and you can view the device name, language, model, serial No., version, and alarm input/output number.

8.3.10 Event Search

Tap  → **Event Search** .

<

Event Search

Search

Event Types

Access Control Event >

Major Type

All Type >

Sub Type

All Type >

Employee ID

Name

Card No.

Start Time

2024-01-17 00:00:00

End Time

2024-01-17 23:59:59

Figure 8-9 Event Search

Select event types, major type and sub type. Enter search conditions, including employee ID, name, card No., start time and end time. Tap **Search**.



Note

It supports searching for names within 128 digits.

The search results will be displayed in the list.

8.3.11 Audio Settings

You can enable or adjust the audio.

Tap  → **Audio**.

Enable **Enable Voice Prompt** according to actual needs. The device will prompt voice instructions. You can also adjust the output volume.

Tap **Save**.

8.3.12 Access Control Settings

Set Authentication Parameters

Set authentication parameters.

Steps

1. Tap  → **Access Control** → **Authentication Settings** .
2. After settings, tap **Save**.

Terminal

Select **Entrance** or **Exit** according to actual situation.

Terminal Type/Model

You can view the current terminal type and model.

Enable Authentication Device

If enable the function, you can authenticate credential on the terminal; or you cannot use credential to authenticate.

Authentication

Select an authentication mode according to your actual needs from the drop-down list.

Continuous Face Recognition Interval

You can set the interval between 2 continuous recognition of a same person during the authentication. In the configured interval, Person A can only recognized once. If another person (Person B) has recognized during the interval, Person A can recognized again.



Note

The recognition internal value ranges from 1 to 10.

Authentication Interval

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed. If there is another person authenticate in the configured interval, the person can authenticate again.

Palm Recognition Interval

You can set the palm authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication

will be failed. If there is another person authenticate in the configured interval, the person can authenticate again.

Alarm of Max. Failed Attempts/Max. Authentication Failed Attempts

Enable **Alarm of Max. Failed Attempts** and you can set the max. authentication failed attempts. When the authentication attempts reach the set value, the authentication will be failed and report to center.

Communication with Controller Every

When the access control device cannot connect with the card reader for longer than the set time, the card reader will turn offline automatically.

Set Door Parameters

You can set door name, open duration and exit button parameters.

Tap  → **Access Control** → **Door Parameters** .




Figure 8-10 Door Parameters

Select entrance or exit for configuration, configure **Name** and **Open Duration**, and select **Exit Button Type**.

Configure **Door Remain Open Duration with First Person**. The mode is applicable for the passing of groups of persons, such as visitors entering the scenic spots. After the set person passes through, the door will open for a set time and other persons can pass through without authentication.

Click **Save** to save the settings after the configuration.

Terminal Settings

Set the working mode.

Tap  → **Access Control** → **Terminal Parameters** to enter the settings page.




Figure 8-11 Terminal Parameters

Permission Free Mode

The device will not verify the person's permission, but only the person's validity period. If the person is in the validity period, the barrier will open.

You can enable **Verify Credential Locally**. After enabling the function, the device will only verify the person's permission without the schedule template, etc.

Access Control Mode

The device works normally and will verify the person's permission to open the barrier.

Remote Authentication

The device will upload the person's authentication information to the platform. The platform will judge to open the barrier or not.


Verify Credential Locally

The device will only verify the person's permission without the schedule template, etc.

Set Card Security

Configure cards for the device.

Tap  → **Access Control** → **Card Security** .



Card Security	
Enable NFC Card	☒
Enable M1 Card	☒
M1 Card Encryption	☐
*Sector	13
Enable EM Card	☒
Enable DESFire Card	☒
DESFire Card Read Content	☐
Enable FeliCa Card	☒
Save	

Figure 8-12 Card Security

Configure card parameters, and click **Save**.

Enable NFC Card

In order to prevent the mobile phone from getting the data of the access control, you can disable NFC card to increase the security level of the data.

Enable M1 Card

Enable M1 card and authenticating by presenting M1 card is available.

M1 Card Encryption

M1 card encryption can improve the security level of authentication.

Sector

Enable the function and set the encryption sector.



Note

It is recommended to encrypt sector 13.

Enable EM Card

Enable EM card and authenticating by presenting EM card is available.



Note

If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function

Enable DESFire Card

The device can read the data from DESFire card when enabling the DESFire card function.

DESFire Card Read Content

After enable the DESFire card content reading function, the device can read the DESFire card content.

Enable FeliCa Card

The device can read the data from FeliCa card when enabling the FeliCa card function.

8.3.13 Set Face Parameters

Tap  → **Smart** → **Face Recognition Parameters** to enter the configuration page.



Note

The functions vary according to different models. Refers to the actual device for details.

Click **Save** to save the settings after the configuration.

Terminal

Select **Entrance** or **Exit** as the terminal direction.

Face Anti-spoofing

Enable or disable the live face detection function. If enabling the function, the device can recognize whether the person is a live one or not.



Biometric recognition products are not completely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.

Live Face Detection Security Level

After enabling the face anti-spoofing function, you can set the matching security level when performing live face authentication.

Recognition Distance

Select the distance between the authenticating user and the device camera.

Application Mode

Select either others or indoor according to actual environment.

1:1 Matching Threshold

Set the matching threshold when authenticating via 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

1:N Matching Threshold

Set the matching threshold when authenticating via 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face Recognition Timeout Value

Set the timeout value when face recognizing. If the face recognition time is longer than the configured value, the system will pop up a prompt.

8.3.14 Set Palm Print Parameters

Steps

1. Tap  → **Smart** → **Palm Print Recognition Parameters** to enter the configuration page.



The functions vary according to different models. Refers to the actual device for details.

2. Set the palm print parameters.

Terminal

Select a direction of the terminal.

Palm Print 1:1 Threshold

Set the matching threshold when authenticating via 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Palm Print 1:1 Match Threshold (ECO)

Set the matching threshold when authenticating via ECO mode 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Palm Print 1:N Match Threshold (ECO)

Set the matching threshold when authenticating via ECO mode 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate

3. Click **Save** to save the settings after the configuration.

8.3.15 Set Face Mask Parameters

After enabling the face without mask detection, the system will recognize the face with mask or not.

Steps

1. Tap  → **Smart** → **Face Mask Detection Parameters** to enter the configuration page.



Note

The functions vary according to different models. Refers to the actual device for details.

2. After enabling the face with mask detection, the system will recognize the face with mask or not.

Terminal

Select **Entrance** or **Exit** as the terminal direction.

Face with Mask Detection

Enable the function and the device will detect the person whether wearing a face mask or not.

Face with Mask & Face (1:1)

Set the matching value when authenticating with face mask via 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face with Mask 1:N Matching Threshold

Set the matching threshold when authenticating with face mask via 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face without Mask Strategy

Select a strategy when detect person not wearing a face mask.

None

The function is disabled. The device will not detect whether a person is wearing a face mask or not.

Reminder of Wearing Face Mask

If the person do not wear the face mask when authenticating, the device will pop up a prompt and the door will open.

Must Wear Face Mask

If the person do not wear the face mask when authenticating, the device will pop up a prompt and the door will keep closed.

3. Click **Save**.

8.3.16 IR Detector Settings

Set the IR detector parameters.

Steps

1. Tap  → **IR Detector Settings** to enter the configuration page.
2. Set **Inductive Mode (Entrance)** and **Inductive Mode (Exit)**.
3. You can customize IR detector.

Exceptional IR Auto Shield

If the IR detector is damaged, the IR detector can be shielded to temporarily restore the lane to use, but it may cause injury to passers-by when the barrier is open and closed.



Note

Exceptional IR auto shield function is a short-term shield. If there is no exception for 1 hour, it will restore.

IR Emergency Mode

If some IR beams do not work properly, you can shield those IR beams to restore the lane. But this action may hit person and cause injury.

Enable Custom Anti-pinch for Door Closing

Anti-pinch for door closing is used when the device detects that there are still people staying in the lane when the barrier closes, the barrier will not close. The barrier will close only when the person has completely exited the lane. When you enable the function, you can shield some IR detectors, so that the barrier can be closed in advance after people pass, but it may injure passers-by when the barrier is open and closed.

It is recommended to enable the function.

4. Tap **Save**.

8.3.17 People Counting Settings

Set people counting.

Steps

1. Tap  → **People Counting Settings** to enter the configuration page.
2. Enable **People Counting**, and the devcie will count passing person's number.
3. Enable **Device Offline People Counting**, and the device will count people numbers even if it is offline.
4. Enable **Passing Event Record**, and the device will upload each person's passing event.

5. Set **Person Statistics Type**.

Invalid

Disable people counting.

Passing Detection

The number of all passing people.

Authentication Number

The number of passing people verified through card swiping, face recognition, etc.

6. Set **Passing Direction** and you can set the passing direction of the device.

7. Tap **Clear** to clear all people counting information.

8. Tap **Save**.

8.3.18 Passing and Authentication Indicator Settings

Set the passing and authentication indicator's light brightness.

Tap  → **Light** → **Passing and Auth. Indicator** to enter the configuration page.

Set **Light Brightness** as **Auto** or **Manual**. If select **Manual**, you should move the block to adjust the brightness.

8.3.19 Other Configurations

Tap  → **Other Settings** .

Set the basic parameters.

Alarm Output Duration

Set duration as 0 means remaining output.

Temperature Unit

Select temperature unit.

Do Not Open Barrier When Lane is Not Clear

When enabled, the barrier will not open when people is authenticated in the lane.

Lightboard Brightness

Drag the block or enter the value to adjust the brightness. The larger the value, the brighter the light becomes.

Barrier Closing Delay

After a person passes through the lane, the barrier will close after the set time period.

Intrusion Duration

If a person mistakenly enters the lane for more than the set time, or if the person passes longer than the set time, the device will start alarming.

Overstaying Duration

If someone or something is detected to be stuck in the lane for more than the set time, the device will start alarming.

IR Obstructed Duration

If the infrared target is obstructed for more than the set time, the device will start alarming. 0 indicates that the function is not enabled.

Anti-Passback Rule

Set the anti-passback rule as **By Authentication Status** or **By Passing Status**.

By Authentication Status

The person should pass the authentication or the anti-passback will be failed.

By Passing Status

The person cannot pass the authentication and the anti-passback will be completed.

Memory Mode

You can Slide **Enable** memory mode. Multiple cards presenting for multiple person passing is allowable when enabling the memory mode. When the passing person's number exceeds the card presenting number, or after the latest person passing with no other person passing within the door open duration, the door will close automatically.

Control Mode

Soft Mode

The barrier will be closed after the person has passed through the barrier when there are tailgating, forced accessing, etc.

Guard Mode

The barrier will be closed immediately when there are tailgating, forced accessing, etc.

Fire Input Type

You can set the signal as **Remain Closed** or **Remain Open**. In the remain open state, closing triggers fire protection. In the remain closed state, disconnection triggers fire protection.

Invert Entrance and Exit Direction

If enable the function, the entrance and exit direction will be inverted.

Barrier Open Angle

Tap **Barrier Open Angle** and set the angle. The barrier can open the configured angle.



Note

You can set the angle between 85° and 91°. 0.1° is the minimum adjust unit.

Tap **Saveto** enable the settings.

8.3.20 Upgrade and Maintenance

Restart device, restore device parameters, and upgrade device version.

Restart Device

Tap  → **Restart** .

Tap **Restart** to restart the device.

Upgrade

Tap  → **Upgrade** .

Tap **Upgrade** to upgrade the device.



Note

Do not power off during the upgrading.

Restore Parameters

Tap  → **Default** .

Restore to Default Settings

The device will restore to the default settings, except for the device IP address and the user information.

Restore to Factory Settings

All parameters will be restored to the factory settings. You should activate the device before usage.

Log Export

Tap  → **Log Export** .

Select the log type, and tap **Export** to download the maintenance log.

8.3.21 Device Debugging

You can finish studying and self-test, and manage the debugging.

Tap  → **Device Debugging** .

Lane Studying/Motor Self-Test

Lane Studying

Tap **Lane Studying**, and the device will enter the studying mode. It will study the closed position of the barrier.

Motor Self-Test

Tap **Motor Self-Test**, and the device motor will start self-test.

Encoder Self-Test

1. Select a lane and start encode test.
2. Make sure the barrier is in the close position. Tap **OK**.

3. Rotate the barrier to the open position. Tap **Stop Testing**.
4. Wait for the result.

IR Self-Test

Select a channel (lane) and tap **IR Self-Test**, the device will test all IR detectors. After enabling IR self-test function, the device will sound to exit the channel (lane) before opening/closing. The barrier is forced to open in entrance/exit at the highest speed, at this time IR anti-pinch is defunct. If IR is triggered or blocked, the device will sound detection failure.



Note

Make sure there are no person in the lane.

Debugging Command Management

Select a command type and select the command or tap the command manually. Tap **Send**. The command will send to the device.

When the command is complete, you can see the result in the page.

Tap **End Debugging** to finish the debugging.



Note

If you do not tap End Debugging, the device will end the debugging mode within 7×24 hours automatically.

IR Exception Info.

Tap **Export** to export the exceptional IR detectors reports.

Demo Mode

After enabled, the device will automatically add and authenticate after face recognition.

You can set the validity period.

If disabled, all person information added in the demo mode will be cleared after disabled.

8.3.22 View User Document

View the user document.



Note

Only when you enter the mobile web by IP address, can you view the user document. Login by hot spot does not support the function.

Tap  to enter the page.

Tap **View Online Document** to view the user manual.

8.3.23 Open Source Software Licenses

You can view the open source software licenses.

Tap  to enter the page.

Tap **Open Source Software Licenses**.

8.3.24 Log Out

Log out the configuration page.

Tap  → **Logout** , tap **OK**.

If you need to enter the configuration page, you need to enter the user name and password again.

Chapter 9 Operation via Web Browser

9.1 Login

You can login via the web browser or the remote configuration of the client software.



Note

Make sure the device is activated.

Login via Web Browser

Enter the device IP address in the address bar of the web browser and press **Enter** to enter the login page.

Enter the device user name and the password. Click **Login**.

Login via Remote Configuration of Client Software

Download and open the client software. After adding the device, click  to enter the Configuration page.

9.2 Forget Password

If you forget the password when logging in, you can change the password by email address or security questions.

On the login page, click **Forget Password**.

Select **Verification Mode**.

Security Question Verification

Answer the security questions.

E-mail Verification

1. Export the QR code and send it to ***pw_recovery@hikvision.com*** as attachment.
2. You will receive a verification code within 5 minutes in your reserved email.
3. Enter the verification code into the verification code field to verify your identification.

Click **Next**, create a new password and confirm it.

9.3 Quick Operation via Web Browser

9.3.1 Time Settings

Click  in the top right of the web page to enter the wizard page.

Device Time

Display the device time in real time.

Time Zone

Select the device located time zone from the drop-down list.

Time Synchronization Mode

NTP

You should set the NTP server's IP address, port No., and interval.

Manual

By default, the device time should be synchronized manually. You can set the device time manually or check **Sync. with Computer Time** to synchronize the device time with the computer's time.

DST

You can enable DST, set and view the DST start time, end time and bias time.

Click **Next** to save the settings and go to the next parameter. Or click **Skip** to skip time settings.

9.3.2 Environment Settings

After activating the device, you should select an application mode for better device application.

Steps

1. Click  in the top right of the web page to enter the wizard page. After setting device language and time, you can click **Next** to enter the **Environment Settings** page.
2. Select **Indoor** or **Other**.



Note

- If you install the device indoors near the window or the face recognition function is not working well, select **Others**.
- If you do not configure the application mode and tap **Next**, the system will select **Indoor** by default.
- If you activate the device via other tools remotely, the system will select **Indoor** as the application mode by default.

Click **Next** to save the settings and go to the next parameter. Or click **Skip** to skip environment settings.

9.3.3 Privacy Settings

Set the picture uploading and storage parameters.

Click  in the top right of the web page to enter the wizard page. After setting time and environment, you can click **Next** to enter the **Privacy Settings** page.

Picture Uploading and Storage

Save Picture When Auth.

Save picture when authenticating automatically.

Upload Picture When Auth.

Upload the pictures when authenticating to the platform automatically.

Save Registered Picture

The registered face picture will be saved to the system if you enable the function.

Upload Picture After Linked Capture

Upload the pictures captured by linked camera to the platform automatically.

Save Pictures After Linked Capture

If you enable this function, you can save the picture captured by linked camera to the device.

Click **Complete** to finish settings.

9.4 Person Management

You can add the person's information, including the basic information, certificate, authentication and settings.

Add Basic Information

Click **Person Management** → **Add** to enter the Add Person page.

Add the person's basic information, including the employee ID, the person's name, and person type.

If you select **Visitor** as the person type, you can set the visit times.

Click **Save** to save the settings.

Set Permission Time

Click **Person Management** → **Add** to enter the Add Person page.

Enable **Long-Term Effective User**, or set **Start Time** and **End Time** and the person can only has the permission within the configured time period according to your actual needs.

Click **Save** to save the settings.

Add Face Picture

Click **Person Management** → **Add** to enter the Add Person page.

Click + on the right to upload a face picture from the local PC.



Note

The picture format should be JPG or JPEG or PNG, and the size should be less than 200 K.

Click **Save** to save the settings.

Add Card

Click **Person Management** → **Add** to enter the Add Person page.

Click **Add Card**, enter the **Card No.** and select the **Property**, and click **Save** to add the card.

Click **Save** to save the settings.

Add Paml Print

Click **Person Management** → **Add** to enter the Add Person page.

Click **+Add Palm Print** and follow the instructions to add palm print on the device.

Click **Save** to save the settings.

Authentication Settings

Click **Person Management** → **Add** to enter the Add Person page.

Set **Authentication Type** as **Same as Device** or **Custom**.

Click **Save** to save the settings.

Import/Export Person Data

Click **Person Management** to enter the Person page.

Export Person Data

You can export added person data for back-up or importing to other devices.

Click **Export Person Data**, set an encryption password and confirm it. Click **OK**.



Note

- The person data will be downloaded to your PC.
 - The password you set will be required for importing the data file.
-

Importing Person Data

Click **Importing Person Data** and select the file. Click **Import**.

Enter the encryption password to import and synchronize the person data to devices.

Clear All/Clear Palm Prints

Click **Person Management** to enter the Person page.

Click **Clear All** and all persons in the page will be deleted.

Click **Clear Palm Prints** and all palm prints of the persons in the page will be deleted.

9.5 Turnstile

9.5.1 Overview

You can view the device component status, real-time event, person information, network status, basic information, and device capacity. You can also control the barrier remotely.

Function Descriptions:

Device Component Status

You can check if the device is working properly. Click **View More** to view the detailed component status.

Remote Control

 /  /  / 

The door is opened/closed/remaining open/remaining closed.

Real-Time Event

You can view the event Employee ID, Name, Card No., Event Type, Time, and Operation. You can also click **View More** to enter the search conditions, including the event type, employee ID, the name, the card No., the start time, and the end time, and click **Search**. The results will be displayed on the right panel.

Person Information

You can view the added and not added information of person, face, card, and palm print.

Network Status

You can view the network connection status.

Basic Information


You can view the model, serial No. and firmware version.

Device Capacity

You can view the person, face, card, event, palm print capacity.

9.5.2 Search Event

Click **Turnstile → Event Search** to enter the page.



The form is titled 'Search Event' and contains several input fields and buttons. It is organized vertically. The first three fields are dropdown menus for 'Event Types', 'Major Type', and 'Sub Type', each with a downward arrow icon. Below these are three text input fields for 'Employee ID', 'Name', and 'Card No.'. The 'Name' field has a small grey button with a double left arrow icon to its right. Next are two date-time pickers for 'Start Time' and 'End Time', each showing a date and time and a calendar icon. Below these are four buttons: 'Yes...', 'Today', 'Cur...', and 'Cur...'. At the bottom is a large red button labeled 'Search'.

Event Types
Access Control Event

Major Type
All Type

Sub Type
All Type

Employee ID

Name

Card No.

Start Time
2024-06-17 00:00:00

End Time
2024-06-17 23:59:59

Yes... Today Cur... Cur...

Search

Figure 9-1 Search Event


Enter the search conditions, including the event type, major and sub type, the employee ID, the name, the card No., the start time, and the end time, and click **Search**.

The results will be displayed on the right panel.

9.5.3 Paramenter Settings

Set Door Parameters

Click **Turnstile** → **Parameter Settings** → **Door Parameters** .



Door No. Entrance Exit

Door Name

Open Duration s  

 Exit Button Type ☐ Remain Closed ☒ Remain Open

Door Remain Open Duration with First Person min  

Figure 9-2 Door Parameters Settings

Set the parameters and click **Save** to save the settings after the configuration.

Door No.

Select **Entrance** or **Exit** for settings.

Door Name

You can create a name for the door.

Open Duration

Set the door unlocking duration. If the door is not opened for the set time, the door will be locked.



Note

The open duration ranges from 5 s to 60 s.

Exit Button Type

You can set the exit button as **Remain Open** or **Remain Closed** according to your actual needs. By default, it is **Remain Open**.

Door Remain Open Duration with First Person

Set the door open duration when first person is in. After the first person is authorized, it allows multiple persons access the door or other authentication actions.

Set Authentication Parameters

Click **Configuration** → **Access Control** → **Authentication Settings** .



Note

The functions vary according to different models. Refers to the actual device for details.

Card Reader Parameter Configuration

Terminal

Entrance

Exit

Terminal Type

Terminal Model

Enable Authentication Device

① Recognition Interval

4

s

① Authentication Interval

0

s

① Alarm of Max. Failed Attem...

Palm Recognition Interval

1

s

Communication with Controller ...

10

s

Authentication Plan Configuration

Authentication

Card

Face ...

Face

Card/...

Card/...

>>

Clear

...

	00	02	04	06	08	10	12	14	16	18	20	22	24
Sun													
Mon													
Tue													
Wed													
Thu													
Fri													
Sat													

The selected authentication mode should be supported by card reader.

Figure 9-3 Set Authentication Parameters

Click **Save** to save the settings after the configuration.

Terminal/Terminal Type/Terminal Model

Get terminal description. They are read-only.

Enable Authentication Device

Enable the authentication function.

Authentication

Select an authentication mode according to your actual needs from the drop-down list.

Continuous Face Recognition Interval

You can set the interval between 2 continuous recognition of a same person during the authentication. In the configured interval, Person A can only recognized once. If another person (Person B) has recognized during the interval, Person A can recognized again.

Authentication Interval

You can set the authentication interval of the same person when authenticating. The same person can only authenticate once in the configured interval. A second authentication will be failed.

Alarm of Max. Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Max. Authentication Failed Attempts

Enable to report alarm when the card reading attempts reach the set value.

Tampering Detection

Enable the anti-tamper detection for the card reader.

Card No. Reversing

The read card No. will be in reverse sequence after enabling the function.

Set Smart Parameters

Set Basic Parameters

Click **Turnstile** → **Parameter Settings** → **Smart** .



Note

The functions vary according to different models. Refers to the actual device for details.

Click **Save** to save the settings after the configuration.

Terminal

Select a direction.

Face Recognition

After enabling, the device will support face recognition.

Face Recognition Parameters

Face Anti-Spoofing

Enable or disable the live face detection function. If enabling the function, the device can recognize whether the person is a live one or not.



Note

Biometric recognition products are not absolutely applicable to anti-spoofing environments. If you require a higher security level, use multiple authentication modes.

Anti-Spoofing Detection Level

After enabling the face anti-spoofing function, you can set the matching security level when performing live face authentication.

Recognition Distance

Select the distance between the authenticating user and the device camera.

Application Mode

Select either other or indoor according to actual environment.

Pitch Angle

The maximum pitch angle when starting face authentication.

Yaw Angle

The maximum yaw angle when starting face authentication.

1:1 Matching Threshold

Set the matching threshold when authenticating via 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

1:N Matching Threshold

Set the matching threshold when authenticating via 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face Recognition Timeout Value

Set the timeout value when face recognizing. If the face recognition time is longer than the configured value, the system will pop up a prompt.

Face Recognition Area

Click **Area Configuration**. Select terminal at entrance or exit, and enter values for the left, right, top, and bottom margin to adjust the recognition area. Only the face within the area can be recognized by the system.

Palm Print Recognition Parameters

Palm Print 1:1 Threshold

Set the matching threshold when authenticating via 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Palm Print 1:N Threshold

Set the matching threshold when authenticating via 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Palm Print 1:1 Match Threshold (ECO)

Set the matching threshold when authenticating via ECO mode 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Palm Print 1:N Match Threshold (ECO)

Set the matching threshold when authenticating via ECO mode 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

ECO Mode Parameter

ECO Mode

After enabling the ECO mode, the device will use the IR camera to authenticate faces in the low light or dark environment. And you can set the ECO mode threshold, ECO mode (1:N), and ECO mode (1:1).

ECO Mode Threshold

The larger the value, the device enter the ECO Mode easier.

ECO Mode (1:1) Threshold

Set the matching threshold when authenticating via ECO mode 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

ECO Mode (1:N) Threshold

Set the matching threshold when authenticating via ECO mode 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face Mask Detection Parameter

Face with Mask Detection

After enabling the face without mask detection, the system will recognize the captured face with mask picture or not. You can set face with mask 1:N matching threshold, it's ECO mode, and the strategy.

None

The function is disabled. The device will not detect whether a person is wearing a face mask or not.

Reminder of Wearing Face Mask

If the person do not wear the face mask when authenticating, the device will pop up a prompt and the door will open.

Must Wear Face Mask

If the person do not wear the face mask when authenticating, the device will pop up a prompt and the door will keep closed.

Face with Mask & Face (1:1)

Set the matching value when authenticating with face mask via 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face with Mask 1:N Matching Threshold

Set the matching threshold when authenticating with face mask via 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face with Mask & Face 1:1 Matching Threshold (ECO)

Set the matching value when authenticating with face mask via ECO mode 1:1 matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Face with Mask & Face 1:N Matching Threshold (ECO)

Set the matching threshold when authenticating with face mask via ECO mode 1:N matching mode. The larger the value, the smaller the false accept rate and the larger the false rejection rate.

Card Settings

Set Card Type

Click **Turnstile** → **Parameter Settings** → **Card Settings** to enter the settings page.

Set the parameters and click **Save**.

Enable NFC Card

In order to prevent the mobile phone from getting the data of the access control, you can disable NFC card to increase the security level of the data.

Enable M1 Card

Enable M1 card and authenticating by presenting M1 card is available.

M1 Card Encryption

Sector

M1 card encryption can improve the security level of authentication.

Enable the function and set the encryption sector. By default, Sector 13 is encrypted. It is recommended to encrypt sector 13.

Enable EM Card

Enable EM card and authenticating by presenting EM card is available.



Note

If the peripheral card reader supports presenting EM card, the function is also supported to enable/disable the EM card function.

Enable DESFire Card

The device can read the data from DESFire card when enabling the DESFire card function.

DESFire Card Read Content

After enable the DESFire card content reading function, the device can read the DESFire card content.

Enable FeliCa Card

The device can read the data from FeliCa card when enabling the FeliCa card function.

Set Card No. Authentication Parameters

Set the card reading content when authenticate via card on the device.

Go to **Turnstile → Parameter Settings → Card Settings** .

Select a card authentication mode and click **Save**.

Card Authentication Mode

Full Card No.

All card No. will be read.

Wiegand 26 (3 bytes)

The device will read card via Wiegand 26 protocol (read 3 bytes).

Wiegand 34 (4 bytes)

The device will read card via Wiegand 34 protocol (read 4 bytes).

Corporate1000_35/Corporate1000_48/H10302_37/10304_37/H103130_332CSN/ Wiegand_56CSN/Wiegand_58

The device will read card via the other mode.

Enable Reversed Card No.

The read card No. will be in reverse sequence after enabling the function.

Event Linkage

Set linked actions for events.

Steps

1. Click **Turnstile → Parameter Settings → Linkage Settings** to enter the settings page.

General Linka...

Add New Event and Card ...

Event Source

Linkage Type ☒ Event Linkage
☐ Card Linkage
☐ Link Employee ID

Event Types Device Event No Memory Alarm for Unreports

Linkage Action

Buzzer Linkage ☐

Door Linkage ☐

Linked Alarm Output ☐

Linkage Audio Prompt ☐

Save

Figure 9-4 Event Linkage

2. Click + to set event source.

- If you choose **Linkage Type** as **Event Linkage**, you need to select event types from the drop-down list.
- If you choose **Linkage Type** as **Card Linkage**, you need to enter the card No. and select the card reader.
- If you choose **Linkage Type** as **Employee ID Linkage**, you need to enter the employee ID and select the card reader.

3. Set linkage action.

Door Linkage

Enable **Door Linkage**, and set the door status **Entrance** and **Exit** for the target event.

Linked Alarm Output

Enable **Linked Alarm Output**, check **Alarm Output 1** or **Alarm Output 2**, and set the alarm output status for the target event.

Linked Audio Prompt

Enable **Linked Audio Prompt** and select the play mode.

- If you choose **TTS**, you need to set language and enter the prompt content.
- If you choose **Audio File**, you need to select an available audio file from the drop-down list or click **General Linkage Settings** to add a new audio file.

Linked Capture

Enable **Linked Capture** and select entrance or exit to capture for the target event.

Set Terminal Parameters

You can set terminal parameters for accessing.

Click **Turnstile → Parameter Settings → Terminal Parameters** .

You can set **Working Mode** as **Permission Free Mode** or **Access Control Mode**.

Permission Free Mode

The device only judge your credential is in the valid duration, and will not authenticate the permission.

Enable **Remote Verification → Verify Credential Locally** , the device will check permission but not estimate the plan template.

Access Control Mode

The access control mode is the device normal mode. You should authenticate your credential for accessing.

You can enable **Remote Verification** according to your actual needs. After enabling, you can verify remotely. And you can enable **Verify Credential Locally** according to your actual needs.

Click **Save** to save the settings after the configuration.

Set Privacy Parameters

Set the event storage type, picture upload and storage parameters, and the picture clearing parameters.

Click **Turnstile → Parameter Settings → Privacy Settings** .

Event Storage Settings

Select a method to delete the event. The device supports **Overwriting**.

Overwriting

The earliest 5% events will be deleted when the system detects the stored events has been over 95% of the full space.

Authentication Settings

Display Authentication Result

You can check **Face Picture**, **Name**, and **Employee ID**, to display the authentication result.

Name De-identification

You can enable **Name De-identification**, and the whole name will not be displayed.

ID De-identification

You can enable **ID De-identification**, and the whole employee ID will not be displayed.

Picture Uploading and Storage

Save Picture When Auth.

Save picture when authenticating automatically.

Upload Picture When Auth.

Upload the pictures when authenticating to the platform automatically.

Save Registered Picture

The registered face picture will be saved to the system if you enable the function.

Upload Picture After Linked Capture

Upload the pictures captured by linked camera to the platform automatically.

Store Palm Print Registered Picture

The registered palm print picture will be saved to the system if you enable the function.

Clear All Pictures in Device



Note

All pictures cannot be restored once they are deleted.

Clear Registered Face Pictures

All registered pictures in the device will be deleted.

Clear Captured Pictures

All captured pictures in the device will be deleted.

Clear All Palm Print Pictures

All palm print pictures in the device will be deleted.

9.5.4 Turnstile

Basic Parameters

Set turnstile basic parameters.

Steps

1. Click **Turnstile** → **Turnstile Configuration** → **Basic Parameters** to enter the page.

Channel Type Swing Barrier

Channel Model 

Barrier Material Glass 

Lane Width 550 

Barrier Height 700 

Barrier Opening Speed  10 

Barrier Closing Speed  4 

Working Status Normal

Passing Mode ☒ General Passing ☐ Weekly Schedule

Entrance Inductive 

Exit Inductive 

Figure 9-5 Basic Parameters

2. View the **Channel Type**, **Channel Model** and **Working Status**.
3. Set **Barrier Material**, **Lane Width**, **Barrier Height**, **Barrier Opening Speed** and **Barrier Closing Speed** according to your actual needs.
4. Set the passing mode.
 - If you choose **General Passing**, you can select the barrier status for the entrance and exit from the drop-down list.
 - If you choose **Weekly Schedule**, you can set a weekly schedule for entrance and exit barriers.
5. Set **Entrance** and **Exit** status.

Controlled

The barrier is controlled, the person should authenticate the credential to pass.

Inductive

When a person is walking through the lane, the barrier will be detected and open the barrier.

Remain Open/Closed

The barrier will remain open or closed whenever the person's authentication result is passed or denied.

Barrier-Free

The barrier will open all the time.

6. Click **Save**.

Keyfob Settings

Set keyfob parameters.

Steps

1. Click **Turnstile** → **Turnstile Configuration** → **Keyfob Configuration** to enter the page.

Keyfob + Add Delete

☐	Name	No.	Operation
☐	1	123456	

Save

Figure 9-6 Keyfob Settings

2. Add keyfob.

1) Click **Add** and the keyfob adding window will pop up.

2) Enter the **Name** and **Serial No.**.

3) Click **Add** to add the keyfob.

3. **Optional:** Select a keyfob and click **Delete** to delete the keyfob.

4. Click **Save**.

IR Detector

Set IR detector.

Steps

1. Click **Configuration** → **Turnstile** → **IR Detector** to enter the page.

Inductive Mode (Entrance) ☒ Single Trigger ☐ Trigger Simultaneously

Inductive Mode (Exit) ☒ Single Trigger ☐ Trigger Simultaneously

Exceptional IR Auto Shield ☐ ( Represents the exceptional IR detector is automatically disabled.)

Custom IR Detector ☐ Enable IR Emergency Mode ⓘ ☐ Enable Custom Anti-pinch for Door Closing ⓘ ( is anti-pinch detector. Do not disable at will.)

Save

Figure 9-7 IR Detector

- Set the entrance and exit inductive mode as **Single Triggered** or **Triggered Simultaneously**.
- Enable **Exceptional IR Auto Shield**. If the IR detector is damaged, the IR detector can be shielded to temporarily restore the lane to use, but it may cause injury to passers-by when the barrier is open and closed.



Note

Exceptional IR auto shield function is a short-term shield. If there is no exception for 1 hour, it will restore.

-
- Set custom IR detector mode.

Enable IR Emergency Mode

If some IR beams do not work properly, you can shield those IR beams to restore the lane. But this action may hit person and cause injury.

Enable Custom Anti-pinch for Door Closing

Anti-pinch for door closing refers that the barrier will not close if the device has detected person in the lane. Only after the person walks out of the lane, the barrier will close. If you enable the function, you can shield parts of the IR beams for closing barrier in advance. But this action may hit person and cause injury.

- Click **Save**.

People Counting

Set people counting.

Steps

- Click **Turnstile** → **Turnstile Configuration** → **People Counting Settings** to enter the page.

People Counting ☒

Device Offline People Counting ☒

Passing Event Record ☐

Person Statistics Type ☐ Invalid ☒ Passing Detection ☐ Authentication Number

Passing Direction Entrance Exit

People Counting 2

People Counting Clear

Save

Figure 9-8 People Counting

2. Set people counting parameters and click **Save**.

People Counting

Enable the function and set the parameters.

Device Offline People Counting

The device will count people numbers even if it is offline.

Passing Event Record

The device will report passing event to the platform when people passing.

People Statistics Type

Invalid

Disable people counting.

Passing Detection

The number of all passing people.

Authentication Number

The number of passing people verified through card swiping, etc.

Passing Direction

Select the device passing direction according to actual needs.

People Counting


View the people counting number and you can also click **Clear** to clear all data.

Set Light

Set the light brightness when authentication of the device.

Steps

1. Click **Turnstile** → **Turnstile Configuration** → **Light Settings** to enter the page.



Authentication Indicator

Light Brightness ☐ Auto ☒ Fixed Brightness

40

Save

Figure 9-9 Light Settings

2. Set **Light Brightness** as **Auto** or **Fixed Brightness**. If you choose **Fixed Brightness**, you can drag the block or enter the value to adjust the light brightness manually.
3. Click **Save**.

Other Settings

Set other parameters.

Steps

1. Click **Turnstile** → **Turnstile Configuration** → **Other Settings** to enter the page.

① * Alarm Output 1 Duration s

① * Alarm Output 2 Duration s

① * Alarm Output 3 Duration s

① * Alarm Output 4 Duration s

Do Not Open Barrier When Lan... ☐

Light Board Brightness 30

* Barrier Closing Delay ms

* Intrusion Duration ms

* Overstaying Duration s

* IR Obstructed Duration s

Anti-Passback Rule ☒ By Authentication Status ☐ By Passing Status

① Memory Mode ☒

Control Mode ☒ Soft Mode ① ☐ Guard Mode ①

Fire Input Type ☐ Remain Closed ☒ Remain Open

Invert Entrance and Exit Direction ☐

[More v](#)

Figure 9-10 Other Settings Page

2. Set parameters.

Alarm Output Duration

The alarm output duration ranges from 0 s to 3599 s. 0 indicates continuous output.

Temperature Unit

Select unit.

Do Not Open Barrier When Lane is Not Clear

When enabled, the barrier will not open when people is authenticated in the lane.

Light Board Brightness

Drag the block or enter the value to adjust the brightness. The larger the value, the brighter the light becomes.

Barrier Closing Delay

After a person passes through the lane, the barrier will close after the set time period.

Intrusion Duration

If a person mistakenly enters the lane for more than the set time, or if the person passes longer than the set time, the device will start alarming.

Overstaying Duration

If someone or something is detected to be stuck in the lane for more than the set time, the device will start alarming.

IR Obstructed Duration

If the infrared target is obstructed for more than the set time, the device will start alarming. 0 indicates that the function is not enabled.

Anti-Passback Rule

Set the anti-passback rule as **By Authentication Status** or **By Passing Status**.

By Authentication Status

The person should pass the authentication or the anti-passback will be failed.

By Passing Status

The person cannot pass the authentication and the anti-passback will be completed.

Memory Mode

Multiple cards presenting for multiple person passing is allowable when enabling the memory mode. When the passing person's number exceeds the card presenting number, or after the latest person passing with no other person passing within the door open duration, the door will close automatically.

Control Mode

Soft Mode: The barrier will be closed after the person has passed through the barrier when there are tailgating, forced accessing, etc.

Guard Mode: The barrier will be closed immediately when there are tailgating, forced accessing, etc.

Fire Input Type

In the normally open state, closing triggers fire protection. In the normally closed state, disconnection triggers fire protection.

Invert Entrance and Exit Direction

If enable the function, the entrance and exit direction will be inverted.

3. Click **More** to adjust **Barrier Open Angle**.

4. Click **Save**.

9.6 System and Maintenance

You can view the system information and the capacity. You can also upgrade the device, restore to factory settings, restore to default settings, and reboot the device.

9.6.1 View Device Information

View the device name, language, model, serial No., version, number of channels, IO input, IO output, alarm input, alarm output, and device capacity, etc.

Click **System and Maintenance** → **System Configuration** → **System** → **System Settings** → **Basic Information** to enter the configuration page.

You can view the language, model, serial No., version, IO input, IO output, alarm input and alarm output number.

You can change **Device Name** and click **Save**.

Click **Upgrade** to upgrade the firmware version.

You can view the device capacity, including person, face, card, event, and palm print.

9.6.2 Set Time

Set the device's time zone, synchronization mode, server address, NTP port, and interval.

Click **System and Maintenance** → **System Configuration** → **System** → **System Settings** → **Time Settings** .

Device Time 2024-06-17 19:57:14

Time Zone (GMT+08:00) Beijing, Urumqi, Singapore, Perth

Time Synchronization mode ☐ NTP ☒ Manual

Set Time 2024-06-17 19:56:52 Sync With Com...

DST ☐

Figure 9-11 Time Settings

Click **Save** to save the settings after the configuration.

Time Zone

Select the device located time zone from the drop-down list.

Time Sync.

NTP

You should set the NTP server's IP address, port No., and interval.

Manual

By default, the device time should be synchronized manually. You can set the device time manually or check **Sync. with Computer Time** to synchronize the device time with the computer's time.

DST

You can set the DST start time, end time and bias time.

9.6.3 Change Administrator's Password

Steps

1. Enter the password change page.
 - Click **System and Maintenance** → **System Configuration** → **System** → **User Management** → **User Management** and click .
 - Click **admin** → **Modify Password** at the upper right corner of the page.
2. Enter the old password and create a new password.
3. Confirm the new password.
4. Click **Save**.



Caution

The password strength of the device can be automatically checked. We highly recommend you change the password of your own choosing (using a minimum of 8 characters, including at least three kinds of following categories: upper case letters, lower case letters, numbers, and special characters) in order to increase the security of your product. And we recommend you change your password regularly, especially in the high security system, changing the password monthly or weekly can better protect your product.

Proper configuration of all passwords and other security settings is the responsibility of the service provider and/or end-user.

9.6.4 Online Users

The information of users logging into the device is shown.

Go to **System and Maintenance** → **System Configuration** → **System** → **User Management** → **Online User** to view the list of online users.

9.6.5 View Device Arming/Disarming Information via PC Web

View device arming type and arming IP address.

Go to **System and Maintenance → System Configuration → System → User Management → Arming/Disarming Information** .

You can view the device arming/disarming information. Click **Refresh** to refresh the page.

9.6.6 Network Settings

Set Basic Network Parameters

Click **System and Maintenance → System Configuration → System → Network → Network Settings → TCP/IP** .

You can view the mac address and MTU.

Set the parameters and click **Save** to save the settings.

NIC Type

DHCP ☐

* IPv4 Address

* IPv4 Subnet Mask

* IPv4 Default Gateway

IPv6 Mode ☒ Manual ☐ DHCP ☐ Route Advertisement

* IPv6 Address

* IPv6 Subnet Prefix Length

* IPv6 Default Gateway

Mac Address

MTU 1500

DNS Server

DHCP ☐

Preferred DNS Server

Alternate DNS Server

Save

Figure 9-12 Set TCP/IP

NIC Type

Select a NIC type from the drop-down list. By default, it is **Auto**.

DHCP

If uncheck the function, you should set the IPv4 address, IPv4 subnet mask, IPv4 default gateway, Mac address, and MTU.

If you check the function, the system will allocate the IPv4 address, IPv4 subnet mask, the IPv4 default gateway automatically.

IPv6 Mode

Manual

Set the IPv6 address, IPv6 subnet prefix length and IPv6 default gateway manually.

DHCP

The system will allocate the IPv6 address, IPv6 subnet prefix length and IPv6 default gateway automatically.

Route Advertisement

A mechanism for automatic address configuration in the IPv6 protocol stack. The device can complete IPv6 address configuration as long as there are routers in the environment that can provide routing notification messages.

Click **View Route Advertisement** to view the IPv6 address list.

DNS Server



Note

Only when DHCP is enabled can DNS server be set.

Set the preferred DNS server and the alternate DNS server according to your actual need.

Device Hotspot

Set the device hotspot.

Click **System and Maintenance → System Configuration → Network → Network Settings → Device Hotspot**.

Click to **Enable Device Hotspot**. Set hotspot **Name** and **Password**.

Click **Save**. You can use your phone to connect the hotspot and set parameters on the mobile web.

Set Port via PC Web

Click **System and Maintenance → System Configuration → Network → Network Service**.

HTTP

It refers to the port through which the browser accesses the device. For example, when the HTTP Port is modified to 81, you need to enter ***http://192.0.0.65:81*** in the browser for login.

HTTPS

Set the HTTPS for accessing the browser. Certificate is required when accessing.

HTTP Listening

The device can send alarm information to the event alarm IP address or domain name via HTTP protocol/HTTPS protocol. Edit the event alarm IP address or domain name, URL, port, and protocol.



Note

The event alarm IP address or domain name should support the HTTP protocol/HTTPS protocol to receive the alarm information.

Click **System and Maintenance** → **System Configuration** → **Network** → **Network Service** → **RTSP** .

It refers to the port of real-time streaming protocol.

Set OTAP via PC Web

Connect the device to the platform through the OTAP protocol to obtain device information, upload operation status and alarm information, restart and upgrade the device.

Steps

1. Click **System and Maintenance** → **System Configuration** → **Network** → **Device Access** → **OTAP** .

Select Central Group 1 2

Enable ☒

* Server IP Address

* Port

* Device ID

* Encryption Key

Register Status ❌ Offline

[More](#) ▼

Figure 9-13 Set OTAP

2. Select central group.
3. Click to **Enable** OTAP.
4. Set **Server IP Address**, **Port**, **Device ID** and **Encryption Key**.
5. Click **More** to view the network type and access priority. Drag the operation icon upward or downward to adjust the network priority.
6. Click **Test** to ensure the device can connect to the server and register successfully. Refresh the page or restart the device to see the **Register Status**.
7. Click **Save**.

Platform Access via PC Web

Platform access provides you an option to manage the devices via platform.

Steps

1. Click **System and Maintenance** → **System Configuration** → **Network** → **Device Access** → **Hik-Connect** to enter the settings page.



Note

Hik-Connect is an application for mobile devices. With the App, you can view live image of the device, receive alarm notification and so on.

2. Check **Enable** to enable the function.
3. **Optional:** Check the checkbox of **Custom**, and you can set the server address by yourself.
4. Enter the verification code.
5. **Optional:** Check **Enable** to enable video encryption, set an encryption password and confirm it.
6. Click **More** to view the network type and access priority. Drag the operation icon upward or downward to adjust the network priority.
7. Click **View** to view device QR code. Scan the QR code to bind the account.



Note

8 to 32 letters (a to z, A to Z) or numbers (0 to 9), case sensitive. You are recommended to use a combination of no less than 8 letters or numbers.

8. Click **Save** to enable the settings.
-

9.6.7 Set Video and Audio Parameters via PC Web

Configure Video Parameters via Web Browser

You can set quality, resolution and other parameters of device camera.

Click **System and Maintenance** → **System Configuration** → **Video/Audio** → **Video** to enter the settings page.

Set camera name, stream type, video type, resolution, bit rate type, video quality, frame rate, Max. bitrate, video encoding and I frame interval.

Click **Save**.

Configure Audio Parameters via Web Browser

You can set device volume.

Click **System and Maintenance** → **System Configuration** → **Video/Audio** → **Audio** to enter the settings page.

Slide to enable voice prompt function.

Slide to set **Output Volume**.

Click **Save**.

9.6.8 Set Image Parameters

You can adjust the image parameters.

Steps

1. Click **System and Maintenance** → **System Configuration** → **Image** .
2. Set the lane as **Entrance** or **Exit**.
3. Configure the parameters to adjust the image.

Image Adjustment

Drag the block or enter the value to adjust the live video's brightness, contrast, saturation, and sharpness.

LED Light

Set the supplement light type and mode. You can also set the brightness.

Backlight

Enable or disable **WDR**.

When there are both very bright and very dark areas simultaneously in the view, WDR balances the brightness level of the whole image and provide clear images with details.

Video Adjustment (Video Standard)

Set the video frame rate when performing live view remotely. After changing the standard, you should reboot the device to take effect.

PAL

25 frames per second. Suitable for mainland China, Hong Kong (China), the Middle East countries, Europe countries, etc.

NTSC

30 frames per second. Suitable for the USA, Canada, Japan, Taiwan (China), Korea, the Philippines, etc.

Beauty

Enable **Beauty**, drag the block or enter numbers to set the whiten and smooth level.

Start All Recording

You can click  to record when starting live view.

Capture

You can click  to capture image when starting live view.

Full Screen

You can click  for full screen view.


4. Click **Restore Default Settings** to restore the parameters to the default settings.

9.6.9 Serial Port Settings

Set serial port parameters.

Steps

1. Click **System and Maintenance → System Configuration → Access Configuration → Serial Port Configuration** .



The image shows a web-based configuration interface for serial port settings. At the top, there are two buttons: 'Entrance' (highlighted with a red border) and 'Exit'. Below these is a label 'Select Serial Port Position'. Underneath, the 'Serial Port Type' is set to 'RS485'. There are three dropdown menus: 'No.' with '1' selected, 'Baud Rate' with '19200' selected, and 'Data Bit' with '8' selected. Below these are three radio button options for 'Stop Bit': '1' (selected), '2', and 'Even Verification'. There are also three radio button options for 'Parity': 'None' (selected), 'Odd Parity', and 'Even Verification'. Below these are two radio button options for 'Peripheral Type': 'Card Reader' (selected) and 'Disable'. At the bottom, the 'External Device Model' is set to 'None'. A red 'Save' button is located at the bottom center of the form.

Figure 9-14 Serial Port Configuration

2. Set the serial port position as **Entrance** or **Exit**.
3. Select a serial port No., and the corresponding serial port type will display automatically.
4. Set the serial port parameters.

Baud Rate

Configure data transfer rate.

Data Bit

Configure the number of bits to send data.

Stop Bit

Select the end point for one frame of data.

Parity

Select the serial communication error detection principle. You can choose to detect that the number of 1 of the data bits and check digits is odd or even, or that there is no check digit.

5. Set the **Peripheral Type** the port connected.

6. You can view the external device model.

7. Click **Save**.

9.6.10 Preference Settings

Set Sleep Time via PC Web

The device will in sleep mode after the configured time duration. The function can reduce power consumption.

Go to **System and Maintenance** → **Preference** → **Screen Display**.

Select Channel Entrance Exit

Sleep

Sleep ☒

Sleep after 60 s

Figure 9-15 Sleep Settings

Select **Entrance** or **Exit**. The screen will execute the configured settings.

Slide **Sleep** and set the sleep time.

Click **Save**.

Set Display Theme

You can set the display theme and the sleep time for the device.

Set Theme

Click **System and Maintenance** → **Preference** → **Screen Display**.

Set the theme mode.

Simple

After selecting this mode, the authentication page will not display the live view image. The person's name, employee ID, face pictures will all be hidden after authentication.

Access Mode

The live view will be displayed in authentication, and in the meanwhile, the person's name, employee ID, face pictures will all displayed as well.

Advertisement

The advertizement takes up the full screen of authentication page, and screensaver, welcome message can be played in the advertizement.

Set Notice Publication via PC Web

You can set the notice publication for the device.

Go to **System and Maintenance** → **Preference** → **Notice Publication** .




Figure 9-16 Notice Publication

Theme Management

Click **Media Library Management** → **+** to upload the picture from the local PC.



Note

Only the format of JPG and JPEG is supported. Each picture should be smaller than 1 MB with resolution up to 1920*1280.

Add Program

You can set the program name and select program type.

Picture

If you select picture, you can click **+** to add picture.

Welcome Message

If you select welcome message, you can set the template, content, font size and color of main and sub title. You can also custom the background picture.

Play Schedule

After you have created a theme, you can select the theme and draw a schedule on the time line.

Select the drawn schedule, and you can edit the exact start and end time.

Select the drawn schedule and you can click **Delete** or **Delete All** to delete the schedule.

Slide Show Interval

Drag the block or enter the number to set the slide show interval. The picture and video will be changed according to the interval.

Customize Audio Content

Customize the output audio content when authentication succeeded and failed.

Steps

1. Click **System and Maintenance** → **Preference** → **Prompt Schedule** .

+ Add Audio File Management

Default

Enable ☒

Appellation ☐ Name ☐ Family Name ☒ None

Time Period When Authentication Succeeded

+ Add Time Duration

Time Period When Authentication Failed

+ Add Time Duration

Save

Figure 9-17 Customize Audio Content

2. Enable the function.
3. Set the appellation.
4. Set the time period when authentication succeeded.
 - 1) Click **Add Time Duration**.
 - 2) Set the time duration.



Note

If authentication is succeeded in the configured time duration, the device will broadcast the configured content.

- 3) Select the voice prompt type.

- 4) Enter the audio prompt content or select audio file.



You can click + **Audio File** or **Audio File Management** to add audio files.

- 5) **Optional:** Repeat substep 1 to 3.
 - 6) **Optional:** Click  to delete the configured time duration.
5. Set the time duration when authentication failed.
- 1) Click **Add Time Duration**.
 - 2) Set the time duration.



If authentication is failed in the configured time duration, the device will broadcast the configured content.

- 3) Select the voice prompt type.
- 4) Enter the audio prompt content or select audio file.



You can click + **Audio File** or **Audio File Management** to add audio files.

- 5) **Optional:** Repeat substep 1 to 3.
 - 6) **Optional:** Click  to delete the configured time duration.
6. Click **Save**.

9.6.11 Upgrade and Maintenance

Reboot device, restore device parameters, and upgrade device version.

Reboot Device

Click **System and Maintenance** → **Maintenance** → **Restart** .
Click **Restart** to reboot the device.

Upgrade

Click **System and Maintenance** → **Maintenance** → **Upgrade** .
Select an upgrade type from the drop-down list. Click  and select the upgrade file from your local PC. Click **Upgrade** to start upgrading.



Do not power off during the upgrading.

Restore Parameters

Click **System and Maintenance** → **Maintenance** → **Backup and Reset** .

Restore All

All parameters will be restored to the factory settings. You should activate the device before usage.

Restore

The device will restore to the default settings, except for the network parameters and the user information.

Import and Export Parameters

Click **System and Maintenance** → **Maintenance** → **Backup and Reset** .

Export

Click **Export** to export the device parameters.



Note

You can import the exported device parameters to another device.

Import

Click  and select the file to import. Click **Import** to start import configuration file.

9.6.12 Device Debugging

You can set device debugging parameters.

Steps

1. Click **System and Maintenance** → **Maintenance** → **Device Debugging** .
2. You can set the following parameters.

Lane Studying/Motor Self-Test

Enable SSH

To raise network security, disable SSH service. The configuration is only used to debug the device for the professionals.

Motor Study & Self-Test

Lane Studying

Click **Start**, the device will enter the studying mode. It will study the closed position of the barrier.

Motor Self-Test

Click **Start**, the motor will test the operation status automatically.

Encoder Self-Test

Select a channel (lane), and click **Start**, the encoder of the selected lane will test the operation status automatically.

IR Self-Test

After enabling IR self-test function, the device will sound to exit the channel (lane) before opening/closing. The barrier is forced to open in entrance/exit at the highest speed, at this time IR anti-pinch is defunct. If IR is triggered or blocked, the device will sound detection failure.

Select a channel (lane) and tap **IR Self-Test**, the device will test all IR detectors.

Note

Make sure there are no person in the lane.

Print Log

You can click **Export** to export log.

Capture Network Packet

You can set the **Capture Packet Duration**, **Capture Packet Size**, and click **Start Capture** to capture.

Debug Command Management

Select the command type **Quick Command** or enter the content of **Custom Command**.

Select the board type from the drop-down list, click **Send** to send the debug command, you can view the received command information of the device in **Execution Result**.

Click **End Debugging**, the device restores to normal operation status.

Note

- To ensure the device performance, please click **End Debugging** to close the Debugging command
 - If you do not tap **End Debugging**, the device will end the debugging mode within 7×24 hours automatically.
-

IR Exception Info.

Click **Export** to export the exceptional IR detectors reports.

Demo Mode

After enabled, the device will automatically add and authenticate after face recognition. You can set the validity period.

If disabled, all person information added in the demo mode will be cleared after disabled.

9.6.13 Test Protocol via PC Web

Select a protocol address, and enter the protocol to test. You can debug the device according to the response header and returned value.

Go to **System and Maintenance** → **Maintenance** → **Device Debugging** → **Protocol Testing**.

*Enter Protocol Address

GET

▼

Enter./ISAPI/...

Execute

Testing Result

Response Header

Return Value

Figure 9-18 Protocol Testing

Select a protocol address, and enter the protocol. Click **Execute**.

Debug the device according to the response header and returned value.

9.6.14 Set Network Penetration Service via PC Web

When the device is deployed in the LAN, you can enable the penetration service to realize device remote management.

Steps

1. Go to **System and Maintenance** → **Maintenance** → **Device Debugging** → **Network Penetration Service**.
2. Slide **Enable Penetration Service**.
3. Set **Server IP Address** and **Server Port**. Create **User Name** and **Password**.
4. **Optional:** You can set **Heartbeat Timeout**. The value range is 1 to 6000.
5. **Optional:** You can view the status of the penetration service. Click **Refresh** to refresh the status.
6. Click **Save**.



Note

The penetration service will auto disabled after 48 h.

9.6.15 Component Status

You can view the status of different components.

Main Lane Status

Device Component

You can view the status of the access control board, lane control board, etc.

Peripheral

You can view the status of the RS-485 card reader.

Temperature

You can view the pedestal temperature.

Movement

You can view the working status of motor encoder.

Others

Passing Mode

You can view the entrance and exit mode.

Input and Output Status

You can view the status of the event input, alarm output and fire alarm.

Other Status

You can view the status of the barrier and the keyfob receiving module.

9.6.16 View Log via PC Web

You can search and view the device logs.

Go to **System and Maintenance → Maintenance → Log** .

Set the major and minor type of the log type. Set the start time and end time for searching, and click **Search**.

The results will be displayed below, which including the No., time, the major type the minor type, the channel No., the local/remote user information, the remote host IP, etc.

9.6.17 Advanced Settings via PC Web

You can configure face parameters and view version information.

Go to **System and Maintenance → Maintenance → Advanced Settings** .

Enter the device activation password and click **Enter**.

Face Parameter

Enable **Custom Anti-Spoofing Detection** and you can set the **Anti-Spoofing Detection Threshold 1:1, Anti-Spoofing Detection Threshold 1:N**.

Enable **Lock Face for Authentication**, and set **Lock Duration**. The face will be locked for the set lock duration after the failed attempt limit of anti-spoofing detection has been reached.
Click **Save**.

Version Information

You can view the different version information here.

9.6.18 Certificate Management

It helps to manage the server/client certificates and CA certificate.



Note

The function is only supported by certain device models.

Create and Import HTTPS Certificate

Steps

1. Go to **System and Maintenance → Safe → Certificate Management**.
2. In the **HTTPS Certificate** area, click **Create Certificate Request**.
3. Input certificate information and click **Save**.
 - Click **View** and the created certificate will be displayed.
 - The certificate will be saved automatically.
4. Download the certificate and save it to an asking file in the local computer.
5. Send the asking file to a certification authority for signature.
6. Import the signed certificate.
 - 1) In the **Import Key** area, select a certificate from the local, and click **Import**.
 - 2) In the **Import Communication Certificate** area, select a certificate from the local, and click **Import**.

Create and Import SYSLOG Certificate

Steps

1. Go to **System and Maintenance → Safe → Certificate Management**.
2. In the **SYSLOG Certificate** area, click **Create Certificate Request**.
3. Input certificate information and click **Save**.
 - Click **View** and the created certificate will be displayed.
 - The certificate will be saved automatically.
4. Download the certificate and save it to an asking file in the local computer.
5. Send the asking file to a certification authority for signature.
6. Import the signed certificate.
 - 1) In the **Import Key** area, select a certificate from the local, and click **Import**.

- 2) In the **Import Communication Certificate** area, select a certificate from the local, and click **Import**.

Import CA Certificate

Before You Start

Prepare a CA certificate in advance.

Steps

1. Go to **System and Maintenance → Safe → Certificate Management**.
2. Create an ID in the **CA Certificate ID** area.



Note

The input certificate ID cannot be the same as the existing ones.

3. Upload a certificate file from the local.
4. Click **Import**.

Chapter 10 Other Platforms to Configure

You can also configure the device via iVMS-4200 Client Software or HikCentral Access Control. For details, see the platforms' user manual.

iVMS-4200 Client Software

Click/tap the link to view the client software's user manual.

<http://enpinfodata.hikvision.com/analysisQR/showQR/ca930247>

HikCentral Access Control (HCAC)

Click/tap the link to view the HCAC's user manual.

<http://enpinfodata.hikvision.com/analysisQR/showQR/f2f6cf42>

Appendix A. Event and Alarm Type

Event	Alarm Type
Tailgating	Visual and Audible
Reverse Passing	Visual and Audible
Force Accessing	None
Climb over Barrier	Visual and Audible
Overstay	Visual and Audible
Passing Timeout	None
Intrusion	Visual and Audible
Free Passing Authentication Failed	Visual
Barrier Obstructed	None

Appendix B. Legal Information

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

- This product can only enjoy the after-sales service support in the country or region where the purchase is made.
- If the product you choose is a video product, please scan the following QR code to obtain the "Initiatives on the Use of Video Products", and read it carefully.



Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR

IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.

Data Protection

- To protect data, the development of Hikvision Products incorporates privacy by design principles. For example, for Products with facial recognition features, biometrics data is stored in your Products with encryption method; for fingerprint Products, only fingerprint template will be saved, which is impossible to reconstruct a fingerprint image.
- As a data controller/processor, you may process personal data, including collection, storage, use, processing, disclosure, deletion, etc. You are advised to pay attention to and comply with applicable laws and regulations related to the protection of personal data, including without limitation, conducting security controls to safeguard personal data, such as, implementing reasonable administrative and physical security controls, conduct periodic reviews and the assessments of the effectiveness of your security controls.

© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.



See Far, Go Further