HIKVISION EN 50131-1:2006+A1:2009+A2:2017 EN 50131-3:2009

EN 50131-5-3:2017

Security Grade(SG) 2 Environmental Class(EC) II Certified by Telefication \_.crication telefication

## ©2020 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved. About this Manual

Adout units Manual The Manual includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website (https://www.hikvision.com/). Please use this Manual with the guidance and assistance of professionals trained in supporting the roduct.

HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions. Other trademarks and logos mentioned are the properties of their respective owners

Disclaimer TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL, INCIDENTIAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF DOLOXUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LUBLITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS. YOU ACKNOWLEDGE THAT THE NATURE OF INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER INTERNET SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER INTERNET SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM (YDER-ATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM (YDE RATTACK, HACKER ATTACK, VIRUS INSPECTION, OR OTHER INTERNET SECURITY RISKS, IND VOU ARE SOLELY RESPONSIBLE FOR USING THIMELY TECHNICAL SUPPORT IF REQUIRED. YOU AGROWLEDGE THAT THE NATURE OF INTERNET SECURITY RISKS, IND WOVEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED. YOU AGROWLEDGE THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS ABUCIT, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER REPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT

This product and - if applicable - the supplied accessories too are marked with "CE" and comply therefore with the applicable harmonized European standards listed under the EMC Directive 2014/30/EU, RE Directive 2014/53/EU, the ROHS Directive 2011/65/EU. Ε

∕!∖


replacement of a battery with an incorrect type that can defeat a safeguard (for example, in the case of some lithium battery types); – disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion; – leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas; and – a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas



2012/19/EU (WEEE directive): Products marked with this symbol 2012/19/EU (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info

2006/66/EC (battery directive): This product contains a battery that cannot be disposed of as unsorted municipal waste in the European Union. See the product documentation for specific battery information. The battery is marked with this symbol, which may include lettering to indicate cadmium (Cd), lead (Pb), or mercury (Hg). For proper recycling, return the battery to your supplier or to a designated collection point. For more information see:www.recy-clethis.info

#### 1 Appearance





Note: The packaging box includes 2pcs tags (DS-PT-M1) by default.

## 2 Enrollment

Note: The enrollment progress will be completed in 3 to 10 seconds normally.

- 1. Log in to the APP Store, download and install the App.
- 2. Power on the security control panel.
- 3. Log in the APP and tap the icon "+". Scan the QR code or input the control panel serial No. to add the control panel.
- Enroll the Peripheral Locally
- 1. In the APP, tap the "Enrollment Mode" button on the control panel page to make the control panel enter the enrollment status.
- 2. Loosen the screw and remove rear panel.
- 3. Power on the peripheral, and it will be automatically enrolled to the control panel.





(A


The distance between the device and AXPRO should be less than 50 cm.

**2** Enroll the Peripheral with QR and serial No.

1. In the APP, tap the icon "+"and scan the QR code or serial No. on the peripheral.

2. Loosen the screw and remove rear panel.

3. Power on the peripheral, and it will be automatically enrolled to the control panel.




## **3** Installation

1. Check Signal Strength

Enter the signal checking mode by operating on the control panel. Trigger the device. Solid Green for 3 s - Strong Signal Solid Orange for 3 s - Medium Signal Solid Red for 3 s - Weak Signal Red light flashes for 3S - Lost Signal






2. Install the tag reader.

Note: The additional force shall be equal to three times the weight of the equipment but not less than 50N. The equipment and its associated mounting means shall remain secure during the installation. After the installation, the equipment, including any associated mounting plate, shall not be damaged.

a. Secure the rear panel on the wall with four screws.




b. Tighten the set screw on the bottom of the device.



# **4** Operation

## Arming/Disarming



## Formatting

Hold the tamper switch for 8 s and power the device on at the same time. The red LED flashes 3 times when the formatting operation is completed.

### **5** Operation Caution and Device Maintenance

- All the electronic operation should be strictly compliance with the electrical safety regulations, fire prevention regulations and other related regulations in your local region.

- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).

- Please make sure that the power has been disconnected before you wire, install or dismantle the device.

- If smoke, odors or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

- Do not drop the device or subject it to physical shock, and do not expose it to high electromagnetism radiation. Avoid the equipment installation on vibrations surface or places subject to shock (ignorance can cause equipment damage).

- Do not place the device in extremely hot (refer to the specification of the device for the detailed operation temperature), cold, dusty or damp locations, and do not expose it to high electromagnetic radiation.

- The device for indoor use shall be kept from rain and moisture.

Exposing the equipment to direct sun light, low ventilation or heat source such as heater or radiator is forbidden (ignorance can cause fire danger).

- Do not aim the device at the sun or extra bright places. A blooming or smear may occur otherwise (which is not a malfunction however), and affecting the endurance of sensor at the same time.

- Improper use or replacement of the battery may result in hazard of explosion. Replace with the same or equivalent type only. Dispose of used batteries according to the instructions provided by the battery manufactur-

er.

- Do not expose the device to the corrosive gas. Otherwise the equipment damage may occur.

- Do not expose the device to the explosive situation.

# 6 Specification

| 868 MHz   |
|---|
| Two-way communication   |
| 1.2 KM  |
| 1, rear panel tamper-proof  |
| 1 status indicator(red, green, blue), and 4 area arming indicator (blue)  |
| 1   |
| 1.5V, 3 AA batteries, (included, Capacity: 2300 mAh each)<br>2 years battery life span (10 times presenting each day) |
| 1.2 V   |
| Fully charged (new) to 1.2 V (battery)  |
| Max. current: 292mA   |
| Quiescent current: 110uA  |
| Туре С  |
| 10% to 90%  |
| - 10°C to +55°C (-10 °C to 40 °C EN Certified)  |
| Use inside the supervised premises, Type: ACE   |
| Wall mounting   |
| 124mm x 75mm x 21mm   |
| 176g (with battery), 106.5g (without battery)   |
|   |

Note:

- when the low voltage message appears there will be at least 30 days of use.

- The tag ID/PIN is a 32 bit long integer, and the variant could be 42949672956.