


INSTRUCTION MANUAL

OLYMPIC II




Connector not included




| OLYMPIC II | | | | | |
|------------|------|-----------------|-----------------|-------|-------|
| Reference | W | V _{in} | I _{in} | cos φ | ⊞ (g) |
| OLP0300 | 300 | 90~305 Vac | 1,36A | 0,96 | 7600 |
| OLP0600 | 600 | 90~305 Vac | 2,75A | 0,96 | 16500 |
| OLP0900 | 900 | 90~305 Vac | 4,08A | 0,96 | 23000 |
| OLP1200 | 1200 | 90~305 Vac | 5,43A | 0,96 | 29000 |


OLP0300




OLP0600



OLP0900



OLP1200



| OLYMPIC II | | |
|------------|-----|--------|
| Reference | M | D1 |
| OLP0300 | M12 | 270,00 |
| OLP0600 | M17 | 330,00 |
| OLP0900 | M17 | 330,00 |
| OLP1200 | M17 | 330,00 |

