



DC-D Series

Installation Manual

- DC-D4511WERX
- DC-D4531WERX

Safety Precautions

<p>WARNING RISK OF ELECTRIC SHOCK DO NOT OPEN</p>
<p>WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.</p>

Important Safeguards

1. Read Instructions

All the safety and operating instructions should be read before the appliance is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Cleaning

Unplug this equipment from the wall outlet before cleaning it. Do not use liquid aerosol cleaners. Use a damp soft cloth for cleaning.

4. Attachments

Never add any attachments and/or equipment without the approval of the manufacturer as such additions may result in the risk of fire, electric shock or other personal injury.

5. Water and/or Moisture

Do not use this equipment near water or in contact with water.

6. Placing and Accessories

Do not place this equipment on a wall or ceiling that is not strong enough to sustain the camera. The equipment may fall, causing serious injury to a child or adult, and serious damage to the equipment. Wall or shelf mounting should follow the manufacturer's instructions, and should use a mounting kit approved by the manufacturer.



This equipment and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the equipment and cart combination to overturn.

Do not place this equipment in an enclosed space. Sufficient ventilation is required to prevent an increase in ambient temperature which can cause malfunction or the risk of fire.

7. Power Sources

This equipment should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power, please consult your equipment dealer or local power company. You may want to install a UPS (Uninterruptible Power Supply) system for safe operation in order to prevent damage caused by an unexpected power stoppage. Any questions concerning UPS, consult your UPS retailer.

This equipment should be remain readily operable.

8. Power Cord

Operator or installer must remove power and TNT connections before handling the equipment.

9. Lightning

For added protection for this equipment during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the equipment due to lightning and power-line surges. If thunder or lightning is common where the equipment is installed, use a surge protection device.

10. Overload

Do not overload wall outlets and extension cords as this can result in the risk of fire or electric shock.

11. Objects and Liquids

Never push objects of any kind through openings of this equipment as they may touch dangerous voltage points or short out parts that could result in a fire or electric shock. Never spill liquid of any kind on the equipment.

12. Servicing

Do not attempt to service this equipment yourself. Refer all servicing to qualified service personnel.

13. Damage requiring Service

Unplug this equipment from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- When the power-supply cord or the plug has been damaged.
- If liquid is spilled, or objects have hit the equipment.
- If the equipment has been exposed to rain or water.
- If the equipment does not operate normally by following the operating instructions, adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the equipment to its normal operation.
- If the equipment has been dropped, or the cabinet damaged.
- When the equipment exhibits a distinct change in performance—this indicates a need for service.

14. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or that have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock or other hazards.

15. Safety Check

Upon completion of any service or repairs to this equipment, ask the service technician to perform safety checks to determine that the equipment is in proper operating condition.

16. Field Installation

This installation should be made by a qualified service person and should conform to all local codes.

17. Correct Batteries

Warning: Risk of explosion if battery is replaced by an incorrect type. Replace only with the same or equivalent type.

Dispose of used batteries according to the instructions.

The battery shall not be exposed to excessive heat such as sunshine, fire or the like.

18. Tmra

A manufacturer's maximum recommended ambient temperature (Tmra) for the equipment must be specified so that the customer and installer may determine a suitable maximum operating environment for the equipment.



Warning: This product emits infrared light. Do not look into the IR LED.

FCC Compliance Statement

THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN THE EQUIPMENT IS OPERATED IN A COMMERCIAL ENVIRONMENT. THIS EQUIPMENT GENERATES, USES, AND CAN RADIATE RADIO FREQUENCY ENERGY AND IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE. IN WHICH CASE USERS WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT THEIR OWN EXPENSE. **WARNING:** CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT. THIS CLASS OF DIGITAL APPARATUS MEETS ALL REQUIREMENTS OF THE CANADIAN INTERFERENCE CAUSING EQUIPMENT REGULATIONS.

WEEE (Waste Electrical & Electronic Equipment)

Correct Disposal of This Product

(Applicable in the European Union and other European countries with separate collection systems)



This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Copyright

©2021 IDIS Co., Ltd.

IDIS Co., Ltd. reserves all rights concerning this operation manual.

Use or duplication of this operation manual in part or whole without the prior consent of IDIS Co., Ltd. is strictly prohibited.

Contents of this operation manual are subject to change without prior notice for reasons such as functionality enhancements.

Registered Trademarks

IDIS is a registered trademark of IDIS Co., Ltd.

Other company and product names are registered trademarks of their respective owners.

The software included in this product contains some Open Sources. You may obtain the corresponding source code which we have to distribute according to the license policy. For more information, refer to **System > General** page. This product includes software developed by the University of California, Berkeley and its contributors, and software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>). Also, this product includes cryptographic software written by Eric Young (ey@cryptsoft.com).

Covered by one or more claims of the patents listed at patentlist.accessadvantage.com


Accessories

Upon purchasing the product, check inside the box to make sure all the following accessories are included. External appearances and colors of the accessories may vary depending on the model.

ITEM	
Network Camera	Guide Pattern
Quick Guide	Screws and Anchors (each 3ea)
Pigtail Connector Insulator and Rubber Bushing	


Overview

DC-D4511WERX



①	Bottom Cover
②	Low Pressure Ring
③	SD Memory Card Slot Factory Reset Button
④	Lens
⑤	Built-in Microphone
⑥	IR LED
⑦	High Pressure Ring
⑧	Network Port
⑨	DC-12V

DC-D4531WERX



①	Bottom Cover
②	Low Pressure Ring
③	SD Memory Card Slot Factory Reset Button
④	Lens
⑤	IR LED
⑥	High Pressure Ring
⑦	DC-12V
⑧	Audio Input
⑨	Audio Output
⑩	Network Port
⑪	Alarm I/O

Installation



• Check the wall or ceiling to see if it needs to be reinforced. The camera may fall off if the wall or ceiling is not strong enough to support its weight.

• Install the camera in a shaded area. If the camera is installed in direct sunlight, it may affect adversely.


• Use the provided guide pattern to check the distance between the screw holes if necessary.

DC-D4511WERX / DC-D4531WERX

1. Remove the white paper of the provided guide pattern and attach it to the wall or ceiling.




2. Remove the low pressure ring from the camera bottom cover by rotating the ring in anti-clockwise.




3. After you insert the SD memory card in the camera, secure the body on a wall or ceiling using the screws, and anchors that came with the camera.

4. Attach the low pressure ring to the bottom cover. Turn the ring clockwise to hold the camera body.


• Do not fasten the ring too hard till completing angle adjustment.



5. The lens can be rotated along three axes. Adjust the angles accordingly.



6. Secure the low pressure ring to the body by turning the ring clockwise completely.




Factory Reset

Only use the factory reset button to restore the camera to its factory default settings.


1. Remove the cover of SD card slot and then press the reset button down.
2. Hold the button down for 10 seconds.
3. All camera settings will be restored to their factory defaults.

Dimension

DC-D4511WERX



DC-D4531WERX



Specifications

Model	DC-D4511WERX	DC-D4531WERX
Video		
Image Sensor	1/2.7" CMOS	
Max. Resolution	2592 x 1944	
Scanning Mode	Progressive Scan	
Lens type	Fixed-focal	Motorized Vari-focal
Focal Length	f=2.8mm	f=2.7 - 12mm
Aperture	F 1.6	F 1.83 (Wide) ~ 3.32 (Tele)
Iris Control	Fixed Iris	DC Iris
Angular Field of View Wide	99°(H), 72°(V), 131°(D)	99°(H), 72°(V), 131°(D)
Min. Illumination	Color 0.05lux @ F1.2 (AGC ON), B/W 0 lux @ IR ON	
Dynamic Range	120dB, True WDR	
Electronic Shutter Speed	1/5 - 1/20000s, Anti-Flicker, Slow Shutter (1-1/5, 1/7.5, 1/15)	
Day & Night	IR cut filter with auto switch	
IR Distance (LEDs)	25 m (2 ea)	45 m (4 ea)
Pan/Tilt Range	Bracket: Pan 0-360°; Lens: Pan 0-360°, Tilt: 0-80°	
Network		
Video Compression	H.265, H.264(MP)	
Bit rate Control	CBR / VBR	
Max. Frame Rate	30fps : 2592x1944 (WDR)	
Audio Compression	G711A (G.711 a-Law), G711U (G.711 u-Law), ADPCM 16K, G726	
Supported Resolution	2592x1944, 2592x1520, 2304x1296, 1920x1080, 1280x960, 1280x720	
Multi-Video Streaming	Triple	
Ethernet	RJ45(10/100BASE-T)	
Edge Storage* (Optional)	Micro SD/SDHC/SDXC memory card (class 6 or higher, max. 256GB)	
<ul style="list-style-type: none"> • An SLC (Single Level Cell) or MLC (Multi Level Cell) card by SanDisk or Transcend is recommended to ensure stable recording performance. • An SD memory card is a consumable product with a finite service life. Prolonged use will damage the card's memory sectors and result in data loss or memory card failure. Test the SD memory card regularly and replace it whenever necessary. • microSD Logo is a trademark of SD-3C, LLC. 		
I/O		
Audio In/Out	Internal MIC	RCA 1ea / RCA 1ea
Alarm In	-	1 switch input
Alarm Out	-	0.5 A at 125 VAC/ 2A at 30 VDC
Video Out**	-	-
General		
Operating Temperature	-30°C ~ +55°C (-22°F ~ +131°F)	
Operating Humidity	0% ~ 90%	
Power Source	DC 12V, POE (IEEE 802.3af Class 3)	
Power Consumption	Max. 6.5W	Max. 9W
Approval	FCC, CE, IP66	
External Dimensions(Ø x H)	90mm x Ø100mm (3.5" x Ø3.9")	Ø135.6mm x 127mm (Ø5.3" x 4.95")
Weight(Main Unit)	0.53kg (1.17lb)	0.84kg (1.85lb)